

[Manuals.plus](#) /

› [BLACK+DECKER](#) /

› BLACK+DECKER 90567079 Lever Instruction Manual

BLACK+DECKER 90567079

BLACK+DECKER 90567079 Lever Instruction Manual

Model: 90567079 | Brand: BLACK+DECKER

INTRODUCTION

This manual provides essential information for the **BLACK+DECKER 90567079 Replacement Lever**. This genuine OEM part is designed for specific BLACK+DECKER models to ensure proper function and fit. Please read these instructions carefully before attempting any installation or maintenance.

PRODUCT OVERVIEW



This image displays the BLACK+DECKER 90567079 Replacement Lever. It is a black, molded plastic component with a metallic pin and collar assembly at one end, designed for precise mechanical operation within compatible tools.

Key Features

- Genuine, OEM Black & Decker Replacement Part
- Part number 90567079
- Compatible with: GH610 Type 1, GH900 Type 1, GH900 Type 2
- Easy to Install

SETUP AND INSTALLATION

Before beginning any installation, ensure the tool is **disconnected from its power source** to prevent accidental operation. Wear appropriate personal protective equipment, such as gloves and eye protection.

1. **Identify the Lever:** Locate the existing lever on your BLACK+DECKER tool that needs replacement.
2. **Remove Fasteners:** Carefully remove any screws, clips, or other fasteners securing the old lever in place. Keep track of all hardware for reinstallation.
3. **Remove Old Lever:** Gently detach and remove the worn or damaged lever from its mounting point.
4. **Position New Lever:** Align the new BLACK+DECKER 90567079 replacement lever with the corresponding mounting points on the tool. Ensure it fits snugly and correctly.
5. **Secure New Lever:** Reinstall the fasteners removed in step 2, ensuring the new lever is securely attached and does not wobble. Do not overtighten.
6. **Test Functionality:** Before reconnecting power, manually operate the lever to ensure it moves freely and engages/disengages the intended mechanism smoothly.
7. **Reconnect Power:** Once satisfied with the installation, reconnect the tool to its power source and perform a final operational check.

OPERATING INSTRUCTIONS

The 90567079 lever is an integral component that facilitates specific mechanical actions within compatible BLACK+DECKER tools, such as the GH610 and GH900 models. Its function is to engage or disengage a mechanism, allowing for control over the tool's operation. The specific use of this lever is dictated by the design of the tool it is installed in. For detailed operational procedures involving this lever, please refer to your specific tool's main instruction manual.

MAINTENANCE

Proper maintenance of the 90567079 lever ensures its longevity and the continued performance of your tool.

- **Cleaning:** Keep the lever and its surrounding area clean and free from dirt, dust, and debris. Use a dry cloth or soft brush for cleaning.
- **Inspection:** Periodically inspect the lever for any signs of wear, cracks, or damage. Check that it moves freely and without excessive play.
- **Lubrication:** If the lever mechanism feels stiff, a small amount of appropriate lubricant (as recommended by your tool's main manual) may be applied to pivot points, avoiding electrical components.
- **Replacement:** If the lever shows significant wear, damage, or no longer functions correctly, replace it immediately with a genuine BLACK+DECKER 90567079 part to maintain tool safety and performance.

TROUBLESHOOTING

If you encounter issues with your 90567079 replacement lever, consider the following common troubleshooting steps:

- **Lever Not Moving Freely:**
 - Check for any obstructions (debris, foreign objects) around the lever's pivot points.
 - Ensure the lever is correctly installed and not binding against other components.
- **Lever Not Engaging/Disengaging:**
 - Verify that the lever is properly aligned with the mechanism it controls.
 - Inspect connecting rods or springs that might be linked to the lever for damage or dislodgement.
- **Lever Appears Broken or Damaged:**
 - If the lever is physically broken, cracked, or severely worn, it requires replacement. Do not attempt to repair a damaged lever as it may compromise tool safety.

If these steps do not resolve the issue, consult a qualified service technician or refer to your tool's comprehensive service manual.

SPECIFICATIONS

Brand	BLACK+DECKER
Model Number	90567079
Part Type	Replacement Lever
Compatibility	GH610 Type 1, GH900 Type 1, GH900 Type 2
Color	Polished Black
Product Dimensions	1"L x 1"W
Item Weight	0.16 ounces (approx. 4.54 g)
Exterior Finish	Polished
Special Feature	Easy to Install
Manufacturer	Black & Decker
UPC	704660026997

WARRANTY AND SUPPORT

This 90567079 lever is a genuine BLACK+DECKER OEM replacement part, designed to meet the manufacturer's quality standards. Using genuine replacement parts helps maintain the integrity, performance, and warranty of your original tool.

For specific warranty information regarding your BLACK+DECKER tool or for technical support, please refer to the documentation provided with your original BLACK+DECKER product or visit the official BLACK+DECKER website. Contacting authorized service centers is recommended for complex issues or professional assistance.