

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Humanscale](#) /

› [Humanscale M8 Adjustable Articulating Monitor Arm Instruction Manual](#)

Humanscale M8

Humanscale M8 Adjustable Articulating Monitor Arm Instruction Manual

Model: M8

INTRODUCTION

The Humanscale M8 Adjustable Articulating Monitor Arm is engineered for both strength and aesthetic appeal. Designed to support a wide range of monitors, it offers dynamic adjustability to enhance ergonomic comfort and optimize workspace efficiency. This manual provides comprehensive instructions for the installation, operation, and maintenance of your M8 monitor arm.



Figure 1: Humanscale M8 Monitor Arm with Bolt-Through Mount, Polished Aluminum with White Trim.

SETUP AND INSTALLATION

The M8 monitor arm offers flexible mounting options to suit various desk configurations. This model is equipped with a Bolt-Through Mount. A Clamp Mount option is also available for other variants.

Mounting Options

- **Bolt-Through Mount:** This method involves drilling a hole through your desk to secure the arm. It provides a highly stable and permanent installation.
- **Clamp Mount:** (Not included with this specific variant) This option allows the arm to be clamped to the edge of your desk without drilling.




Figure 2: Illustration of Bolt-Through Mount and Clamp Mount configurations.

VESA Compatibility

The VESA plate supports all monitors with 75mm and 100mm VESA hole patterns. Ensure your monitor is compatible before installation.

Cable Management

The M8 arm features integrated cable management to keep your workspace tidy and organized. Route monitor cables through the designated channels along the arm for a clean aesthetic.





Figure 3: Integrated cable management keeps cables organized along the arm.

Installation Video

Video 1: Official

Related Documents - M8

 M/Connect 2 <small>Assembly Instructions</small>	<p>Humanscale M/Connect 2 Assembly Instructions</p> <p>A comprehensive guide for assembling and installing the Humanscale M/Connect 2, covering parts included, installation guidelines, port identification, various mounting methods, cable connections, software installation, troubleshooting, system requirements, electrical specifications, and FCC notices.</p>
---	---

 <p>Nova Assembly Instructions</p>	<p>Humanscale Nova LED Desk Lamp Assembly and User Guide</p> <p>Comprehensive guide for assembling and using the Humanscale Nova LED desk lamp, including installation steps for various mounts, operation of the occupancy sensor and dimming features, safety precautions, and product specifications.</p>
 <p>Humanscale M2.1 Direct Wall Mount Installation Instructions</p>	<p>Humanscale M2.1 Direct Wall Mount Installation Instructions</p> <p>Step-by-step installation guide for the Humanscale M2.1 Direct Wall Mount, detailing mounting procedures, arm rotation adjustments, and component assembly.</p>
 <p>Humanscale M8.1/M10 SlatWall Mount Installation Guide</p>	<p>Humanscale M8.1/M10 SlatWall Mount Installation Guide</p> <p>Detailed installation instructions for the Humanscale M8.1 and M10 SlatWall Mounts, covering attachment to slat walls and arm positioning.</p>
 <p>Humanscale M8.1/M10 Direct Wall Mount Installation Instructions</p>	<p>Humanscale M8.1/M10 Direct Wall Mount Installation Instructions</p> <p>Comprehensive guide for installing the Humanscale M8.1 and M10 Direct Wall Mount monitor arms, detailing each step from preparation to final attachment.</p>
 <p>Humanscale' PRODUCT CARE GUIDE</p>	<p>Humanscale Product Care Guide: Cleaning Instructions for Furniture and Accessories</p> <p>A comprehensive guide from Humanscale detailing the proper cleaning and care instructions for various product lines, including seating, sit/stand desks, monitor arms, lighting, ergo tools, cable management, and separation panels. Learn how to maintain your Humanscale products for longevity and optimal performance.</p>