

manuals.plus /

› [Movado](#) /

› [Movado 0606555 Men's Stainless Steel Quartz Watch Instruction Manual](#)

Movado 0606555

Movado 0606555 Men's Stainless Steel Quartz Watch Instruction Manual

1. INTRODUCTION AND OVERVIEW

This manual provides essential instructions for the proper setup, operation, and maintenance of your Movado 0606555 Men's Stainless Steel Quartz Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image 1.1: Front view of the Movado 0606555 watch, featuring a black dial, silver-tone stainless steel case, and matching bracelet.

Key Features:

- Swiss Quartz movement for precise timekeeping.
- Durable stainless steel case and bracelet.
- Scratch-resistant sapphire crystal.
- Water resistance up to 30 meters (100 feet).
- Classic black dial with Movado's signature dot at 12 o'clock.

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Ensure all protective films are removed from the crystal, case back, and bracelet.

2.2 Adjusting the Bracelet

The stainless steel bracelet may require adjustment to fit your wrist comfortably. This typically involves removing or adding links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to prevent damage to the bracelet or clasp mechanism.

2.3 Setting the Time

1. Pull the crown (the small knob on the side of the watch case) gently outwards to the time-setting position.
2. Rotate the crown in either direction to move the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position against the watch case. This will start the watch movement.

3. OPERATING THE WATCH

Your Movado 0606555 watch is powered by a precise Swiss Quartz movement. Once the time is set, the watch will operate continuously until the battery requires replacement.

3.1 Basic Timekeeping

The watch displays hours and minutes via two central hands. The Movado signature concave dot at the 12 o'clock position serves as the primary indicator for orientation.

4. MAINTENANCE

4.1 Cleaning

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

4.2 Water Resistance

This watch is water resistant to 30 meters (100 feet). This rating means the watch is suitable for splashes or brief immersion in water, but not for swimming, showering, or diving. Ensure the crown is fully pushed in before any contact with water. Prolonged exposure to water or steam should be avoided.

4.3 Battery Replacement

The watch is powered by a CR2 battery. When the watch stops or the hands move erratically, it indicates that the battery needs replacement. Battery replacement should be performed by a professional watchmaker to ensure proper sealing and maintain water resistance.

4.4 Storage

When not wearing your watch, store it in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it away from strong magnetic fields, which can affect the quartz movement's accuracy.

5. TROUBLESHOOTING

| Issue | Possible Cause | Solution |
|------------------------------------|---|---|
| Watch stops or runs intermittently | Depleted battery | Replace battery by a professional watchmaker. |
| Time is inaccurate | Incorrect time setting; exposure to strong magnetic fields | Reset the time. Keep watch away from magnets. If issue persists, consult a professional. |
| Condensation inside crystal | Exposure to extreme temperature changes or compromised water resistance | Immediately take the watch to a professional watchmaker for inspection and repair to prevent internal damage. |

6. SPECIFICATIONS

- **Model Number:** 0606555
- **Movement:** Swiss Quartz
- **Case Material:** Stainless Steel
- **Case Diameter:** 40 mm
- **Case Thickness:** 8 mm
- **Dial Color:** Black
- **Crystal:** Sapphire
- **Band Material:** Stainless Steel
- **Clasp Type:** Deployment with Push Button Release
- **Water Resistance:** 30 meters (100 feet)
- **Battery Type:** 1 CR2 battery (included)
- **Product Dimensions:** 11.99 x 11.99 x 11.99 cm
- **Item Weight:** 315 g

7. WARRANTY AND SUPPORT

Information regarding the specific warranty terms and customer support for your Movado 0606555 watch is not provided within this manual. For detailed warranty information, service inquiries, or to locate an authorized service center, please refer to the official Movado website or contact Movado customer service directly. Retain your proof of purchase for warranty claims.