Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TOOLPORT PRO Smart

TOOLPORT 10x7 ft Marquee Party Tent PRO Smart Instruction Manual

Model: PRO Smart (8641)

1. Introduction

This manual provides essential instructions for the safe and correct assembly, operation, and maintenance of your TOOLPORT 10x7 ft Marquee Party Tent, model PRO Smart. Please read this manual thoroughly before attempting to set up or use the tent. Retain this manual for future reference.



Image 1.1: Fully assembled TOOLPORT 10x7 ft Marquee Party Tent.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- **Weather Conditions:** This tent is designed for temporary use. Do not use in extreme weather conditions such as

heavy winds, snow, or severe thunderstorms. High winds can cause the tent to collapse, leading to injury or property damage. Always secure the tent properly with all provided ground pegs and safety ropes.

- **Fire Hazard:** Keep all flame and heat sources away from the tent fabric. The tent material is not fireproof.
- **Assembly:** Assembly requires at least 2-3 adults. Ensure all connections are securely bolted before use.
- **Location:** Choose a level, clear area for setup, away from overhead power lines, trees, or other obstructions.
- **Anchoring:** Always use all provided ground pegs and safety ropes to anchor the tent securely. In soft ground, additional anchoring may be required (e.g., sandbags, heavier stakes).

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact TOOLPORT customer service.

- Steel Frame Components (approx. 38mm steel tubes, approx. 42mm connectors)
- PVC Tarpaulins (Roof, Sidewalls, Front with entrances)
- Ground Pegs
- Safety Ropes
- Assembly Manual
- Wrench/Tool for bolted connections




Image 3.1: Illustration of the steel frame components.

4. Setup and Assembly

Assembly typically requires 2-3 people. Follow these general steps for setting up your tent. Refer to the detailed diagrams in the included paper manual for specific part identification and connection points.

1. **Unpack and Sort:** Lay out all frame components and tarpaulins. Identify all parts according to the parts list in your detailed manual.
2. **Assemble the Roof Frame:** Connect the roof poles and connectors. Ensure all bolted connections are tightened securely.
3. **Attach the Roof Tarpaulin:** Drape the one-piece roof tarpaulin over the assembled roof frame. Secure it temporarily.
4. **Assemble the Leg Poles:** Attach the leg poles to the roof frame connectors.
5. **Raise the Frame:** With assistance, carefully raise the entire frame structure.

6. **Secure Base Plates:** Ensure the base plates of the leg poles are flat on the ground.
7. **Attach Sidewalls:** Hang the sidewalls, including those with integrated wind deflectors and entrances, to the frame using the elastic loops and grommets. Ensure the wind deflectors are positioned correctly at the bottom.
8. **Final Tarpaulin Adjustments:** Adjust all tarpaulins to ensure a snug fit and proper coverage.
9. **Anchor the Tent:** Drive all ground pegs through the designated loops at the base of the tent and attach safety ropes to the frame, securing them to the ground with additional pegs. This step is crucial for stability.



Image 4.1: Detail of a bolted steel frame connection.



Image 4.2: Sidewall with integrated wind deflector.

5. Operation

The TOOLPORT Marquee Party Tent is designed for various outdoor events and temporary shelter needs. Its PVC 700 N tarpaulins provide waterproof protection and UV resistance (UPF 50+).

- **Entrances:** The front sidewalls feature integrated entrances for easy access.
- **Climate Control:** Sidewalls with integrated wind deflectors help manage airflow and provide protection from drafts.
- **Ventilation:** Ensure adequate ventilation, especially if using heating or cooking equipment inside (maintain safe distances from tent fabric).



Image 5.1: Front view of the tent with an open entrance.

6. Maintenance

Proper maintenance will extend the lifespan of your tent.

- **Cleaning:** Clean PVC tarpaulins with mild soap and water. Avoid harsh chemicals or abrasive cleaners, which can damage the material. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Inspection:** Regularly inspect the steel frame for any signs of rust, bending, or damage. Ensure all bolted connections remain tight.
- **Tarpaulin Inspection:** Check tarpaulins for tears, holes, or weakened areas. Repair minor damage promptly to prevent further deterioration.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure tarpaulins are completely dry to prevent mold and mildew.

7. Troubleshooting

Problem	Possible Cause	Solution
Tent unstable in wind	Insufficient anchoring; loose frame connections; extreme wind conditions.	Ensure all ground pegs and safety ropes are securely fastened. Tighten all bolted frame connections. Do not use in high winds. Consider additional anchoring methods for soft ground.
Water leakage	Tarpaulin not properly tensioned; minor tears; improper assembly.	Ensure the roof tarpaulin is taut and correctly positioned. Check for any tears and repair them. Verify all sidewalls are properly attached and overlapping where necessary.
Difficulty assembling frame	Incorrect part orientation; insufficient manpower.	Refer to the detailed assembly diagrams. Ensure parts are oriented correctly. Assembly is easier with 2-3 people.

8. Specifications

- **Brand:** TOOLPORT
- **Model:** PRO Smart
- **Manufacturer Part Number:** 8641
- **Dimensions (L x W x H):** 120"L x 84"W x 79"H (10x7 ft)
- **Floor Area:** 6 Square Meters
- **Material:** Metal (Frame), PVC 700 N (Tarpaulins)
- **Frame Material:** Alloy Steel (approx. 38mm tubes, approx. 42mm connectors)
- **Color:** White
- **Item Weight:** 49100 Grams
- **Water Resistance Level:** Waterproof
- **Ultraviolet Light Protection:** 50+
- **Required Assembly:** Yes




Image 8.1: Tent dimensions diagram (3x2m equivalent to 10x7ft).

9. Warranty and Support

For warranty information, please refer to the official TOOLPORT warranty document available at:

https://manuals.plus/m/4e2b2d6b1df36973eb78637d1a03f2ca3ece89839fd4f968910514f5a6da5120
For further assistance, technical support, or to inquire about replacement parts, please contact TOOLPORT customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00A8IJJRO

More documents and user manuals: **https://manuals.plus/**