

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BANDAI SPIRITS](#) /

› [Bandai Hobby High Grade Universal Century 1/144 Nemo Action Figure \(Z Gundam Version\) Instruction Manual](#)

BANDAI SPIRITS 181386

Bandai Hobby High Grade Universal Century 1/144 Nemo Action Figure (Z Gundam Version) Instruction Manual

Model: 181386 | Brand: BANDAI SPIRITS

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for assembling and maintaining your Bandai Hobby High Grade Universal Century 1/144 Nemo Action Figure. The Nemo is a mobile suit featured in the animated series "Zeta Gundam," utilized by the AEUG. This model kit allows you to recreate the iconic mobile suit with various accessories.

The kit includes:

- Beam Rifle
- Shield
- 2 Beam Sabers
- Left and Right Closed Fists
- Spread Hand
- Fists for Holding Weapons
- One Right Trigger Finger for the Rifle



Image 1.1: Product box art showing the Nemo mobile suit and its accessories.

2. SETUP AND ASSEMBLY

This High Grade model kit is designed for snap-together assembly, requiring no glue or paint. All parts are molded in colored plastic. Please follow the included instruction manual (physical copy) for detailed step-by-step assembly.

2.1 Components

Before starting, ensure all components are present:

- Runner x10 (plastic parts frames)
- Foil Sticker x1 (for detailing)
- Instruction Manual x1 (physical copy)

2.2 Assembly Steps

1. Carefully detach parts from the runners using a hobby nipper (recommended) or by twisting them gently. Avoid pulling forcefully to prevent damage.
2. Identify the corresponding parts as indicated in the physical instruction manual.
3. Snap the parts together firmly. Ensure proper alignment and connection.
4. Apply the foil stickers as directed in the manual for enhanced detail.
5. Assemble the main body, limbs, head, and then the accessories.



Image 2.1: Illustration of hands assembling a model kit, demonstrating the snap-fit process.



Image 2.2: Close-up view of plastic runners with various colored parts, ready for assembly.

3. OPERATING THE ACTION FIGURE

Once assembled, your Nemo action figure is ready for display and posing. The figure features articulation points allowing for dynamic poses.

3.1 Posing and Articulation

- Gently manipulate the joints (shoulders, elbows, hips, knees, ankles, neck) to achieve desired poses.
- Avoid forcing joints beyond their natural range of motion to prevent breakage.

3.2 Attaching Accessories

The Nemo comes with several interchangeable accessories:

- **Beam Rifle:** Can be held by the right trigger finger hand.
- **Shield:** Attaches to the left forearm.
- **Beam Sabers:** Can be held by the weapon-holding fists.

- **Interchangeable Hands:** Swap between closed fists, spread hand, and weapon-holding fists as needed.



Image 3.1: The fully assembled Nemo figure, equipped with its beam rifle and shield.



Image 3.2: The Nemo figure showcasing its articulation and ability to wield a beam saber.

4. MAINTENANCE

Proper care will ensure the longevity of your model kit.

- **Cleaning:** Dust the figure regularly with a soft brush or compressed air. For stubborn dirt, gently wipe with a slightly damp cloth and mild soap, then dry thoroughly. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent discoloration or material degradation.
- **Handling:** Handle the figure by its main body parts rather than delicate accessories or thin protrusions.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

Problem	Solution
Parts do not fit together easily.	Ensure parts are correctly oriented. Check for any excess plastic (nubs) from the runners and carefully trim them with a hobby knife. Do not force parts.
Joints are too loose.	Apply a thin layer of clear nail polish or a specialized hobby joint tightener to the ball joint or peg, let it dry, then reassemble. This adds friction.
Stickers are peeling.	Ensure the surface is clean and dry before application. Press firmly. For existing peeling, a small amount of hobby-grade adhesive can be used carefully.
Parts break during assembly.	Contact customer support for replacement parts if available. For minor breaks, plastic cement designed for model kits can be used.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	2 x 4 x 6 inches
Item Weight	0.57 ounces
ASIN	B00AAQ0OSM
Item Model Number	181386
Manufacturer Recommended Age	15 years and up
Manufacturer	Bluefin Distribution Toys
Assembly Type	Snap-together, no glue required
Coloring	Colored plastic, no paint required

7. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For any inquiries regarding product defects, missing parts, or general support, please contact the manufacturer directly.

Manufacturer: Bluefin Distribution Toys (under BANDAI SPIRITS)

Please refer to the official BANDAI SPIRITS website or contact their customer service for the most up-to-date support information.

