#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Acme /
- Acme Ireland Queen Storage Bed (Espresso, Model AC-21600Q) User Manual

#### Acme AC-21600Q

# Acme Ireland Queen Storage Bed (Espresso, Model AC-21600Q) User Manual

Comprehensive Instructions for Assembly, Use, and Care

## 1. Introduction

This manual provides essential information for the safe and correct assembly, operation, and maintenance of your Acme Ireland Queen Storage Bed in Espresso. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Acme Ireland Queen Storage Bed is designed to offer both comfort and practical storage solutions, featuring a multi-drawer platform bed with a headboard and integrated storage drawers.



Image 1.1: The Acme Ireland Queen Storage Bed in Espresso, showcasing its design and integrated storage.

# 2. SAFETY INFORMATION

- Always follow assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- Ensure all hardware is securely tightened. Periodically check and re-tighten fasteners as needed.
- Do not exceed the maximum weight limit of 500 pounds for the bed.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Use caution when moving the assembled bed to prevent damage or injury.
- This product is intended for adult use.

#### 3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

## **Expected Components:**

- Headboard with integrated storage
- Bed frame side rails (with integrated storage drawers)
- Footboard (with integrated storage drawers)
- Support slats/boards
- Hardware pack (screws, bolts, washers, Allen wrench)
- · Assembly instructions manual

Note: Some pieces may not be labeled. Refer to the diagrams in the assembly instructions for identification.

#### 4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults. Ensure you have adequate space and the necessary tools (screwdriver, possibly a drill for pilot holes if not pre-drilled).

## **Required Tools (Not Included):**

- · Phillips head screwdriver
- Rubber mallet (optional, for gentle tapping)
- Drill with appropriate bits (optional, if pilot holes are missing or unclear)

# **Assembly Steps:**

- 1. **Unpack and Organize:** Carefully unpack all components and hardware. Lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided parts list and diagrams.
- 2. **Assemble Headboard:** Attach any separate headboard components as per the specific instructions provided in your package. Ensure all connections are secure.
- 3. **Attach Side Rails to Headboard:** Connect the bed frame side rails to the headboard using the specified hardware. Do not fully tighten bolts until the entire frame is assembled.
- 4. **Attach Footboard:** Connect the footboard to the other end of the side rails. Once all four sides are connected, gently tighten all bolts, ensuring the frame is square.

- 5. **Install Support Slats:** Place the wooden support slats across the bed frame. Ensure they are evenly spaced and securely fastened to the side rails. Some slats may require screwing into the frame.
- 6. **Insert Storage Drawers:** Slide the pre-assembled storage drawers into their designated compartments within the headboard, footboard, and side rails. Ensure they glide smoothly.



Image 4.1: Overview of the bed's storage components, including headboard, footboard, and side rail drawers.



Image 4.2: Detail of the headboard's integrated storage, featuring shelves and two small drawers.



Image 4.3: Detail of the storage drawers located within the bed frame, designed for easy access.

# 5. OPERATION

The Acme Ireland Queen Storage Bed features multiple integrated drawers for convenient storage.

- Storage Drawers: The bed includes six drawers (three on each side) and additional drawers/shelves in the headboard. These are designed for storing linens, clothing, books, or other personal items.
- **Drawer Use:** To open a drawer, gently pull the handle. To close, push the drawer back until it is fully seated within the frame. Avoid forcing drawers if they stick; check for obstructions.

# 6. MAINTENANCE

# Cleaning:

- Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the espresso finish.
- For spills, blot immediately with a clean, dry cloth.

# **General Care:**

• Periodically check all bolts and screws and re-tighten them to ensure the bed remains stable.

- Avoid dragging the bed when moving it; lift it to prevent damage to the frame and flooring.
- Protect the surface from direct sunlight and extreme temperature changes to prevent fading or warping.

#### 7. TROUBLESHOOTING

# **Common Issues and Solutions:**

#### • Bed Squeaks:

- Check all connections and tighten any loose bolts or screws. Ensure slats are properly seated and secured. Applying furniture wax or silicone spray to contact points between wood components can sometimes reduce friction and noise.

#### • Drawers Stick or Don't Close Properly:

- Ensure drawers are not overloaded. Check drawer glides for obstructions or damage. Verify that the bed frame is assembled squarely and is not warped.

#### • Bed Feels Unstable:

- Re-check all assembly points, especially the main frame connections. Ensure all hardware is fully tightened. Verify that the bed is on a level surface.

#### • Missing or Damaged Parts:

- Do not attempt to modify or force parts. Contact Acme customer support immediately for replacement parts.

# 8. SPECIFICATIONS

Feature	Detail
Brand	Acme
Model Number	AC-21600Q
Size	Queen
Color	Espresso
Product Dimensions	91"L x 63"W x 56"H
Item Weight	276 Pounds
Weight Limit	500 Pounds
Special Feature	Storage (6 drawers + headboard storage)
Assembly Required	Yes



Image 8.1: Dimensional diagram of the Acme Ireland Queen Storage Bed.

# 9. WARRANTY AND SUPPORT

This Acme product comes with a Limited Warranty. Please refer to the warranty documentation included with your purchase for specific terms and conditions, including coverage details and duration. For technical assistance, missing parts, or warranty claims, please contact Acme customer support. Contact information can typically be found on the manufacturer's website or on the packaging materials. Online Resources: For additional support or frequently asked questions, visit the official Acme Furniture website.

© 2023 Acme Furniture. All rights reserved.

Related Documents - AC-21600Q



#### Руководство по эксплуатации промышленных источников питания АСМЕ серии 800

Подробное руководство по эксплуатации промышленных источников питания ACME серии 800. Информация по установке, настройке, управлению, протоколам связи и техническому обслуживанию.



#### Acme Thread Data Sheets and Specifications

Comprehensive data sheets for Acme screw threads, including dimensions, tolerances, and formulas for external and internal threads, with a focus on 29° Acme threads.



#### ACME BH203 Bluetooth Earphones User Manual and Specifications

Comprehensive user manual for ACME BH203 Bluetooth earphones, detailing features, technical specifications, setup, troubleshooting, and maintenance. Supports multiple languages.



# Acme ACME CH302 Wireless Charger 10W - Qi Fast Charging Pad

Discover the Acme CH302 Wireless Charger, a 10W Qi-compatible charging pad. Features include a slim, compact design, anti-slip rubber, and an LED indicator for easy status checks. Includes USB Type-C cable and user manual. Ideal for convenient, cable-free charging.



#### Acme Smart Home Hub: Centralized Control & Connectivity

Learn about the Acme Smart Home Hub, your central point for managing smart devices. Features include voice assistant integration, app connectivity, and easy setup. Includes troubleshooting tips and warranty information.



# Manuale di Riparazione Motori ACME ALN 215W/290W/330W AT 330-OHV

Manuale di riparazione completo per i motori a scoppio ACME delle serie ALN 215W, 290W, 330W e AT 330-OHV. Include specifiche tecniche, procedure di smontaggio, montaggio, revisione, diagnostica e manutenzione.