

[Manuals.plus](#) /

> [Aladdin](#) /

> Aladdin Tempreserve Insulated Casserole Carrier Server ICC100 User Manual

## Aladdin ICC100

# Aladdin Tempreserve Insulated Casserole Carrier Server ICC100 User Manual

## INTRODUCTION

This manual provides instructions for the safe and effective use of your Aladdin Tempreserve Insulated Casserole Carrier Server, model ICC100. This carrier is designed to transport and keep a standard 9x13 inch casserole dish warm or cold for extended periods.



Image: The Aladdin Tempreserve Insulated Casserole Carrier shown with a glass casserole dish containing a meal of noodles, meat, and colorful bell peppers, demonstrating its intended use.

Key features of your Aladdin Tempreserve carrier include:

- Insulated design for temperature retention.

- Accommodates one standard 9x13 inch casserole dish.
- Ideal for transporting hot or cold dishes to gatherings or events.

## SETUP

---

Before first use, ensure the carrier is clean. The Aladdin Tempreserve Casserole Carrier is ready for use directly out of its packaging.

1. **Prepare your dish:** Cook or chill your food in a standard 9x13 inch casserole dish. Ensure the dish is oven-safe if heating, or suitable for chilling if cooling.
2. **Open the carrier:** Unlatch or unclip the carrier lid. The carrier typically opens into two halves.
3. **Place the dish:** Carefully place your 9x13 inch casserole dish into the bottom half of the carrier. Ensure it sits securely.
4. **Close the carrier:** Place the top half of the carrier over the dish and secure the latches or clips to ensure a tight seal. This seal is crucial for maintaining the food's temperature.



Image: The Aladdin Tempreserve Insulated Casserole Carrier shown open and empty, revealing the interior space designed to hold a 9x13 inch dish.

## OPERATING INSTRUCTIONS

---

The Aladdin Tempreserve carrier is designed for temperature retention, not for cooking or reheating. For best results, ensure your food is at the desired temperature before placing it in the carrier.

1. **For Hot Food:**
  - Pre-heat your casserole dish with hot water for a few minutes, then empty and dry it before adding hot food. This helps maintain temperature longer.
  - Place the hot casserole dish into the carrier immediately after cooking.
  - Securely close the carrier lid to minimize heat loss.

## 2. For Cold Food:

- Pre-chill your casserole dish in the refrigerator or freezer for a short period before adding cold food.
- Place the cold casserole dish into the carrier.
- Securely close the carrier lid to minimize cold air loss.

3. **Transport:** Use the integrated handles for easy and secure transport.



Image: The Aladdin Tempreserve Insulated Casserole Carrier shown closed, ready for transport, highlighting its compact and secure design.

## MAINTENANCE AND CARE

---

Proper care will extend the life of your Aladdin Tempreserve Casserole Carrier.

- **Cleaning:** The carrier is made of plastic and is **not dishwasher safe**. Hand wash with warm, soapy water. Rinse thoroughly and allow to air dry completely before storing.
- **Storage:** Store the carrier in a clean, dry place when not in use.
- **Heat Exposure:** Do not place the plastic carrier in an oven, microwave, or on a stovetop. The "Oven Safe" instruction refers to the casserole dish you place inside, not the carrier itself.
- **Avoid Abrasives:** Do not use abrasive cleaners or scouring pads, as these can scratch the plastic surface.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Food not staying hot/cold	Lid not securely closed; carrier not pre-warmed/cooled; food not at desired temperature when placed in carrier.	Ensure lid is latched tightly. Pre-warm or pre-chill the carrier and dish for optimal temperature retention. Ensure food is at the correct temperature before placing it in the carrier.
Casserole dish does not fit	Dish is not a standard 9x13 inch size.	Verify the dimensions of your casserole dish. This carrier is designed specifically for standard 9x13 inch dishes.

## SPECIFICATIONS

<b>Feature</b>	<b>Detail</b>
Model Number	ICC100
Brand	Aladdin
Material	Plastic
Color	White
Shape	Rectangular
Accommodates Dish Size	Standard 9x13 inch casserole dish
Item Weight	3.1 Pounds
Dishwasher Safe	No (Hand wash only)

## WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not provided in the available product data. For warranty details or assistance, please refer to the manufacturer's official website or contact Aladdin customer service directly.