

Manuals.plus /

- › Dryfast /
- › Dryfast HK-JA01-WP Hand Dryer User Manual

## Dryfast HK-JA01-WP

# Dryfast HK-JA01-WP Hand Dryer User Manual

Model: HK-JA01-WP | Brand: Dryfast

## 1. PRODUCT OVERVIEW

The Dryfast HK-JA01-WP is a robust and efficient hand dryer designed for commercial and public restrooms. Featuring a durable steel construction with an enamel coating, this unit provides fast and hygienic hand drying. It operates on 110/120 Volt power and comes equipped with a wall plug for convenient installation.



Figure 1: Front view of the Dryfast HK-JA01-WP Hand Dryer, showcasing its compact design and white enamel finish.

## 2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and operation. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply matches the specifications of the unit (110/120 Volt).
- Do not install in areas where water spray is direct or excessive.
- Installation should be performed by a qualified electrician in accordance with all local and national electrical codes.
- Do not block the air inlet or outlet during operation.
- Disconnect power before performing any maintenance or cleaning.
- Keep hands and foreign objects away from the air outlet during operation.

### 3. SETUP AND INSTALLATION

---

The HK-JA01-WP hand dryer is designed for wall-mounted installation. Follow these steps for proper setup:

1. **Choose Location:** Select a suitable wall location, ensuring adequate space around the unit for air circulation and user access. Avoid placing directly above sinks or in areas prone to excessive moisture.
2. **Mark Mounting Holes:** Use the provided mounting template (if applicable) or measure the distance between the mounting holes on the back of the unit. Mark these points on the wall.
3. **Drill Holes:** Drill pilot holes at the marked locations. Insert wall anchors if necessary for secure mounting.
4. **Mount Unit:** Secure the hand dryer to the wall using appropriate screws. Ensure the unit is level and firmly attached.
5. **Connect Power:** Plug the hand dryer's wall plug into a grounded 110/120 Volt electrical outlet. Ensure the outlet is easily accessible for disconnection if needed.
6. **Test Operation:** Once securely mounted and powered, test the unit by placing hands under the sensor.

### 4. OPERATING INSTRUCTIONS

---

The Dryfast HK-JA01-WP hand dryer features automatic, sensor-activated operation.

- **Activation:** Place your hands directly under the air outlet. The infrared sensor will detect your hands and automatically activate the air flow.
- **Drying:** Keep your hands under the air flow, moving them gently to ensure even drying. The powerful airflow will dry hands quickly and efficiently.
- **Deactivation:** Remove your hands from the sensor's detection area. The hand dryer will automatically shut off after a few seconds.

*Note: No official product videos from the seller were available for embedding in this manual.*

### 5. MAINTENANCE

---

Regular maintenance ensures optimal performance and longevity of your hand dryer.

- **Cleaning Exterior:** Wipe the exterior surface with a soft, damp cloth and mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive materials that could damage the enamel coating.
- **Cleaning Air Inlet/Outlet:** Periodically inspect and clean the air inlet and outlet grilles to remove any dust or lint buildup. Use a soft brush or vacuum cleaner.
- **Filter Maintenance (if applicable):** If your model includes an air filter, refer to the specific instructions for cleaning or replacing it. (This model does not specify a filter, so this is a general note).
- **Power Disconnection:** Always disconnect the power supply before performing any cleaning or maintenance.

### 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Hand dryer does not activate.	No power; Sensor obstructed or dirty; Sensor malfunction.	Check power connection and outlet; Clean sensor lens; Contact customer support.
Weak airflow.	Blocked air inlet/outlet; Motor issue.	Clean air grilles; Contact customer support.
Unit runs continuously.	Sensor malfunction; Obstruction in sensor path.	Remove any obstructions; Clean sensor lens; Contact customer support.

## 7. SPECIFICATIONS

---

**Model:** HK-JA01-WP

**Brand:** Dryfast

**Power:** 110/120 Volt

**Material:** Steel with Enamel Coating

**ASIN:** B00AEBMFGM

**First Available:** November 27, 2012

## 8. WARRANTY AND SUPPORT

---

For warranty information, technical support, or service inquiries, please contact Dryfast customer service directly. Refer to your purchase documentation for specific warranty terms and contact details.

You may also visit the official Dryfast website for additional resources and support.

