

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Fossil](#) /

› [Fossil Men's Dean Quartz Stainless Steel Chronograph Watch User Manual](#)

Fossil FS4795

Fossil Men's Dean Quartz Stainless Steel Chronograph Watch User Manual

Model: FS4795

PRODUCT OVERVIEW

The Fossil Men's Dean Quartz Stainless Steel Chronograph Watch (Model: FS4795) is a versatile timepiece designed with clean lines and a classic shape, drawing inspiration from Mid-Century modernism. It features a shiny steel case with gold-tone accents, making it suitable for various occasions.

- **Case & Movement:** 45mm case, 22mm band width, hardened mineral crystal lens resists scratches. Features accurate Quartz movement with chronograph analog display and date window. Includes three subdials to track minutes, seconds, and 24-hour time, along with stopwatch functionality.
- **Dial:** Round silver and gold two-tone stainless steel case, with a silver dial and gold accents.
- **Watch Band:** Silver and gold two-tone, durable stainless steel bracelet band with a secure fold-over clasp closure. Links can be removed for a customized fit and it is interchangeable with all 22mm Fossil straps.
- **Water Resistance:** Water resistant up to 50m (165ft), suitable for short periods of recreational swimming and showering, but not for diving or snorkeling (5 ATM).

SETUP AND INITIAL USE

Unboxing and Inspection

Upon receiving your Fossil Dean watch, carefully open the packaging. The watch comes secured in a Fossil branded tin box, designed to protect it during transit.



Image: The Fossil watch tin packaging, containing the watch and its accessories.

Setting Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to the first or second click position. The first click is typically for setting the date, and the second click for setting the time.
2. **Set the time:** Rotate the crown to adjust the hour and minute hands to the correct time. Ensure to account for AM/PM if your watch has a 24-hour subdial or date function.
3. **Set the date:** If applicable, pull the crown to the first click position and rotate it to set the correct date.
4. **Push in the crown:** Once time and date are set, push the crown back into its original position to start the watch movement.

Adjusting the Watch Band

The stainless steel bracelet band can be adjusted for a customized fit by removing links. It is recommended to have this done by a professional jeweler to avoid damaging the band or watch.



Image: The Fossil Dean watch worn on a wrist, showcasing its fit and appearance.

Understanding Case Size

The Fossil Dean watch features a 45mm case. Understanding watch case sizes can help ensure a comfortable and aesthetically pleasing fit on your wrist.




Image: A visual guide illustrating various watch case sizes, from 36mm to 50mm, to help determine the ideal fit.

OPERATING THE CHRONOGRAPH

The chronograph function allows you to measure elapsed time independently of the main time display. Your Fossil Dean watch features three subdials for this purpose.





Image: A clear front view of the Fossil Dean Chronograph Watch, highlighting the main dial and three subdials.

1. **Starting the Chronograph:** Press the top pusher (button) on the side of the watch to start the chronograph. The chronograph second hand will begin to move.
2. **Stopping the Chronograph:** Press the top pusher again to stop the chronograph. The elapsed time will be indicated by the subdial hands.
3. **Resetting the Chronograph:** Press the bottom pusher to reset all chronograph hands to their zero positions.
4. **Subdials:**
 - One subdial tracks elapsed seconds.
 - Another subdial tracks elapsed minutes.
 - The third subdial indicates 24-hour time, often linked to the main time display.

Official Product Video: Chronograph Functionality



Video: An official product video demonstrating the chronograph functionality of the Fossil Men's Dean Watch, including starting, stopping, and resetting the timer.

MAINTENANCE AND CARE

Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and band with a soft, damp cloth. For the stainless steel band, a mild soap solution can be used, followed by thorough rinsing and drying. Avoid harsh chemicals or abrasive materials.

Water Resistance Guidelines

Your watch is water resistant up to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming and showering. However, it is not designed for diving, snorkeling, or high-pressure water activities. Always ensure the crown is fully pushed in before any contact with water.

Battery Replacement

The watch uses 1 CR2 battery. When the battery needs replacement, it is highly recommended to take your watch to an authorized Fossil service center or a reputable jeweler. This ensures proper battery installation and re-sealing to maintain water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not keeping time or stopped	Dead battery	Replace battery (professional service recommended).
Chronograph hands not resetting to zero	Misalignment	Consult the detailed user manual for specific chronograph hand calibration instructions, or seek professional assistance.
Moisture under crystal	Water ingress	Immediately take the watch to a professional for inspection and repair to prevent further damage.
Date not changing at midnight	Time set incorrectly (AM/PM)	Advance the time by 12 hours.

SPECIFICATIONS

- **Brand:** Fossil
- **Model Number:** FS4795
- **Product Dimensions:** 2.83 x 3.54 x 3.54 inches; 0.02 ounces
- **Department:** Men
- **Batteries:** 1 CR2 batteries required (included)
- **Date First Available:** February 2, 2013
- **Manufacturer:** Fossil
- **Country of Origin:** Japan
- **Material:** Stainless-steel



Image: A detailed close-up of the Fossil Dean watch face, showing the intricate dial and subdial markings.

WARRANTY AND SUPPORT

Fossil offers various protection plans for your watch. For detailed information regarding warranty coverage and terms, please refer to the official documentation provided with your purchase or visit the Fossil website.

Additional Resources

- **User Guide (PDF):** [Download User Guide](#)
- **User Manual (PDF):** [Download User Manual](#)
- **Visit the Fossil Store:** [Fossil Official Store](#)