

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HAND](#) /
- › [HAND Precision Automatic Numbering Machine ZS209 User Manual](#)

HAND ZS209

HAND Precision Automatic Numbering Machine ZS209 User Manual

Model: ZS209

1. INTRODUCTION

The HAND Precision Automatic Numbering Machine ZS209 is a heavy-duty, self-inking device designed for efficient sequential numbering operations. Crafted with a one-piece hardened steel frame and finished in high-polish chrome, this machine features all-metal interior construction for reliable, long-term use. It is ideal for document identification, date and number stamping, serial number stamping, inspection stamping, and ticket stamping.

This machine includes 9 die-cast metal wheels with 5mm digit size and offers 8 movement settings for versatile numbering patterns. Each unit comes with two dry inking pads and a bottle of black ink.

2. PRODUCT OVERVIEW

Familiarize yourself with the components of your numbering machine.



Image 2.1: Front view of the HAND Precision Automatic Numbering Machine ZS209, showing the handle, chrome body, and numbering wheels.

The machine features a sturdy handle for operation, a robust metal housing, and visible numbering wheels for setting the desired sequence. The ink pad is located internally, accessible for replacement.

3. SETUP

Before first use, ensure the ink pad is properly installed and inked.

1. **Unpack the Machine:** Carefully remove the numbering machine and accessories (ink, stylus, extra pads) from the packaging.
2. **Install/Ink the Pad:** The machine typically comes with a dry ink pad. To ink it, apply a small amount of the provided black ink evenly onto the dry pad. Do not over-saturate. Allow a few minutes for the ink to absorb.
3. **Insert the Pad:** Open the machine's base or side compartment (refer to specific model design if different) and insert the inked pad. Ensure it sits securely.
4. **Test Impression:** Make a few test impressions on scrap paper to ensure even ink distribution and clear numbering.

4. OPERATING INSTRUCTIONS

This numbering machine offers various settings for different numbering requirements.

4.1 Setting the Number

Use the included stylus to adjust the numbering wheels. Each wheel can be rotated to display the desired digit. Ensure all wheels are aligned correctly for a clear impression.



Image 4.1: Detailed view of the numbering machine, highlighting the wheels and adjustment area.

4.2 Movement Settings

The machine features 8 movement settings, controlled by a small lever or dial (location may vary slightly by unit, typically on the side or base). These settings determine how the number advances after each impression.

- **Consecutive:** Advances the number by one digit with each impression (e.g., 001, 002, 003...).
- **Repeat:** Stamps the same number repeatedly without advancing.
- **2 x Repeat:** Stamps the same number twice, then advances (e.g., 001, 001, 002, 002...).
- **3 x Repeat:** Stamps the same number three times, then advances.
- **4 x Repeat:** Stamps the same number four times, then advances.
- **5 x Repeat:** Stamps the same number five times, then advances.
- **6 x Repeat:** Stamps the same number six times, then advances.
- **12 x Repeat:** Stamps the same number twelve times, then advances.

To change the setting, locate the movement lever/dial and slide or rotate it to the desired position. Test the setting on scrap paper before use on important documents.

4.3 Making an Impression

1. Place the document on a flat, stable surface.
2. Position the numbering machine over the desired stamping area.
3. Press down firmly and evenly on the handle until the impression is made.
4. Lift the machine straight up to avoid smudging.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your numbering machine.

- **Ink Pad Replacement:** When impressions become faint, replace the ink pad with a new one or re-ink the existing dry pad. Ensure you use ink specifically designed for numbering machines to prevent damage to the rubber components.
- **Cleaning:** Periodically clean the numbering wheels with a soft, lint-free cloth to remove any accumulated ink or dust. A small brush can be used for hard-to-reach areas. Avoid using harsh chemicals or solvents.
- **Storage:** Store the machine in a clean, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Faint Impressions:**
 - Check if the ink pad is dry. Re-ink or replace the pad.
 - Ensure you are pressing down firmly and evenly.
- **Smudged Impressions:**
 - Lift the machine straight up after making an impression.
 - Avoid over-inking the pad.
- **Number Not Advancing:**
 - Check the movement setting. Ensure it is set to 'Consecutive' or a 'Repeat' setting that allows advancement.
 - Clean the internal mechanism if debris is obstructing movement.
- **Digits Not Clear/Misaligned:**
 - Ensure the numbering wheels are properly aligned using the stylus.
 - Clean any ink buildup on the numbering wheels.

7. SPECIFICATIONS

Feature	Detail
Model	ZS209
Number of Wheels	9 (die-cast metal)
Digit Size	5mm
Movement Settings	Consecutive, Repeat, 2x Repeat, 3x Repeat, 4x Repeat, 5x Repeat, 6x Repeat, 12x Repeat
Material	Hardened Steel Frame, All-metal interior
Item Weight	1.05 pounds (approx. 0.48 kg)
Product Dimensions	2.76 x 1.46 x 5.51 inches (7 x 3.7 x 14 cm)

Included Accessories	2 Dry Ink Pads, Black Ink Bottle, Stylus
-------------------------	--

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

© 2023 HAND. All rights reserved.