

AGPTEK AGPTEK Timer Tea Lights

AGPTEK 24-Pack Flameless LED Tea Lights with Timer Function User Manual

1. INTRODUCTION

The AGPTEK Flameless LED Tea Lights provide a safe and convenient alternative to traditional candles. These battery-operated tea lights feature a flickering warm white light effect and an integrated timer function, making them suitable for various decorative purposes without the concerns of open flames or melting wax. This manual provides instructions for the proper setup, operation, and maintenance of your LED tea lights.



AGPTEK Flameless LED Tea Lights displayed in a glass holder with decorative elements, showcasing their warm glow.

2. SAFETY INFORMATION

- Keep batteries out of reach of children and pets.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries according to local regulations.
- Do not expose the tea lights to extreme temperatures or direct sunlight for prolonged periods.
- These tea lights are not waterproof. Avoid contact with water or moisture.



LED CANDLE



TRADITION CANDLE



Comparison of LED candles versus traditional candles, illustrating the benefits of LED candles: energy-saving, flameless, no dripping wax, and no risk of fire.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 24 x LED Tealight Candles
- 24 x CR2032 Coin Batteries (pre-installed inside the candles)

4. SETUP

Battery Installation

The AGPTEK LED tea lights come with CR2032 button cell batteries pre-installed. If you need to replace the battery:

1. Locate the battery compartment cover on the bottom of the tea light.
2. Use a small coin or screwdriver to gently open the cover.
3. Remove the old CR2032 battery.
4. Insert a new CR2032 battery with the positive (+) side facing upwards.
5. Securely close the battery compartment cover.



Detailed view of the AGPTEK LED tea light, illustrating its dimensions (36mm/1.4inch diameter and height) and the battery compartment with a CR2032 button cell for easy replacement.

5. OPERATING INSTRUCTIONS

Power On/Off

Each tea light has a small slide switch located on its bottom. To turn the tea light ON, slide the switch to the 'ON' position. To turn it OFF, slide the switch to the 'OFF' position.

Timer Function

The AGPTEK LED tea lights feature an automatic timer function. Once you turn the switch to the 'ON' position, the tea light will illuminate for 6 hours, then automatically turn off for 18 hours. This 24-hour cycle will repeat daily. To reset the timer, simply turn the tea light OFF and then ON again at your desired start time.




Diagram illustrating the ON/OFF switch on the bottom of the tea light and the 6-hour on, 18-hour off timer cycle for automatic operation.

6. MAINTENANCE

Cleaning

To clean the tea lights, gently wipe them with a soft, dry cloth. Do not use abrasive cleaners or immerse them in water.

Battery Replacement

When the light appears dim or stops working, it is time to replace the CR2032 battery. Refer to the 'Battery Installation' section under 'Setup' for detailed instructions.

7. TROUBLESHOOTING

- **Tea light does not turn on:** Ensure the switch is in the 'ON' position. Check if the battery is correctly installed with the positive (+) side up. Replace the battery if it is depleted.

- **Light is dim:** This indicates a low battery. Replace the CR2032 battery.
- **Timer function not working as expected:** Ensure the tea light was turned ON at the desired start time. The timer cycle begins from the moment the switch is set to 'ON'. To reset, turn OFF and then ON again.

8. SPECIFICATIONS

Brand	AGPTEK
Model Name	AGPTEK Timer Tea Lights
Material	PP+LED
Light Source Type	LED
Light Color	Warm White
Light Effect	Flickering Flashing
Product Dimensions	1.4"D x 1.4"W x 1.4"H (3.6cm Diameter x 3.6cm Height)
Item Weight	1.6 ounces (per tea light)
Battery Type	CR2032 Button Cell
Battery Life	72-100 hours
Timer Function	6 hours ON, 18 hours OFF (24-hour cycle)
Number of Items	24

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact AGPTEK customer service through the retailer where the product was purchased. Please retain your proof of purchase for any warranty claims.