

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Evenflo](#) /

› [Evenflo Exersaucer Johnny Jumper Instruction Manual](#)

Evenflo 60441449

Evenflo Exersaucer Johnny Jumper Instruction Manual

Model: 60441449

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and warnings before assembling and using the Evenflo Exersaucer Johnny Jumper. Failure to follow these instructions could result in serious injury or death.

General Warnings:

- **Age and Weight Limits:** This product is intended for children who can hold their head up unassisted and who are not yet able to walk. Do not use for children weighing more than 24 lbs (11 kg).
- **Supervision:** Never leave a child unattended in the jumper. Always keep the child in view while they are using the product.
- **Doorway Requirements:** Use only in doorways with a securely affixed door trim at least 0.5 inches (1.27 cm) wide. The doorway frame must be between 3 to 6 inches (7.6 to 15.2 cm) thick. Ensure the doorway is structurally sound and capable of supporting the child's weight and activity.
- **Clearance:** Ensure there is adequate space around the child to prevent contact with the door frame or other objects during jumping.
- **Inspection:** Before each use, inspect the jumper for loose parts, damaged components, or signs of wear. Discontinue use immediately if any damage is found.
- **Spring Safety:** The fully enclosed spring is designed to prevent finger entrapment and dirt accumulation. Do not attempt to open or modify the spring mechanism.

2. SETUP AND INSTALLATION

The Evenflo Exersaucer Johnny Jumper is designed for quick and tool-free setup.

Installation Steps:

1. **Select a Doorway:** Choose a doorway that meets the safety requirements outlined in Section 1. Ensure the door frame is sturdy and has a securely affixed trim.
2. **Attach the Clamp:** Hold the jumper's clamp firmly. Squeeze the clamp handles together to open the jaws. Position the clamp over the top of the door frame, ensuring it securely grips both sides of the trim. Release the handles to lock the clamp in place. Verify the clamp is firmly attached and does not move.



Image: Hands attaching the jumper's clamp to a doorframe. Ensure a secure fit on the door trim.

3. **Adjust Height:** The jumper features adjustable straps to customize the height for your child. With the child in the seat, adjust the straps so that the child's toes can just touch the floor when standing upright. This allows for proper bouncing motion without putting excessive pressure on their legs.



Image: Hands adjusting the strap to set the appropriate height for the child.

4. **Final Check:** Before placing your child in the jumper, double-check all connections and adjustments to ensure they are secure.

3. OPERATING INSTRUCTIONS

The Evenflo Exersaucer Johnny Jumper provides an engaging activity for your child.

Using the Jumper:

1. **Placing Child in Jumper:** Carefully place your child into the fabric seat, ensuring their legs are positioned correctly through the leg openings and the framed seat fully surrounds them.
2. **Supervise Play:** Always remain within arm's reach of your child while they are in the jumper. Encourage gentle bouncing and interaction.



Image: A baby enjoying the Evenflo Exersaucer Johnny Jumper.

3. **Duration of Use:** Limit jumping sessions to short periods (e.g., 15-20 minutes) to prevent over-stimulation or fatigue.
4. **Removing Child:** Carefully lift your child out of the jumper when playtime is over.

Portability:

The jumper's quick setup and compact design make it suitable for travel. It can be easily detached from one doorway and re-attached to another, or packed for day trips and vacations.



Image: The jumper can be easily transported, fitting into a bag for travel.

4. CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and hygiene of your Evenflo Exersaucer Johnny Jumper.

Cleaning Instructions:

- **Fabric Seat:** The fabric seat is machine-washable. Remove the seat from the frame and wash it in cold water on a delicate cycle. Air dry or tumble dry on low heat. Do not bleach.
- **Frame and Straps:** Wipe down the plastic frame and straps with a damp cloth and mild soap. Rinse thoroughly and air dry.



Image: The fabric seat is machine-washable, and other components can be wiped clean.

- **Spring:** The enclosed spring requires no special maintenance. Do not lubricate or attempt to disassemble.

5. TROUBLESHOOTING

If you encounter issues with your Evenflo Exersaucer Johnny Jumper, refer to the following common solutions:

- **Jumper is noisy during use:** Ensure the clamp is securely fastened to the door frame. Check for any loose connections. A slight squeak from the spring mechanism is normal; however, if excessive, ensure the spring is clean and free of debris.
- **Child appears uncomfortable or has red marks:** Ensure the jumper is adjusted to the correct height, allowing the child's toes to just touch the floor. Verify the child is properly seated with legs through the designated openings. Discontinue use if discomfort persists and consult a pediatrician.
- **Jumper does not feel secure:** Re-evaluate the chosen doorway to ensure it meets all safety requirements (door frame thickness, trim width, structural integrity). Re-attach the clamp, ensuring it is fully engaged and stable.
- **Lack of bounce:** Confirm the jumper is installed correctly and the child's feet are properly positioned to initiate bouncing. Ensure the spring mechanism is not obstructed.

6. PRODUCT SPECIFICATIONS

Brand	Evenflo
Model Number	60441449
Color	Bumbly
Frame Material	Plastic
Material Type	Phthalate Free
Product Dimensions	15.7 x 7 x 4.1 inches (40 x 17.8 x 10.4 cm)
Item Weight	2.4 pounds (1.09 kg)
Assembly Required	No
Batteries Required	No



Image: Dimensions of the Evenflo Exersaucer Johnny Jumper seat.

7. WARRANTY AND CUSTOMER SUPPORT

Warranty Information:

For specific warranty details, please refer to the warranty card included with your product or visit the official Evenflo website. Keep your proof of purchase for warranty claims.


Customer Support:

If you have questions, require assistance, or need to report a problem, please contact Evenflo Customer Service. You can find contact information on the Evenflo website or through the retailer where the product was purchased. Visit the official [Evenflo Store](#) for more products and information.

© 2025 Evenflo. All rights reserved.

Related Documents - 60441449

	<p>Evenflo Exersaucer Jump & Learn Activity Centre - Safari Friends</p> <p>Discover the Evenflo Exersaucer Jump & Learn Activity Centre, designed for safe and stimulating play. Features 45 learning activities, adjustable height, and washable seat for convenience. Ideal for babies aged 4-12 months.</p>
	<p>Evenflo ExerSaucer Jam Session Stationary Jumper - Assembly and User Manual</p> <p>Comprehensive guide for the Evenflo ExerSaucer Jam Session stationary jumper, covering assembly instructions, safety warnings, height adjustment, care and maintenance, troubleshooting, and warranty information.</p>
	<p>Baby Trend Sit N Stand LX Tandem Stroller with Car Seat Snap N Go Attachment System - Instruction Manual</p> <p>This comprehensive instruction manual details the assembly, operation, and safety guidelines for the Baby Trend Sit N Stand LX Tandem Stroller (Model #7311). It covers essential warnings, identification of stroller parts, step-by-step assembly instructions, methods for securing children in both the front and rear seats, seatback positioning, brake operation, canopy adjustments, and folding/unfolding procedures. Additionally, it provides crucial information and compatibility charts for using the Snap N Go attachment system with various infant car seats, including detailed installation and removal instructions for models from Cosco, Peg Perego, Evenflo, Century, Graco, and Baby Trend.</p>
	<p>Evenflo SHYFT Modular Stroller/Travel System: User Manual</p> <p>Comprehensive user manual for the Evenflo SHYFT Modular Stroller/Travel System, covering assembly, usage, care, and warranty information. Features include infant mode, toddler mode, and compatibility with Evenflo car seats.</p>



[Evenflo Pivot Xpand Stroller Travel System User Manual](#)

Comprehensive user manual for the Evenflo Pivot Xpand Stroller/Travel System, covering assembly, dual modes (Toddler Seat and Carriage), safety guidelines, infant car seat compatibility, and maintenance. Learn to configure for single or double use.



[Evenflo Journey Stroller/Travel System User Manual](#)

Comprehensive user manual for the Evenflo Journey Stroller/Travel System, covering assembly, usage, safety guidelines, and maintenance. Learn how to safely operate and care for your stroller.