



Manuals.plus /

- › Tide /
- › User Manual for Tide Liquid Laundry Detergent, 25 Oz, Unscented

## Tide B00AM21SBG

# User Manual: Tide Liquid Laundry Detergent

Model: B00AM21SBG | Unscented, 25 Fl Oz

---

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of Tide Liquid Laundry Detergent, 25 Fl Oz, Unscented. This product is designed for cleaning clothes in various washing machines.



Figure 1: Front view of the Tide Liquid Laundry Detergent bottle, 25 Fl Oz, Unscented.

## 2. SAFETY INFORMATION

Read all safety warnings and instructions before using this product. Keep out of reach of children.

### General Warnings:

- CAUTION: EYE IRRITANT. HARMFUL IF SWALLOWED.
- DO NOT GET IN EYES.
- DO NOT REUSE THIS PACKAGE FOR DISPENSING BEVERAGES OR OTHER LIQUIDS.
- KEEP OUT OF REACH OF CHILDREN.

### First Aid Treatment:

- Contains biodegradable surfactants (anionic and nonionic) and enzymes.
- **If swallowed:** Give a glassful of water or milk and call a Poison Control Center or doctor immediately. Do not induce vomiting.
- **If in eyes:** Rinse well with water for 15 minutes.

**10X** Cleaning power\*

\*Stain Removal of 1 dose vs. 10X doses of the leading liquid bargain brand

Figure 2: Back view of the Tide Liquid Laundry Detergent bottle, showing detailed safety warnings and usage instructions.

## 3. SETUP

No specific setup is required for this product. Ensure the bottle is stored upright in a cool, dry place, away from direct sunlight and extreme temperatures.

## 4. OPERATING INSTRUCTIONS

Use the cap to measure the appropriate amount of detergent. The cap has measurement lines (bars) to guide dosage.

### Dosage Guidelines:

- For **medium loads**, fill to bar 1 on the cap.
- For **large loads**, fill to bar 3 on the cap.
- For **HE full loads**, fill to bar 5 on the cap.

Add the measured detergent to your washing machine's dispenser or directly into the drum before adding clothes. Follow your washing machine's instructions for optimal results.

This 25 Fl Oz bottle contains approximately 16 loads when measured to bar 1 on the cap.

## 5. MAINTENANCE

To maintain product quality, keep the cap tightly closed when not in use. Store the bottle in an upright position to prevent leaks. Avoid exposing the product to freezing temperatures or excessive heat.

## 6. TROUBLESHOOTING

### Common Concerns:

- **Accidental Spills:** Wipe up spills immediately with a damp cloth. Rinse the area thoroughly with water.
- **Skin Contact:** If detergent comes into contact with skin, rinse thoroughly with water. If irritation persists, seek medical attention.
- **Product Separation:** If the product appears separated, shake the bottle gently before use. This is rare but can occur with liquid detergents.

## 7. SPECIFICATIONS

Feature	Detail
Brand	Tide
Model Number (ASIN)	B00AM21SBG
Item Form	Liquid
Scent	Unscented
Unit Count	1.00 Count
Material Type Free	Fragrance, Odorless
Product Dimensions	15.7 x 7.7 x 8.7 inches
Item Weight	1.56 Pounds
Date First Available	March 20, 2013

## 8. WARRANTY

Specific warranty information for this product is typically provided by the manufacturer at the time of purchase or on their official website. Please refer to the manufacturer's official resources for details regarding product guarantees and return policies.

## 9. SUPPORT

For further assistance, questions, or concerns regarding your Tide Liquid Laundry Detergent, please contact the manufacturer directly.

Manufacturer: Tide

You can visit the official Tide Store for more information:[Tide Official Store](#)