

Black & Decker PAV1205

BLACK&DECKER Car Cleaner Pivot Auto PAV1205 Instruction Manual

Model: PAV1205 | Brand: Black & Decker

1. INTRODUCTION

The BLACK&DECKER Car Cleaner Pivot Auto PAV1205 is a powerful and compact car vacuum cleaner designed for efficient cleaning of vehicle interiors. Its unique pivot nozzle and cyclone technology ensure thorough cleaning in hard-to-reach areas, providing a clean and comfortable environment for your car.



Image: Packaging of the BLACK&DECKER Car Cleaner Pivot Auto PAV1205, highlighting its key features and included accessories.

2. SAFETY INFORMATION

- Always ensure the vehicle engine is off before connecting or disconnecting the cleaner from the cigarette lighter socket.
- Do not use the cleaner to pick up flammable or combustible liquids, such as gasoline, or in areas where they may be present.
- Avoid picking up hot ashes, burning cigarettes, or any hot, burning, or smoking objects.
- Do not immerse the cleaner in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not operate the cleaner with a damaged cord or plug. If damaged, contact customer service for repair.
- This appliance is for car use only and operates on a 12V DC power supply.

3. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- BLACK&DECKER Car Cleaner Pivot Auto PAV1205 Main Unit
- Snake Hose
- Large Carpet Brush
- Brush Nozzle
- Storage Bag
- Plastic Filter
- HD Filter (High-Density Dust Collection Filter)
- Adapter



Image: The BLACK&DECKER Car Cleaner Pivot Auto PAV1205 and its various attachments, including the hose, brushes, and crevice tool.

4. SETUP

1. **Connect Power:** Insert the cleaner's 12V cigarette lighter plug into your vehicle's cigarette lighter socket. Ensure a secure connection. The cord length is 5.0 meters, allowing access to all areas of most vehicles.
2. **Attach Nozzle/Accessory:** Select the appropriate nozzle or accessory for your cleaning task.
 - For tight spaces and crevices, use the adapter with the brush nozzle or the snake hose.
 - For larger carpeted areas, attach the large carpet brush.
 - The Pivot Nozzle can be adjusted to various angles (up to 200 degrees) to reach awkward spots.

5. OPERATING INSTRUCTIONS

1. **Power On:** Once connected to the 12V socket, press the power switch to turn on the cleaner.
2. **Cleaning:** Move the cleaner over the surfaces you wish to clean. The cyclone dust collection method provides powerful and continuous suction.
3. **Using the Pivot Nozzle:** Adjust the angle of the pivot nozzle to effectively clean different contours and angles within your car.
4. **Using Accessories:** Utilize the snake hose for deep crevices, the large carpet brush for floor mats, and the brush nozzle for upholstery and delicate surfaces.

5. **Continuous Operation:** The cleaner is designed for approximately 30 minutes of continuous operation.
6. **Power Off:** After cleaning, press the power switch to turn off the cleaner and then disconnect it from the cigarette lighter socket.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your cleaner.

1. **Emptying the Dust Box:** The transparent dust box allows you to easily see when it needs emptying. To empty, detach the dust box from the main unit and dispose of the collected debris.
2. **Cleaning Filters:** The cleaner includes a Plastic Filter and an HD Filter. These filters can be washed with water.
 - Remove the filters from the dust box.
 - Rinse them under running water until clean.
 - Allow the filters to air dry completely before reinserting them into the dust box and reattaching to the cleaner. Ensure they are completely dry to prevent damage and maintain suction power.
3. **Storing the Cleaner:** The nozzle can be folded for compact storage. Use the provided storage bag to keep the cleaner and its accessories organized.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cleaner does not turn on.	Not properly connected to 12V socket; vehicle engine off.	Ensure the plug is fully inserted into the cigarette lighter socket. Start the vehicle engine if necessary.
Low suction power.	Dust box full; filters clogged; nozzle/hose blocked.	Empty the dust box. Clean the filters thoroughly. Check nozzles and hose for blockages and clear them.
Unusual noise during operation.	Foreign object in the nozzle or hose; motor issue.	Turn off and disconnect the cleaner. Inspect nozzles and hose for foreign objects and remove them. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	PAV1205
Rated Voltage	12V
Power Source	Car Battery (Cigarette Socket)
Dust Collection Method	Cyclone Method
Dust Collection Capacity	350ml (0.35 L)

Feature	Detail
Continuous Operation Time	Approx. 30 minutes
Cord Length	5.0m
Package Size (LWH)	37.8 x 19.4 x 17.9 cm
Package Weight	1.94 kg
Filter Type	Cartridge (Plastic Filter, HD Filter)
Recommended Use	Carpet, Car Interior

9. WARRANTY AND SUPPORT

For warranty information, technical support, or to purchase replacement parts, please refer to the official Black & Decker website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

Official Website: www.blackanddecker.com

© 2023 Black & Decker. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question