

[Manuals.plus](#) /

› [Honey-Can-Do](#) /

› Honey-Can-Do Dual Control Dry Food Dispenser (KCH-06123) - Instruction Manual

Honey-Can-Do KCH-06123

Honey-Can-Do Dual Control Dry Food Dispenser (KCH-06123) - Instruction Manual

1. INTRODUCTION AND OVERVIEW

The Honey-Can-Do Dual Control Dry Food Dispenser, model KCH-06123, offers a convenient and hygienic solution for storing and dispensing various dry foods. Its contemporary design features two transparent canisters, each capable of holding up to 17.5 ounces of dry food, totaling 35 ounces. This dispenser is ideal for items such as cereal, trail mix, candy, granola, nuts, beans, and rice.

Key features include a portion-control system that dispenses approximately one ounce per twist, an airtight seal to maintain freshness for up to 45 days, and durable, scratch-resistant, shatterproof construction. The unit also includes a removable bottom tray for easy cleanup.



Image 1: The Honey-Can-Do Dual Control Dry Food Dispenser, showcasing its two transparent canisters filled with different types of cereal, positioned on a kitchen counter next to a white bowl.

2. SETUP INSTRUCTIONS

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure you have the base, two dispenser units with knobs, two transparent canisters, and two lids.
- 2. Initial Cleaning:** Before first use, wash all removable parts (canisters, lids, and dispensing mechanisms) with warm, soapy water. Rinse thoroughly and allow to air dry completely. The main base can be wiped clean with a damp cloth.
- 3. Assemble the Dispenser:**
 - Place the two dispenser units onto the base, ensuring they snap securely into position.
 - Attach the transparent canisters to the top of the dispenser units.
 - Ensure the dispensing knobs are properly aligned and securely attached to the paddle wheels inside the dispenser.
- 4. Fill Canisters:** Open the lids and pour your desired dry food into each canister. Do not overfill.

5. **Secure Lids:** Place the lids firmly back onto the canisters to ensure an airtight seal.

3. OPERATING INSTRUCTIONS

The Honey-Can-Do Dry Food Dispenser is designed for simple, mess-free operation and portion control.

1. **Position Bowl:** Place a bowl directly under the dispensing spout.
2. **Dispense Food:** Twist the chrome knob clockwise. The flexible paddle wheel inside will rotate, dispensing approximately one ounce of dry food with each full twist. Continue twisting until the desired amount is reached.
3. **Maintain Freshness:** After dispensing, ensure the bottom cap is securely in place to maintain the airtight seal and prevent food from going stale.



Image 2: A close-up view of the chrome dispensing knob on the Honey-Can-Do Dry Food Dispenser, showing the mechanism for portion control.

4. MAINTENANCE

Regular cleaning will ensure the longevity and hygienic operation of your dispenser.

- **Disassembly for Cleaning:** To clean, carefully remove the canisters and dispensing units from the base. The bottom tray is also removable for easy access to any crumbs or spills.
- **Washing:** Hand wash all removable parts with warm, soapy water. Rinse thoroughly and dry completely before reassembly. The product is **not dishwasher safe**.
- **Base Cleaning:** Wipe the base clean with a damp cloth. Do not immerse the base in water.
- **Airtight Seal:** Ensure lids are always securely placed on the canisters and the bottom caps are in position when not in use to maintain the airtight seal and preserve food freshness.



REMOVEABLE TRAY CAPTURES CRUMBS

Image 3: A view of the removable bottom tray designed to catch crumbs and facilitate easy cleaning.

5. TROUBLESHOOTING

- **Food Not Dispensing:**
 - Check if the canister is empty or if the food is jammed. Gently shake the canister to dislodge any blockages.
 - Ensure the dispensing knob is fully engaged with the paddle wheel.
- **Cereal Crushing:** The flexible paddle wheel is designed to minimize crushing. However, very delicate or large flake cereals

may experience some breakage. This is normal for this type of dispensing mechanism.

- **Food Going Stale:** Ensure both the top lids and the bottom caps are securely in place after each use to maintain the airtight seal.
- **Messy Spills:** The portion control system is designed to reduce spills. Ensure the bowl is positioned correctly and avoid excessive or rapid twisting of the knob.

6. SPECIFICATIONS

Product Dimensions	13" L x 7.5" W x 16.3" H
Capacity	17.5 ounces per canister (35 ounces total)
Material	Plastic (BPA Free, Food Grade)
Color	White, Chrome
Item Weight	3.65 pounds
Special Feature	Airtight, Shatterproof, Portion Control
Care Instructions	Hand Wash Only
Model Number	KCH-06123
UPC	855321003212



Image 4: Diagram showing the dimensions of the Honey-Can-Do Dual Control Dry Food Dispenser: 16.25" H x 13" W x 7.5" D.

7. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service department. Keep your purchase receipt for any warranty claims.

Manufacturer: Honey-Can-Do

For further assistance, visit the [Honey-Can-Do Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question