

## Wahl Professional 7031-200

# Wahl Professional 5 Star Series Shaver Shaper Replacement Foil (Model 7031-200) Instruction Manual

Model: 7031-200 | Brand: Wahl Professional

## INTRODUCTION

This manual provides comprehensive instructions for the proper installation, use, and maintenance of your Wahl Professional 5 Star Series Shaver Shaper Replacement Foil, Model 7031-200. Designed for professional use, this hypo-allergenic gold foil ensures a super close and comfortable shave. Please read this manual thoroughly before use to ensure optimal performance and longevity of your product.

## SAFETY INFORMATION

- Always ensure the shaver is turned off and unplugged before attempting to replace the foil or perform any maintenance.
- Handle the replacement foil with care to avoid damage to the delicate foil screen.
- Keep replacement parts out of reach of children.
- Do not use damaged or bent foils, as this can cause skin irritation or injury.
- Use only genuine Wahl Professional replacement parts to maintain product integrity and performance.

## PRODUCT OVERVIEW

The Wahl Professional 5 Star Series Shaver Shaper Replacement Foil (Model 7031-200) is engineered for precision and comfort. It features a hypo-allergenic gold foil designed to provide an ultra-close, bump-free shave, making it ideal for finishing and blending bald fades, as well as cleaning up hair and neck lines.



5-STAR  
★★★★★  
SERIES

BUMP FREE SHAVING

# Shaver/Shaper Replacement Gold Foil

RED SUPER CLOSE



Your all-in-one replacement package compatible only with the 5-Star Shaver/Shaper Model #8061-100

Image: Close-up of the Wahl Professional 5 Star Series Shaver Shaper Replacement Gold Foil.



Image: The Wahl Professional Shaver/Shaper Replacement Gold Foil, highlighting its bump-free shaving capability.

## COMPATIBILITY

This replacement foil (Model 7031-200) is specifically designed for use with the **Wahl Professional 5-Star**

**Shaver/Shaper Model #8061-100 (Cord/Cordless).** Ensure your shaver model matches for proper fit and function.



*Image: Visual guide indicating the compatibility of the 07031-200 replacement foil with the 5-Star Shaver/Shaper.*



*Image: A detailed table showing various Wahl replacement foils and their compatible 5-Star shaver models. Model 07031-200 is marked compatible with 5-Star Shaver/Shaper 08061-100.*

## SETUP AND INSTALLATION (FOIL REPLACEMENT)

To ensure optimal shaving performance, replace your shaver foil when it shows signs of wear or damage. Follow these steps:


1. **Turn Off and Unplug:** Ensure your Wahl 5-Star Shaver/Shaper is turned off and unplugged from any power source.
2. **Remove Old Foil:** Gently press the release buttons (if present) or carefully pull the old foil head upwards from the shaver body. Dispose of the old foil responsibly.
3. **Inspect Shaver:** Check the shaver's cutter bar for any debris or hair. Clean if necessary using a small brush.
4. **Install New Foil:** Align the new replacement foil (Model 7031-200) with the shaver head. Gently press down until it clicks securely into place. Do not force it.
5. **Test:** Turn on the shaver briefly to ensure the new foil is properly seated and operating smoothly.

## OPERATING INSTRUCTIONS


Once the replacement foil is installed, your Wahl 5-Star Shaver/Shaper is ready for use. For best results:

- Ensure your skin is clean and dry before shaving.
- Hold the shaver at a slight angle against the skin.

- Use short, gentle strokes against the direction of hair growth for the closest shave.
- Avoid applying excessive pressure, as this can damage the foil and irritate the skin.
- For finishing and blending, use light, controlled movements.



*Image: A Wahl Shaver/Shaper being used to achieve an ultra-smooth finish on the neck area.*



*Image: The Wahl Shaver/Shaper in action, providing a close shave on a person's head.*

## MAINTENANCE AND CARE

Regular cleaning and proper care will extend the life of your replacement foil and maintain optimal shaving performance.

- Daily Cleaning:** After each use, gently tap the foil head to remove loose hair. Use the provided cleaning brush (if applicable) to brush away any remaining hair from the foil and cutter bar.
- Deep Cleaning:** Periodically, remove the foil head and rinse it under warm running water. Allow it to air dry completely before reattaching. Ensure the shaver body does not get wet.
- Lubrication:** Apply a few drops of Wahl clipper oil to the cutter blades (underneath the foil) regularly to ensure smooth operation and reduce wear.
- Storage:** Store the shaver with the foil attached in a clean, dry place, protected from dust and damage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Poor Shaving Performance	Worn or damaged foil; dull cutter blades; insufficient cleaning.	Replace the foil (Model 7031-200). Ensure cutter blades are sharp (replace if necessary). Clean the foil and cutter bar thoroughly.
Skin Irritation/Bumps	Damaged foil; applying too much pressure; shaving against grain too aggressively.	Inspect foil for damage and replace if found. Use lighter pressure and gentle strokes. Ensure skin is clean before shaving.
Foil Not Staying Attached	Improper installation; damaged locking mechanism on shaver or foil.	Ensure the foil is correctly aligned and clicks into place. If the issue persists, the shaver or foil may be damaged and require professional inspection or replacement.

## SPECIFICATIONS

- **Model Number:** 7031-200
- **UPC:** 043917703121
- **Product Dimensions:** 1 x 3 x 1 inches
- **Item Weight:** 0.32 ounces
- **Special Feature:** Hypo-Allergenic Gold Foil
- **Recommended Uses:** Beard, Mustache, Neck, Chin, Lip
- **Manufacturer:** Wahl

## WARRANTY AND SUPPORT

Wahl Professional products are manufactured to the highest standards. For specific warranty information regarding your shaver or replacement parts, please refer to the documentation included with your original Wahl Professional shaver or visit the official Wahl Professional website. For technical support or further assistance, please contact Wahl Professional customer service.

*Note: Using non-genuine replacement parts may void your product's warranty.*

## **IMPORTANT NOTE ON VIDEOS**

---

No official product videos from the seller meeting the specified criteria (creator\_type: "Seller") were found in the provided data to embed in this manual.