Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Bluestork /
- > Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard User Manual

Bluestork BS-KB-MICRO/BT/SP

Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard User Manual

Model: BS-KB-MICRO/BT/SP

1. Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard. Please read this manual carefully before using the product to ensure proper functionality and longevity.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard
- User Manual (this document)



Image: The retail packaging for the Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard, showing the keyboard and branding.

3. PRODUCT OVERVIEW

The Bluestork BS-KB-Micro/BT/SP is a compact, wireless Bluetooth keyboard designed for various compatible devices. It features a QWERTY layout and operates using AAA batteries.



Image: Top-down view of the Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard, displaying the full key layout.



Image: Angled view of the Bluestork BS-KB-Micro/BT/SP Bluetooth QWERTY Keyboard, highlighting its slim profile and key design.

4. SETUP

4.1. Battery Installation

- 1. Locate the battery compartment on the underside of the keyboard.
- 2. Open the battery compartment cover.
- 3. Insert two (2) AAA batteries, ensuring correct polarity (+/-).
- 4. Close the battery compartment cover securely.

4.2. Pairing with a Device

To connect your Bluestork keyboard via Bluetooth:

- 1. Ensure the keyboard has fresh batteries installed and is powered on (if it has a power switch).
- 2. Activate Bluetooth on your compatible device (e.g., PC, tablet, smartphone).
- 3. Put the keyboard into pairing mode. This usually involves pressing a dedicated Bluetooth pairing button or a combination of function keys (refer to specific key markings on your keyboard, often indicated by a Bluetooth symbol).
- 4. On your device, search for available Bluetooth devices.
- 5. Select "Bluestork Keyboard" or a similar name from the list of found devices.
- 6. If prompted, enter the pairing code displayed on your device's screen using the Bluestork keyboard and press **Enter**.
- 7. Once paired, the keyboard will be ready for use.

5. OPERATING INSTRUCTIONS

5.1. Basic Usage

The keyboard functions like a standard QWERTY keyboard. Simply type as you would on any other keyboard.

5.2. Function Keys

The keyboard may feature function keys (F1-F12) with secondary multimedia or system control functions. These are typically accessed by holding down the **Fn** key and pressing the desired function key.

Fn + Fx: Access multimedia controls (e.g., volume, play/pause), brightness adjustments, or other system
functions. Refer to the icons printed on the keys for specific functions.

5.3. Automatic Shutdown

The keyboard is equipped with an automatic shutdown feature to conserve battery life. If inactive for a period, it will enter a low-power sleep mode. To reactivate, press any key.

6. MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage. Store the keyboard in a cool, dry place.
- Battery Replacement: Replace batteries when performance degrades or the keyboard stops responding. Always use new AAA batteries.

7. TROUBLESHOOTING

Keyboard not responding:

- Check if the batteries are correctly installed and have sufficient charge. Replace if necessary.
- Ensure the keyboard is powered on.
- Verify that Bluetooth is enabled on your device.
- Re-pair the keyboard with your device. Go to your device's Bluetooth settings, remove the keyboard, and then follow the pairing instructions in Section 4.2.
- Ensure the keyboard is within the effective range of your device's Bluetooth signal (typically up to 10 meters).

Keys are not typing correctly:

- Check your device's language and keyboard layout settings to ensure they match the QWERTY layout of the Bluestork keyboard.
- Clean any debris from around the affected keys.

Intermittent connection:

- Move closer to your device to reduce interference.
- Ensure there are no other strong wireless signals or large metal objects between the keyboard and your device.
- · Replace batteries.

8. SPECIFICATIONS

Feature	Detail
Brand	Bluestork

Model Number	BS-KB-MICRO/BT/SP
Connectivity	Bluetooth (Wireless)
Keyboard Layout	QWERTY
Compatible Devices	PC and other Bluetooth-enabled devices
Power Source	2 x AAA Batteries (not rechargeable)
Special Features	Automatic shutdown for power saving
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Silver/White (Solid color)

9. WARRANTY INFORMATION


Information regarding product warranty is not available in the provided data. Please refer to the warranty card included with your purchase or contact Bluestork customer support for details.

10. SUPPORT

For further assistance or technical support, please visit the official Bluestork website or contact their customer service department. Contact information may be found on the product packaging or their official website.

© 2023 Bluestork. All rights reserved.

Related Documents - BS-KB-MICRO/BT/SP





Kwikboil Instant Boiling Water Dispenser Operation and Installation Manual

Comprehensive operation and installation manual for the Kwikot Kwikboil Instant Boiling Water Dispensers, covering features, specifications, installation steps, troubleshooting, and warranty information.