

[manuals.plus](#) /

› [Hamilton Beach](#) /

› [Hamilton Beach Health Smart Juice Extractor Model 67150 User Manual](#)

Hamilton Beach 67150

Hamilton Beach Health Smart Juice Extractor Model 67150 User Manual

Model: 67150

INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Hamilton Beach Health Smart Juice Extractor, Model 67150. Please read all instructions carefully before first use and retain this manual for future reference.



Figure 1: Hamilton Beach Health Smart Juice Extractor, Model 67150, assembled and ready for use.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons. Read all instructions.

- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Avoid contact with moving parts.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the cover is securely locked in place before operating the motor.
- Do not put fingers or other objects into the feed chute while the appliance is in operation. If food becomes lodged in the chute, use the food pusher provided.

SETUP AND ASSEMBLY

Before first use, wash all removable parts in warm, soapy water or in the dishwasher (top rack only). Rinse and dry thoroughly. The juicer consists of several components that fit together for operation.

1. Place the motor base on a clean, dry, and level surface.
2. Insert the strainer basket into the motor base, ensuring it sits firmly.
3. Place the juicer cover over the strainer basket and align it with the motor base.
4. Secure the locking clips on both sides of the juicer cover to the motor base. Ensure they click into place.
5. Insert the food pusher into the feed chute opening on the juicer cover.
6. Position the pulp container under the pulp spout and the juice cup under the juice spout.



Figure 2: Disassembled components of the juicer, illustrating how parts separate for cleaning.

OPERATING INSTRUCTIONS

The Hamilton Beach Health Smart Juice Extractor is designed for efficient juicing of fruits and vegetables. Its wide mouth chute minimizes the need for pre-cutting.

1. Ensure the juicer is properly assembled and securely locked.
2. Plug the power cord into a standard electrical outlet.
3. Prepare your fruits and vegetables. For apples, it is recommended to remove seeds to avoid grinding them. The wide mouth chute can accommodate whole or large pieces of many fruits and vegetables, reducing preparation time.
4. Place a glass or the provided juice cup under the juice spout.
5. Turn the juicer ON using the switch located on the front of the unit.
6. Gradually feed the prepared fruits or vegetables into the feed chute. Use the food pusher to gently guide them down. Do not force food into the chute.
7. Observe the juice flowing into your cup and the pulp collecting in the pulp container.
8. Once juicing is complete, turn the juicer OFF and unplug it from the outlet.




Figure 3: Example of fresh juice prepared with the extractor, showcasing various fruits and vegetables.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer. All removable parts are dishwasher safe.

1. Always unplug the juicer before cleaning.
2. Disassemble the juicer by releasing the locking clips, removing the cover, strainer basket, and food pusher.
3. Empty the pulp container.
4. Rinse all removable parts under running water to remove any large food particles.
5. For thorough cleaning, wash the removable parts in warm, soapy water or place them on the top rack of your dishwasher.
6. Use the provided cleaning brush to clean the strainer basket, especially the fine mesh, to remove any trapped pulp.
7. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
8. Dry all parts thoroughly before reassembling or storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; locking clips not secured.	Ensure power cord is firmly plugged into a working outlet. Check that both locking clips are fully engaged.
Low juice yield or excessive pulp.	Strainer basket clogged; feeding food too quickly.	Clean the strainer basket thoroughly. Feed food slowly and steadily.
Motor stops during operation.	Overheating; too much pressure on food pusher.	Turn off and unplug. Allow to cool for 30 minutes. Reduce pressure when feeding food.

SPECIFICATIONS

- **Brand:** Hamilton Beach
- **Model Number:** 67150
- **Power Source:** Corded Electric
- **Wattage:** 150 watts
- **Blade Material:** Stainless Steel
- **Product Dimensions:** 8.5 x 8.4 x 13.6 inches
- **Item Weight:** 6 pounds

- **Dishwasher Safe Parts:** Yes (removable parts)

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the official Hamilton Beach website or contact their customer service. Keep your purchase receipt as proof of purchase for warranty claims.

Hamilton Beach Official Website: [Visit the Hamilton Beach Store on Amazon](#)