

Fastrack NS3072SL01

Fastrack Big Time Analog Chronograph Watch NS3072SL01 User Manual

Model: NS3072SL01

1. INTRODUCTION

Thank you for choosing the Fastrack Big Time Analog Chronograph Watch, model NS3072SL01. This timepiece combines classic analog display with chronograph functionality, offering precision and a distinctive style. This manual provides essential information for setting up, operating, and maintaining your watch to ensure its optimal performance and longevity.

2. PRODUCT OVERVIEW

Familiarize yourself with the key components of your Fastrack Chronograph watch.



Figure 2.1: Front view of the Fastrack Big Time Analog Chronograph Watch. Displays the white dial, three subdials, main hour and minute hands, and the crown and pushers on the side.



Figure 2.2: Side view of the watch, highlighting the crown and the two chronograph pushers. The black leather strap with white stitching is also visible.



Figure 2.3: Rear view of the watch, showing the stainless steel case back with Fastrack branding and model engravings. The brown leather strap and buckle are also visible.



Figure 2.4: The Fastrack watch packaging, designed as a black cylindrical can with the brand logo.

3. SETUP AND INITIAL OPERATION

3.1 Setting the Time

1. Pull the crown (located on the right side of the watch) out to position 2.
2. Rotate the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. Once the correct time is set, push the crown back into position 1 (normal operating position). The second hand will begin to move.

3.2 Battery Activation

Your watch comes with a pre-installed battery. If the watch is not running upon receipt, ensure the crown is fully pushed in. If it still does not operate, the battery may need replacement (refer to Section 5.3).

4. OPERATING THE CHRONOGRAPH FUNCTION

The chronograph function allows you to measure elapsed time independently of the main time display.

4.1 Chronograph Pushers

- **Pusher A (Top Pusher):** Starts and stops the chronograph.
- **Pusher B (Bottom Pusher):** Resets the chronograph to zero.

4.2 Using the Chronograph

1. To start timing, press Pusher A. The chronograph second hand (typically the large central second hand or a dedicated subdial hand) will begin to move.
2. To stop timing, press Pusher A again. The chronograph hands will stop, indicating the elapsed time.
3. To reset the chronograph, press Pusher B. The chronograph hands will return to their zero positions.
4. To measure split times (lap times), press Pusher A to start, then Pusher B to temporarily stop the hands to read a split time, while the chronograph continues to run internally. Press Pusher B again to catch up the hands to the running time. Press Pusher A to stop the final time, then Pusher B to reset.

5. MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your Fastrack watch.

5.1 Cleaning

- Wipe the watch case and crystal with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals. Clean with a slightly damp cloth and allow to air dry.

5.2 Water Resistance

While your watch may offer some resistance to splashes, it is generally not designed for swimming or showering. Avoid submerging the watch in water. Always ensure the crown is fully pushed in to maintain any water resistance.

5.3 Battery Replacement

The watch is powered by a quartz movement and requires a 'A' type battery (1 included). When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to prevent damage to the movement and maintain water resistance.

6. TROUBLESHOOTING

If you encounter issues with your watch, refer to the following common solutions:

- **Watch Not Running:** Ensure the crown is fully pushed in. If it still doesn't run, the battery may need replacement.
- **Incorrect Time:** Re-set the time as described in Section 3.1. If the time consistently loses or gains significantly, the movement may require servicing.
- **Chronograph Hands Not Resetting to Zero:** This may require a chronograph reset procedure. Consult a professional watch repair service for adjustment.

For persistent issues, contact Fastrack customer support or an authorized service center.

7. SPECIFICATIONS

Detailed technical specifications for the Fastrack Big Time Analog Chronograph Watch NS3072SL01:

Feature	Specification
Model Number	NS3072SL01
Movement Type	Quartz
Case Diameter	48.25 Millimetres
Band Material Type	Leather
Band Colour	Black
Item Weight	200 Grams
Batteries Required	1 A battery (included)
Manufacturer	Titan Company Limited
Country of Origin	India

8. WARRANTY AND SUPPORT


8.1 Warranty Information






Your Fastrack watch comes with a Limited Warranty. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects.

8.2 Customer Support

For any inquiries, service requests, or warranty claims, please contact Fastrack customer support or visit an authorized Fastrack service center. Contact details can usually be found on the Fastrack official website or on your warranty documentation.

Related Documents - NS3072SL01

	<p>OY22E Smart Watch User Manual: Setup, Features, and Safety</p> <p>Comprehensive user manual for the OY22E Smart Watch by Fastrack. Learn how to set up, pair, use features like Bluetooth calls, health tracking, and understand safety guidelines and specifications.</p>
---	---

	<p>Fastrack S06 Smartwatch User Manual</p> <p>Comprehensive user manual for the Fastrack S06 Smartwatch, covering setup, features, maintenance, and safety information.</p>
	<p>Fastrack Reflex Play Smartwatch User Manual: Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the Fastrack Reflex Play smartwatch, covering setup, app connection, features like fitness tracking, heart rate monitoring, notifications, and troubleshooting guides.</p>
	<p>Fastrack Reflex Beat+ Smartwatch User Manual: Features, Pairing & Setup</p> <p>Comprehensive user manual for the Fastrack Reflex Beat+ Smartwatch. Learn about its features, app installation, watch pairing, health tracking, and technical specifications.</p>
	<p>Fastrack FPods FT7 Truly Wireless Earpods Quick Start Guide</p> <p>Get started with your Fastrack FPods FT7 Truly Wireless Earpods. This guide covers setup, controls, features like 3C NitroFast Charge, Quad Mic ENC, and low latency gaming mode.</p>
	<p>Fastrack FPods FZ100 Truly Wireless Earbuds Quick Start Guide</p> <p>Learn how to set up, use, and care for your Fastrack FPods FZ100 Truly Wireless Earbuds. This guide covers pairing, controls, features like gaming mode and voice assistant, charging, and specifications.</p>