

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [ONE TOUCH](#) /
- › [One Touch Hands Free Can Opener User Manual](#)

ONE TOUCH KC86

One Touch Hands Free Can Opener

USER MANUAL

Introduction

Thank you for purchasing the One Touch Hands Free Can Opener, model KC86. This automatic can opener is designed for effortless and safe opening of various can sizes and shapes, providing a convenient solution for your kitchen needs. Please read this manual carefully before use to ensure proper operation and maintenance.



Image: The One Touch Hands Free Can Opener positioned on top of a can of soup, ready for operation. This image illustrates the product in use.

Setup

Before using your One Touch Can Opener for the first time, follow these steps:

- 1. Battery Installation:** The can opener requires 2 AA batteries (not included). Locate the battery compartment on the

underside of the device. Open the cover, insert the batteries according to the polarity indicators (+/-), and close the cover securely.

2. **Initial Cleaning:** Wipe the cutting blade and exterior of the can opener with a damp cloth before first use. Ensure it is completely dry before operation.



Image: A top-down view of the One Touch Hands Free Can Opener, showing its sleek white design and the prominent green activation button. This image highlights the device's simple interface.

Operating Instructions

Using your One Touch Can Opener is simple and efficient:

1. **Positioning:** Place the can opener on top of the can, ensuring the cutting wheel and the metal gear are aligned with the can's rim. The can opener will automatically grip the can.
2. **Start Operation:** Press the green activation button once. The can opener will start cutting along the side of the can. It will automatically stop once the can is fully opened.
3. **Removing the Can Opener:** Once the cutting process is complete and the motor stops, gently lift the can opener off the can. The lid will remain attached to the can opener via a magnet for safe disposal.
4. **Lid Removal:** To release the lid, press the green activation button again. This will reverse the motor slightly, releasing the lid from the magnet. Dispose of the lid safely.

Note: The can opener cuts along the side of the can, leaving a smooth, safe edge on both the can and the lid.



Image: The One Touch Hands Free Can Opener positioned on a square-shaped can, demonstrating its versatility in handling different can forms. This image highlights the product's adaptability.

Maintenance

Proper care will extend the life of your can opener:

- **Cleaning:** After each use, wipe the cutting wheel and the magnet with a damp cloth to remove any food residue. Do not immerse the can opener in water or wash it in a dishwasher.
- **Drying:** Ensure the can opener is completely dry before storing.
- **Storage:** Store the can opener in a dry place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the can opener slows down or fails to operate, replace the batteries. Always replace both batteries at the same time.

Troubleshooting

Problem	Possible Cause	Solution
Can opener does not start.	Batteries are dead or incorrectly inserted.	Check battery polarity or replace batteries.
Can opener stops mid-operation.	Batteries are low. Can is dented or irregular.	Replace batteries. Reposition the can opener or try a different can.
Lid does not detach from magnet.	Can opener not fully reset.	Press the activation button again to release the lid.
Can opener leaves rough edges.	Improper positioning or worn blade.	Ensure proper alignment on the can rim. If problem persists, contact support.

Specifications

- **Brand:** One Touch
- **Model Number:** KC86
- **Color:** White/Green
- **Product Dimensions:** 7 x 11.5 x 4.5 cm (2.76 x 4.53 x 1.77 inches)
- **Item Weight:** 160 g (0.35 lbs)
- **Material:** Stainless Steel (blade), Plastic (body)
- **Power Source:** 2 x AA Batteries (1.5V each)
- **Operating Mode:** Automatic
- **Automatic Shut-off:** No (User must press button to stop/release lid)

Warranty and Support

The One Touch Hands Free Can Opener is designed for durability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ONE TOUCH website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please contact customer service:

- **Manufacturer:** ONE TOUCH
- **Website:** www.onetouch.com (Note: This is a placeholder URL as no specific support link was provided)

Related Documents - KC86

 ONE-TOUCH™ Original Instructions One Touch Automatic Jar Opener Article No. 92 29 03 CE	<p>One Touch Automatic Jar Opener - Original Instructions and User Guide</p> <p>Comprehensive instructions and safety information for the One Touch Automatic Jar Opener (Article No. 92 29 03) by Westfalia Werkzeugcompany. Learn how to use, maintain, and dispose of the product safely.</p>
 ONE-TOUCH™ AUTOMATIC CAN OPENER (The Classic) ONE-TOUCH™ SOUP USER MANUAL	<p>One Touch Automatic Can Opener (The Classic) User Manual KC08</p> <p>Comprehensive user manual for the One Touch Automatic Can Opener (The Classic), model KC08. Includes instructions for battery installation, operation, safety precautions, care, maintenance, and troubleshooting.</p>
 ONE-TOUCH™ Original Instructions One Touch Automatic Jar Opener Article No. 92 29 03 CE	<p>One Touch Automatic Jar Opener - Original Instructions and User Guide</p> <p>Comprehensive instructions and safety information for the One Touch Automatic Jar Opener (Article No. 92 29 03) by Westfalia Werkzeugcompany. Learn how to use, maintain, and dispose of the product safely.</p>
 ONE-TOUCH™ One Touch Deckelöffner One Touch Jar Opener Art. 92 29 03 Westfalia	<p>One Touch Jar Opener by Westfalia - User Manual and Safety Instructions</p> <p>Comprehensive user manual and safety guide for the Westfalia One Touch Jar Opener (Art. 92 29 03), detailing operation, maintenance, and important safety precautions.</p>
 OneShot Automatic Soap System Technical Concepts	<p>OneShot Automatic Soap System: Touch-Free Dispenser Features and Installation</p> <p>Discover the OneShot Automatic Soap System, a touch-free, hands-free soap dispenser from Technical Concepts. Learn about its features, specifications, installation guide, and frequently asked questions.</p>



[Kitchen Mama One-Touch Electric Can Opener: Use and Care Manual](#)

Comprehensive use and care manual for the Kitchen Mama One-Touch Electric Can Opener. Learn how to operate, maintain, and troubleshoot your can opener for safe and efficient use.