

[Manuals.plus](#) /

> [Joseph Joseph](#) /

> Joseph Joseph Wash & Drain Dish Tub Instruction Manual (Model B00AVWE7O2)

## Joseph Joseph B00AVWE7O2

# Joseph Joseph Wash & Drain Dish Tub Instruction Manual

Model: B00AVWE7O2

Brand: Joseph Joseph

## 1. INTRODUCTION

The Joseph Joseph Wash & Drain Dish Tub is a versatile and practical kitchen accessory designed to simplify dishwashing and other household tasks. Its innovative design features an integrated plug for easy draining and straining, along with sturdy handles for convenient portability. This manual provides essential information for the proper setup, operation, and maintenance of your Wash & Drain Dish Tub.



*Image 1: Joseph Joseph Wash & Drain Dish Tub in Gray.*

## 2. KEY FEATURES

- **Integrated Plug and Strainer:** Easily twist the plug to drain water or strain food particles, preventing sink blockages.
- **Large Carry Handles:** Designed for comfortable and secure transport, even when the tub is full.
- **Steep Sides:** Helps to contain water and soapsuds, minimizing splashes and spills.
- **Durable Construction:** Made from robust plastic for long-lasting use.
- **Versatile Use:** Ideal for dishwashing in the sink, on the counter, or for other tasks like soaking clothes or carrying items.

## 3. SETUP

1. **Unpack:** Carefully remove the Wash & Drain Dish Tub from its packaging.
2. **Inspect:** Check the tub and its integrated plug for any signs of damage.
3. **Initial Cleaning:** Before first use, wash the tub with warm soapy water and rinse thoroughly.
4. **Positioning:** Place the tub in your kitchen sink or on a stable, flat surface where you intend to use it. Ensure the area is clear and ready for use.

## 4. OPERATING INSTRUCTIONS

### 4.1 Filling the Tub

Ensure the integrated plug is in the closed position (fully pressed down and twisted to seal) before filling the tub with water and dish soap. The steep sides are designed to keep water and suds contained.

### 4.2 Draining and Straining

The Wash & Drain features an integrated plug with multiple settings:

- **Sealed:** Press the plug down and twist to seal, allowing the tub to hold water.
- **Drain & Strain:** Twist the plug to partially open it. This allows water to drain while trapping larger food particles in the integrated strainer, preventing them from going down your sink drain.
- **Fast Empty:** For quick emptying, pull the plug completely out.




Image 2: Illustration of the three plug settings for draining and straining.

### 4.3 Portability

Utilize the large, integrated handles on either side of the tub to easily lift and carry it, even when filled with water or dishes. This feature is particularly useful for moving the tub between different locations or for emptying it into a larger sink.



Image 3: The Wash & Drain Dish Tub positioned within a kitchen sink for use.

## 5. MAINTENANCE AND CARE

- **Cleaning:** The Joseph Joseph Wash & Drain Dish Tub is designed for hand washing only. Do not place it in a dishwasher.
- **Plug Cleaning:** Regularly remove the integrated plug to clean any trapped food particles. Wash the plug and the tub thoroughly with warm, soapy water.
- **Drying:** Allow the tub to air dry completely after cleaning to prevent water spots or mildew.
- **Storage:** Store the tub in a dry place when not in use. Its compact design allows for easy storage under most sinks or in cabinets.

## 6. TROUBLESHOOTING

- **Water Leaks:** If water is leaking from the plug, ensure it is fully pressed down and twisted into the sealed position. Check for any debris obstructing the seal.
- **Slow Draining:** If the tub is draining slowly, the integrated strainer may be clogged with food particles. Remove the plug and clean the strainer thoroughly.

## 7. SPECIFICATIONS

| Attribute    | Value         |
|--------------|---------------|
| Brand        | Joseph Joseph |
| Model Number | B00AVWE7O2    |

|                                |  |
|--------------------------------|--|
| Color                          | Gray   |
| Material                       | Plastic  |
| Item Weight                    | 200 Grams                                      |
| Product Dimensions (L x W x H) | 12.4" x 12.2" x 7.9" (31.5 cm x 31 cm x 20 cm) |
| Capacity                       | 2.35 Gallons (8.9 Liters)                      |
| Handle Material                | Plastic  |
| Shape                          | Round, Oval                                    |

## 8. WARRANTY AND SUPPORT

The Joseph Joseph Wash & Drain Dish Tub comes with a manufacturer's warranty. For specific warranty details, product support, or to inquire about replacement parts, please refer to the official Joseph Joseph website or contact their customer service directly. Keep your proof of purchase for warranty claims.

**Website:** [www.josephjoseph.com](http://www.josephjoseph.com)