

[Manuals.plus](#) /

› [Joseph Joseph](#) /

› Joseph Joseph Rinse & Chop Plus Chopping Board with Integrated Colander - Model 60081 User Manual

Joseph Joseph 60081

Joseph Joseph Rinse & Chop Plus Chopping Board with Integrated Colander - Model 60081 User Manual

Your guide to using and maintaining your Joseph Joseph Rinse & Chop Plus.

1. PRODUCT OVERVIEW

The Joseph Joseph Rinse & Chop Plus is a versatile kitchen tool designed to simplify food preparation. This innovative chopping board features an integrated colander, allowing you to rinse and chop ingredients efficiently in one compact unit. Its unique folding design provides multiple functionalities for various kitchen tasks.



Image 1.1: The Joseph Joseph Rinse & Chop Plus Chopping Board shown in its folded position, ready to be used as a colander. The vibrant green color is visible, and the perforated section for draining is clearly displayed.

Key Features:

- **Multi-function Folding Design:** Transforms from a flat chopping surface to a curved colander or a chute.

- **Integrated Colander:** Allows for easy rinsing of food items directly on the board.
- **Knife-Friendly Surface:** Provides a durable and safe surface for cutting and chopping.
- **Chute Function:** Facilitates neat transfer of chopped food or waste into a pan or bin.
- **Non-Slip Edge:** Ensures stability during use, preventing the board from sliding.
- **Hanging Point:** Includes a hole for convenient storage.

2. SETUP

Before first use, and after each subsequent use, ensure the chopping board is clean. The Rinse & Chop Plus is ready for immediate use out of the packaging after a thorough wash.

1. **Unpack:** Remove the chopping board from its packaging.
2. **Wash:** Wash the board thoroughly with warm soapy water or place it in a dishwasher.
3. **Dry:** Ensure the board is completely dry before storing or using.

3. OPERATING INSTRUCTIONS

The Rinse & Chop Plus offers three primary modes of operation: flat chopping surface, integrated colander, and food chute.

3.1. Using as a Chopping Surface

To use the board as a flat chopping surface, ensure it is fully unfolded and lying flat on a stable countertop. The non-slip edge will help keep it in place.

- Place the board on a clean, flat surface.
- Proceed with chopping or cutting ingredients as desired.

3.2. Using the Integrated Colander

The board can be folded to create a curved colander for rinsing fruits, vegetables, or other food items.

1. Hold the board by its handles.
2. Gently fold the board along its central crease until the perforated section forms a curved basket shape.
3. Place food items into the colander.
4. Rinse under running water, allowing excess water to drain through the perforations.



Image 3.1: The Joseph Joseph Rinse & Chop Plus Chopping Board demonstrating its colander function. Chopped red cabbage is being rinsed, with water draining into a bowl below the perforated section of the board.

3.3. Using the Chute Function

After chopping, the board can be folded to create a chute, making it easy to transfer ingredients directly into a pot, pan, or waste bin without spills.

1. Once chopping is complete, lift the board.
2. Fold the board along its central crease, creating a V-shape.
3. Guide the chopped food or waste into the desired container.



Image 3.2: The Joseph Joseph Rinse & Chop Plus Chopping Board folded into a chute. This configuration allows for easy and mess-free transfer of chopped ingredients or food waste into a cooking vessel or disposal unit.

4. MAINTENANCE

Proper care will extend the life and maintain the appearance of your Rinse & Chop Plus chopping board.

- **Cleaning:** The chopping board is dishwasher safe. Alternatively, wash by hand with warm soapy water.
- **Drying:** Allow the board to air dry completely or wipe dry with a clean cloth before storing.
- **Storage:** Store flat or hang using the integrated hole for convenient storage.

5. TROUBLESHOOTING

Addressing common concerns for your chopping board.

- **Discoloration:** Over time, certain foods (e.g., tomatoes, carrots, turmeric) may cause slight discoloration. This is normal for plastic chopping boards and does not affect performance or hygiene.
- **Knife Marks:** The board is designed to be knife-friendly, meaning it will show some knife marks over time. This is normal and helps protect your knife blades.
- **Avoid Serrated Knives:** Using serrated knives on the cutting surface may cause excessive wear and tear, potentially "chewing up" the plastic. It is recommended to use smooth-edged knives for optimal board longevity.
- **Warping:** Avoid exposing the board to extreme heat, such as placing hot pans directly on it, as this can cause warping.

6. SPECIFICATIONS

Detailed technical specifications for the Joseph Joseph Rinse & Chop Plus Chopping Board.

Feature	Detail
Brand	Joseph Joseph
Model Number	60081
Colour	Green
Material	Resin
Product Dimensions (L x W x Th)	42.5L x 26.5W x 6Th centimetres
Item Weight	0.96 Pounds
Shape	Rectangular (when flat)
Care Instructions	Dishwasher Safe
Included Components	1 x Chopping Board
UPC	732233491705, 899989066592, 798525559942
ASIN	B00AVWEBFM




Image 6.1: A diagram illustrating the dimensions of the Joseph Joseph Rinse & Chop Plus Chopping Board. The length is indicated as 18 inches (45 cm), providing a clear understanding of its size.

7. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to the official Joseph Joseph website or contact their customer service directly. Specific warranty terms may vary by region and retailer.

Official Website: www.josephjoseph.com

© 2023 Joseph Joseph. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question