

Beetel B25

Beetel B25 Corded Landline Phone User Manual

Model: B25

1. INTRODUCTION

This manual provides essential instructions for the proper installation, operation, and maintenance of your Beetel B25 Corded Landline Phone. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

The Beetel B25 is a reliable corded landline phone designed for both desktop and wall-mounted use. It features essential functions for clear communication.

Key Features:

- Ringer volume control for adjustable alert levels.
- Tone/pulse dialing switchable for compatibility with various telephone systems.
- Designed for both desktop placement and wall mounting.
- Redial function for quickly calling the last dialed number.
- Pause function for inserting a delay during dialing.

Components:



Figure 2.1: Overview of the Beetel B25 phone, showing the base unit, handset, coiled handset cord, and line cord.



Figure 2.2: Detailed view of the Beetel B25 keypad, including the Tone/Pulse switch, Flash, Pause, and Redial buttons.




Figure 2.3: Side view of the Beetel B25 phone, illustrating its compact design and the attached coiled cord.

3. SETUP

3.1 Connecting the Phone

1. **Connect the Handset:** Plug one end of the coiled cord into the handset and the other end into the designated jack on the phone base unit.
2. **Connect to Phone Line:** Insert one end of the straight line cord into the phone base unit's line jack and the other end into your telephone wall jack.

3.2 Placement Options

- **Desktop Use:** Place the phone on a flat, stable surface.
- **Wall Mounting:** The Beetel B25 is designed to be wall-mountable. Use appropriate screws (not included) to secure the phone to a wall. Ensure the phone is securely attached to prevent accidental falls.

4. OPERATING INSTRUCTIONS

4.1 Making a Call

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.
4. Once the call is complete, replace the handset on the base unit.

4.2 Receiving a Call

1. When the phone rings, lift the handset to answer the call.
2. After the conversation, replace the handset on the base unit.

4.3 Redial Function

To redial the last number called:

1. Lift the handset.
2. Press the **REDIAL** button. The phone will automatically dial the last number.

4.4 Pause Function

The Pause function inserts a delay in the dialing sequence, useful when dialing numbers that require waiting for a second dial tone (e.g., PABX systems).

1. Lift the handset and begin dialing.
2. At the point where a pause is needed, press the **PAUSE** button.
3. Continue dialing the remaining digits after the pause.

4.5 Ringer Volume Control

The ringer volume can be adjusted using the switch located on the side or bottom of the phone base unit. Slide the switch to your desired volume level (e.g., High, Low, Off).

4.6 Tone/Pulse Dialing Switch

The Beetel B25 supports both Tone (DTMF) and Pulse dialing modes. The switch is typically located on the side or bottom of the phone base unit, or near the keypad (refer to Figure 2.2).

- Set the switch to **TONE** for modern telephone systems.
- Set the switch to **PULSE** for older, rotary-style telephone systems.

Note: Most modern telephone exchanges use Tone dialing. If you are unsure, try Tone mode first.

5. MAINTENANCE

- **Cleaning:** Wipe the phone with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the phone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the phone or subjecting it to strong impacts.

6. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|-------------------------------|---|--|
| No dial tone. | Phone line not connected properly or service issue. | Ensure the line cord is securely plugged into both the phone and the wall jack. Test with another phone if available, or contact your telephone service provider. |
| Cannot make or receive calls. | Incorrect dialing mode (Tone/Pulse) or line issue. | Check the Tone/Pulse switch setting. Most modern systems use Tone. Verify phone line connection. |
| Ringer not working. | Ringer volume set to Off or Low. | Adjust the ringer volume control switch to a higher setting. |

7. SPECIFICATIONS

| | |
|---------------------------|--|
| Model Number | B25 |
| Product Dimensions | 22.2 x 9.8 x 7 cm |
| Item Weight | 390 g |
| Color | Blue |
| Material | Plastic |
| Telephone Type | Corded |
| Power Source | Line-powered (No batteries required for basic operation) |
| Manufacturer | Beetel Teletech Limited |
| Country of Origin | India |

Note on Batteries: The product specifications mentioned "C batteries required." However, standard corded landline phones like the B25 are typically line-powered and do not require batteries for basic operation. This specification might refer to an optional feature or be a general entry. Please refer to the product packaging for definitive battery requirements if any advanced features are present.

8. WARRANTY INFORMATION

The Beetel B25 Corded Landline Phone may be covered by a manufacturer's warranty. Warranty terms and conditions are subject to the manufacturer's policy. Please retain your purchase receipt as proof of purchase for any warranty claims.

For specific warranty details, it is recommended to contact Beetel Teletech Limited directly or refer to any warranty documentation included with your product packaging.

9. CUSTOMER SUPPORT

For technical assistance, service, or inquiries regarding your Beetel B25 Corded Landline Phone, please contact the manufacturer:

- **Manufacturer:** Beetel Teletech Limited
- **Customer Care:** 1800-10-23456
- **Website:** www.beetel.in

| | |
|---|--|
|  | <p>Beetel M71 Caller ID Phone User Manual</p> <p>User manual for the Beetel M71 Caller ID Phone, detailing its features, setup, and troubleshooting.</p> |
|  | <p>Beetel B26 User's Manual: Installation, Features, and Warranty</p> <p>This user's manual provides comprehensive guidance for the Beetel B26 corded telephone, covering installation, operation, essential precautions, and warranty information. Learn how to set up and use your Beetel B26 phone effectively.</p> |
|  | <p>Beetel F2N+ GSM Fixed Wireless Phone: Features and Specifications</p> <p>A comprehensive overview of the Beetel F2N+ GSM Fixed Wireless Phone, detailing its dual SIM capability, language support, key features, and a comparison with the F2N model. Includes specifications and pricing.</p> |
|  | <p>GS-B25 Bluetooth Audio Speaker User Manual</p> <p>User manual for the GS-B25 Bluetooth audio speaker, covering reconnection, stereo connect, product specifications, charging instructions, important notices, and FCC compliance information.</p> |