

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Duravit](#) /
- › [Duravit Metro Flush Valve 0074030062 User Manual](#)

### Duravit 0074030062

# Duravit Metro Flush Valve Instruction Manual

MODEL: 0074030062

Brand: Duravit

## 1. PRODUCT OVERVIEW

---

The Duravit 0074030062 Metro Flush Valve is an essential component for your toilet's flushing mechanism. This is an original replacement part designed for Duravit Metro toilets, featuring a 3-inch one-piece design and engineered for a single flush at 1.28 gallons per flush (gpf). It ensures efficient and reliable water discharge from the toilet tank into the bowl.



Image: The Duravit Metro 3-inch flush valve, showing its white plastic construction, integrated flapper, and metal chain for connection to the

## 2. INSTALLATION (SETUP)

---

### 2.1 Safety Precautions

- Always turn off the water supply to the toilet before beginning any installation or maintenance.
- Drain the toilet tank completely before removing old components.
- Wear appropriate personal protective equipment, such as gloves, if necessary.

### 2.2 Tools Required

- Adjustable wrench or pliers
- Sponge or towel for water cleanup
- Bucket (optional, for draining)

### 2.3 Installation Steps

1. Turn off the water supply valve located at the base of the toilet.
2. Flush the toilet to drain most of the water from the tank. Use a sponge or towel to remove any remaining water.
3. Disconnect the old flush valve from the toilet tank. This typically involves unscrewing a large nut from underneath the tank and detaching the refill tube and flush lever chain.
4. Clean the area where the flush valve seats to ensure a proper seal.
5. Place the new Duravit 0074030062 flush valve into the opening at the bottom of the tank, ensuring the gasket is properly seated.
6. From underneath the tank, secure the flush valve with the large mounting nut, tightening it firmly but without overtightening to avoid cracking the tank.
7. Connect the refill tube to the overflow pipe of the new flush valve.
8. Attach the flush lever chain to the flapper arm, ensuring there is a slight amount of slack (approximately 1/2 inch) when the flapper is closed. Too much tension will prevent a proper seal, and too much slack will prevent a full flush.
9. Turn the water supply back on and allow the tank to fill.
10. Check for any leaks around the base of the flush valve and the water supply connection.
11. Perform several test flushes to ensure proper operation and water level.

## 3. OPERATING INSTRUCTIONS

---

The Duravit 0074030062 Metro Flush Valve is designed for single-flush operation at 1.28 gpf. To operate, simply press or push the toilet's flush lever. This action lifts the flapper, allowing water to flow from the tank into the toilet bowl, initiating the flush cycle. Once the tank is empty, the flapper will return to its closed position, and the tank will begin to refill.

## 4. MAINTENANCE

---

Regular maintenance helps ensure the longevity and efficient operation of your flush valve.

- **Cleaning:** Periodically inspect the flapper and the flush valve seat for mineral deposits or debris. Clean with a soft brush and mild, non-abrasive cleaner if necessary. Avoid harsh chemicals that can damage rubber components.
- **Flapper Inspection:** Check the flapper for signs of wear, cracking, or stiffness. A worn flapper can lead to continuous running water. Replace the flapper if it appears damaged or is not sealing properly.
- **Chain Adjustment:** Ensure the flush chain has the correct amount of slack. Too tight, and the flapper won't seal; too loose, and it won't lift fully. Adjust as needed.

- **Leak Checks:** Regularly check for leaks around the base of the toilet and inside the tank. A small amount of food coloring in the tank can help identify slow leaks past the flapper if the color appears in the bowl without flushing.

## 5. TROUBLESHOOTING

Here are common issues and their potential solutions:

Problem	Possible Cause	Solution
Toilet runs continuously	Flapper not sealing, chain too tight, debris on valve seat.	Adjust chain slack, clean valve seat, inspect/replace flapper.
Weak or incomplete flush	Insufficient water level, flapper not opening fully, clogged siphon jet.	Adjust fill valve to increase water level, check chain for proper slack, clear siphon jet.
No flush when lever is pressed	Chain disconnected or broken, flush lever broken.	Reconnect or replace chain, replace flush lever.


## 6. SPECIFICATIONS


Attribute	Detail
Brand	Duravit
Model Number	0074030062
Part Number	0074030062
Item Weight	9.8 ounces
Package Dimensions	11.89 x 8.9 x 4.02 inches
Flush Type	Single Flush
Gallons Per Flush (gpf)	1.28 gpf
Valve Size	3 inch
ASIN	B00AYM03OC
Date First Available	January 8, 2013

## 7. WARRANTY AND SUPPORT

As an original replacement part, the Duravit 0074030062 Metro Flush Valve is manufactured to Duravit's quality standards. For specific warranty information, please refer to the warranty documentation provided with your original Duravit toilet or contact Duravit customer support directly. For technical assistance or further inquiries, please reach out to Duravit's official support channels.


## Related Documents - 0074030062

 <p>The image shows the cover of the Duravit Spare Parts Catalog. It features the Duravit logo at the top left, the text 'Spare Parts' below it, and a large blue square with the number '3' in white.</p>	<p><a href="#">Duravit Spare Parts Catalog</a></p> <p>Comprehensive catalog of Duravit spare parts for various toilet models, including troubleshooting tips and purchasing information.</p>
 <p>The image shows the technical specifications and accessories page for the Duravit Happy D.2 wall-mounted rimless toilet. It includes a technical drawing of the toilet, a table of specifications, and a list of accessories.</p>	<p><a href="#">Duravit Happy D.2 Wall-Mounted Rimless Toilet - Technical Specifications and Accessories</a></p> <p>Detailed specifications, dimensions, and accessory information for the Duravit Happy D.2 wall-mounted rimless toilet, including color options, variants, and compatible SensoWash shower-toilet seats.</p>
 <p>The image shows the installation guide for the Duravit Vero toilet seat and cover with SoftClose functionality. It includes a list of parts and a table of specifications.</p>	<p><a href="#">Duravit Vero Toilet Seat and Cover SoftClose Installation Guide</a></p> <p>Step-by-step instructions for installing the Duravit Vero toilet seat and cover with SoftClose functionality. Includes diagrams and multilingual guidance.</p>
 <p>The image shows the installation guide for the Duravit DuraStyle toilet seat and cover with soft-close functionality. It includes a list of parts and a table of specifications.</p>	<p><a href="#">Duravit DuraStyle Toilet Seat and Cover with Soft Close Installation Guide</a></p> <p>This document provides installation instructions for the Duravit DuraStyle toilet seat and cover with soft-close functionality. It includes multilingual assembly steps and diagrams.</p>
 <p>The image shows the official mounting instructions for the Duravit DuraStyle toilet seat and cover, providing step-by-step guidance for installation.</p>	<p><a href="#">Duravit DuraStyle Toilet Seat Installation Guide</a></p> <p>Official mounting instructions for the Duravit DuraStyle toilet seat and cover, providing step-by-step guidance for installation.</p>




[Duravit SensoWash C Installation and Safety Guide](#)  
 Comprehensive guide for the installation, operation, and safety of the Duravit SensoWash C shower toilet seat. Includes multilingual instructions and important safety warnings.

Documents - Duravit – 0074030062




[Duravit Spare Parts Catalog and Troubleshooting Guide](#)  
 Comprehensive parts catalog and troubleshooting guide for Duravit bathroom fixtures including toilets, bidets, urinals, washbasins, bathtubs, and furniture. Features model numbers, part details, and solutions for common issues.

lang:tl score:17 filesize: 3.48 M page\_count: 147 document date: 2011-08-26



[\[pdf\] Troubleshooting Guide Parts List Specifications](#)  
 Duravit Spare Parts List AAI S N 992144 Nathan Settembrini Specification SheetDuravit 0074135300 Replacement Flush Valve for 0157010092 Buildduravit specification sheets1 img b build mediabase specifications duravit 1178251 sheet 0074770062 sheetduravit 1659461 SheetSpecification BuildDuravit 0050401000 Drain Cover Only sheetv1s1 2612 005040 ||| Spare Parts August 2011 3 Content General Information Where to Purchase Parts ..... ravit seat used. 1 Fill valve for Metro HET 0074020062 15 2 Flush Valve 3 for Metro HET **0074030062** 15 3 Flapper 3 , white plastic 1002350000 15 4 Trip lever, chrome 1 4 SP 3\_US ...

lang:en score:16 filesize: 3.48 M page\_count: 147 document date: 2011-08-26



[Duravit Spare Parts Catalog](#)  
 Comprehensive catalog of Duravit spare parts for various toilet models, including troubleshooting tips and purchasing information.

lang:tl score:15 filesize: 3.52 M page\_count: 147 document date: 2011-08-26



### [Duravit Spare Parts Catalog and Troubleshooting Guide](#)

Comprehensive spare parts catalog for Duravit bathroom fixtures including toilets, washbasins, bidets, urinals, bathtubs, and furniture. Features model identification, part numbers, and basic toilet troubleshooting tips.

lang:tl score:15 filesize: 1.87 M page\_count: 147 document date: 2015-08-13