



Manuals.plus /

› YAMAZAKI /

› YAMAZAKI 7128 Magnetic Kitchen Paper Holder Instruction Manual

YAMAZAKI 7128

YAMAZAKI 7128 Magnetic Kitchen Paper Holder Instruction Manual

Model: 7128 | Brand: YAMAZAKI

PRODUCT OVERVIEW

The YAMAZAKI 7128 Magnetic Kitchen Paper Holder is designed for convenient storage and dispensing of kitchen paper towels. Its magnetic attachment allows for flexible placement on various metal surfaces, helping to optimize kitchen space.

SETUP AND INSTALLATION

This paper holder features a strong magnetic backing for easy attachment to metal surfaces such as refrigerators or metal cabinets. No tools or permanent fixtures are required for installation.

Placement Options:

- **Vertical Orientation:** Attach the holder vertically to a metal surface to dispense paper towels from the side.
- **Horizontal Orientation:** The holder can also be attached horizontally, allowing it to function as a towel bar for small kitchen towels.

Loading Paper Towels:

1. Ensure the holder is securely attached to a clean, dry metal surface.
2. Slide a standard-sized kitchen paper towel roll onto the bar of the holder.
3. Confirm the roll spins freely for easy dispensing.



Image: The YAMAZAKI 7128 Magnetic Kitchen Paper Holder in black, demonstrating its sleek design and magnetic attachment to a refrigerator side.

OPERATING INSTRUCTIONS

To use the paper towel holder, simply pull down on the desired amount of paper towel and tear it off against the edge of the holder. The design facilitates easy, one-handed tearing.

When used horizontally, the bar can hold small kitchen towels for quick access.

MAINTENANCE

To maintain the appearance and functionality of your paper holder:

- Wipe the holder regularly with a soft, damp cloth to remove dust and spills.
- Avoid using abrasive cleaners or scouring pads, as these can damage the powder-coated finish.
- Ensure the magnetic surface is kept clean to maintain optimal adhesion.

TROUBLESHOOTING

Holder is not staying in place:


- Ensure the surface you are attaching it to is made of a magnetic material (e.g., steel refrigerator, metal cabinet).
- Clean both the magnetic backing of the holder and the surface it is being attached to. Dirt or debris can reduce magnetic strength.

Paper towel roll does not fit or dispense smoothly:

- Verify that you are using a standard-sized kitchen paper towel roll. Oversized or unusually thick rolls may not fit or dispense correctly.
- Check for any obstructions around the roll or the holder's bar.

SPECIFICATIONS

Model Number:	7128
Brand:	YAMAZAKI
Material:	Alloy Steel (Body: Steel, powder coated), 1 magnet
Color:	Black
Mounting Type:	Magnet
Product Dimensions (L x W):	9.6 inches x 2.4 inches (Approx. 24.5 cm x 6 cm)
Item Weight:	10.6 ounces (Approx. 0.3 Kilograms)






Image: Detailed dimensions of the YAMAZAKI 7128 Magnetic Kitchen Paper Holder, indicating its length and width.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not provided within this manual. Please refer to the product packaging or the manufacturer's official website for details on warranty coverage and support contacts.