Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LiftMaster 882lm

LiftMaster 882LMW Wi-Fi Multi-Function Control Panel User Manual

Model: 882LMW | Brand: LiftMaster

Introduction

The LiftMaster 882LMW Wi-Fi Multi-Function Control Panel provides convenient and secure operation for compatible LiftMaster garage door openers. This manual outlines the features, installation, operation, and maintenance of your control panel.






Figure 1: Front view of the LiftMaster 882LMW Control Panel.

Compatibility

The LiftMaster 882LMW control panel is **ONLY** compatible with the following garage door openers:

- LiftMaster Security+ 2.0 garage door openers.
- Openers enabled by myQ technology.
- Openers featuring a round yellow learn button and two yellow antennas.

Important: This product is not battery-powered and requires a wired connection for operation.



Figure 2: Image illustrating compatibility requirements for the 882LMW control panel.

Features

- **Ultimate Security:** Equipped with Security+ 2.0 technology, ensuring a unique, encrypted code with every press for enhanced security.
- **Seamless Device Sync:** Facilitates immediate and effortless programming of Wi-Fi and myQ-enabled devices directly from the control panel.
- **Unified Access Control:** Efficiently operates a single garage door and integrates lighting control for a comprehensive garage access experience.
- **Wired Connection:** Requires a wired connection to the garage door opener for power, ensuring reliable operation.
- **Amber Indicator Light:** An amber light on the panel provides visibility in dark environments, making it easy to locate and operate.



Figure 3: The control panel offers fast, easy programming for your home security system.

Setup and Installation

Follow these steps for proper installation of your LiftMaster 882LMW control panel:

1. **Preparation:** Ensure your garage door opener is compatible (Security+ 2.0, myQ enabled, yellow learn button).
2. **Mounting Location:** Choose a convenient location inside your garage, at least 5 feet (1.5 meters) above the floor, away from moving parts of the garage door.
3. **Wiring:** Connect the wires from your garage door opener to the terminals on the back of the 882LMW control panel. Ensure connections are secure. This unit requires a wired power source and is not battery operated.
4. **Mounting:** Secure the control panel to the wall using appropriate screws.
5. **Power On:** Restore power to your garage door opener. The control panel should illuminate.



Figure 4: The control panel is designed for ultra-secure operation.

Operating Instructions

The LiftMaster 882LMW control panel offers straightforward operation:

- **Opening/Closing the Door:** Press the large main button on the front of the control panel to open or close the garage door. Pressing it again during operation will stop the door.
- **Controlling Lights:** Press the "LIGHT" button (with the light bulb icon) to manually turn the garage door opener lights on or off.
- **Programming Devices:** Lift the cover on the control panel to access the "LEARN" and "LOCK" buttons.
  - Press the **"LEARN"** button to program new remote controls or myQ-enabled accessories to your garage door opener. Refer to your garage door opener's manual for specific programming steps.
  - Press the **"LOCK"** button to disable the main door button for added security, preventing unauthorized operation from the wall panel. Press again to unlock.



Figure 5: The main button controls the garage door opener.

Maintenance

The LiftMaster 882LMW control panel requires minimal maintenance:

- Keep the control panel clean by wiping it with a soft, dry cloth.
- Ensure the wiring connections remain secure and free from damage.
- Regularly test the operation of the main door button and light button to ensure proper functionality.

Troubleshooting

If you experience issues with your LiftMaster 882LMW control panel, consider the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Control panel is not responding.	No power to the unit or loose wiring.	Check power supply to the garage door opener. Verify all wired connections are secure.
Door does not open/close from the panel.	Panel is in "LOCK" mode or opener is not compatible.	Press the "LOCK" button to disable lock mode. Confirm your garage door opener is a Security+ 2.0 myQ enabled model with a yellow learn button.
Lights do not turn on/off.	Light bulb is faulty or not installed.	Check and replace the light bulb in your garage door opener.

For further assistance, please refer to your garage door opener's main instruction manual or contact LiftMaster customer support.

Specifications

Attribute	Detail
Model Number	882LMW
Brand	LiftMaster
Installation Type	Screw-In
Recommended Uses	Controlling and managing access to garages and gates
UPC	012381118823
Product Dimensions	5.75 x 3.88 x 1.88 inches
Item Weight	1.76 ounces (0.11 Pounds)
Material	Plastic
Color	Brushed Nickel
Exterior Finish	Stainless Steel

Warranty Information

The LiftMaster 882LMW Wi-Fi Multi-Function Control Panel comes with a**1 Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the official LiftMaster website or contact customer support.



Figure 6: The product is covered by a 1-year warranty.

Customer Support

For technical support, troubleshooting, or warranty inquiries, please visit the official LiftMaster website or contact their customer service department. You can find contact information on the LiftMaster website or in the documentation provided with your garage door opener.

Visit the Official LiftMaster Store on Amazon

LiftMaster

Figure 7: LiftMaster Official Logo.

© 2023 LiftMaster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00AZL8MO0

More documents and user manuals: **https://manuals.plus/**