Sunnydaze NB-SMS202

Sunnydaze Cosmic 42-Inch Large Outdoor Fire Pit User Manual

Model: NB-SMS202

Introduction

The Sunnydaze Cosmic 42-Inch Large Outdoor Fire Pit is designed to enhance your outdoor living space, providing a central point for gatherings and warmth. This wood-burning fire pit features a spacious design, accommodating 8-10 people comfortably. Its robust construction and thoughtful design ensure both durability and safety for enjoyable outdoor fires.



Image: The Sunnydaze Cosmic 42-Inch Large Outdoor Fire Pit in use, showcasing its design and included poker tool.

Safety Information

WARNING: This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

- Always keep the fire pit away from flammable materials and structures.
- Ensure the fire pit is placed on a stable, non-combustible surface.
- Never leave a burning fire pit unattended.
- Keep children and pets at a safe distance from the fire pit.
- Use the included poker tool to safely maneuver logs and the spark screen.
- Ensure the fire is completely extinguished before leaving the area or covering the fire pit.

Components List

Before assembly, ensure all components are present and undamaged:

- Fire Pit Bowl (1)
- Legs (3)
- Outer Rim (1)
- Spark Screen (1)
- Poker Tool (1)
- Built-in Wood-Burning Grate (pre-installed)

Setup

Assembly of your Sunnydaze Cosmic Fire Pit is quick and straightforward. No special tools are required beyond what is typically found in a household.

1. Carefully unpack all components from the packaging.
2. Attach the three legs to the bottom of the fire pit bowl using the provided hardware. Ensure they are securely fastened.
3. Place the outer rim around the top edge of the fire pit bowl and secure it according to the instructions.
4. Position the fire pit on a level, non-combustible surface in your desired outdoor location, ensuring adequate clearance from any overhead structures or flammable materials.
5. The built-in wood-burning grate is pre-installed. Place the spark screen on top of the fire pit when not actively tending the fire.



Image: A diagram illustrating the key dimensions of the fire pit, useful for planning placement and understanding its size.

Operating Instructions

Your Sunnydaze Cosmic Fire Pit is designed for wood-burning fires, perfect for creating a warm and inviting atmosphere.

- **Fuel:** Use only seasoned firewood. Avoid using accelerants, charcoal, or other combustible materials not intended for wood-burning fire pits.
- **Starting the Fire:** Place kindling and smaller pieces of wood on the built-in grate. Gradually add larger logs as the fire establishes. The cutouts in the fire pit design promote improved airflow, leading to a steadier burn with less smoke.
- **Safety Features:** The fire pit includes a metal spark screen to contain flying embers and a poker tool for safely maneuvering burning logs. The outer ring provides a safe distance from the flames for those gathered around.
- **Extinguishing the Fire:** Allow the fire to burn down naturally. Do not use water to extinguish the fire as this can damage the fire pit's finish and material due to rapid temperature changes. Once the embers are cool, you can safely remove ash.



Image: Four individuals comfortably seated around the fire pit on a patio, demonstrating its capacity for social gatherings.




Image: A visual representation of how air circulates through the fire pit's design, optimizing combustion and reducing smoke.



Image: A hand demonstrating the use of the included poker tool to safely manage logs within the fire pit.

Maintenance

Proper maintenance will extend the life and appearance of your fire pit.

- **Cleaning:** After each use and once the fire pit has completely cooled, remove all ash and debris from the bowl. This prevents moisture retention and corrosion.
- **Protection from Elements:** While the fire pit is finished with high-temperature paint for heat and rust resistance, prolonged exposure to rain and snow can lead to rust. It is highly recommended to store the fire pit in a dry, covered area (such as a garage or shed) when not in use, especially during off-seasons.
- **Paint Touch-ups:** The high-temperature paint may burn off over time with use. If desired, you can repaint the fire pit with high-temperature automotive engine block paint or similar products to maintain its aesthetic.



Image: A detailed view highlighting the decorative moon and star cutouts and the robust construction of the fire pit, emphasizing its durability.

Troubleshooting

Problem	Possible Cause	Solution
Rusting appears on the fire pit.	Prolonged exposure to moisture (rain, snow).	Store the fire pit in a dry, covered area when not in use. Consider applying high-temperature rust-resistant paint for touch-ups.
Fire is difficult to start or produces excessive smoke.	Wood is wet or unseasoned; insufficient airflow; ash buildup.	Use only dry, seasoned firewood. Ensure the built-in grate is clear of ash to allow proper airflow. Arrange wood to promote air circulation.
Spark screen does not fit properly.	Improper placement or minor warping due to heat.	Ensure the spark screen is correctly aligned with the fire pit rim. Allow the screen to cool completely before attempting to adjust.

Specifications

Feature	Detail
Brand	Sunnydaze
Model Number	NB-SMS202
Material	Alloy Steel
Product Dimensions	41.5"D x 41.5"W x 23"H
Fire Bowl Diameter	41.5 inches
Fire Pit Base Diameter	34 inches
Item Weight	30 Pounds
Fuel Type	Wood
Color	Bronze
Finish Type	Painted
Shape	Round

Warranty and Support

Sunnydaze Decor stands behind the quality of its products. This fire pit is backed by a **1-year manufacturer's warranty** from the date of purchase.
For warranty claims, technical assistance, or any questions regarding your Sunnydaze Cosmic Fire Pit, please contact Sunnydaze Decor customer support directly. Please have your model number (NB-SMS202) and proof of purchase ready when contacting support.
An official User Guide in PDF format is also available for download: Download User Guide (PDF)

© 2024 Sunnydaze Decor. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question