

YA-MAN YJHB0USW

YA-MAN Spa Styler Straight + Wave User Manual

Model: YJHB0USW

INTRODUCTION

The YA-MAN Spa Styler Straight + Wave Flat Iron is a versatile 2-in-1 hair styling tool designed to straighten and wave hair with advanced Japanese technology. It features titanium tourmaline plates, Red Light Therapy, and multiple heat settings to promote hair health and achieve desired styles. This manual provides essential information for safe and effective use of your device.

SAFETY INFORMATION

Please read all safety instructions before using the appliance to reduce the risk of burns, electrocution, fire, or injury to persons.

- Do not use this appliance near water, such as bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Do not operate if the cord or plug is damaged, or if it has been dropped or damaged.
- This appliance is for household use only.
- Ensure the auto shut-off function is active for safety.

PRODUCT FEATURES

Advanced Japanese Technology

The device incorporates cutting-edge Japanese technology, prioritizing hair health while delivering efficient and effective styling results.

Moisture Pulse Technology

This feature emits millions of negative ions to seal in moisture and help reduce static frizz, resulting in smoother,

shinier hair.

ANTI-TANGLE CORD & LOCK

360° swivel cord prevents tangling, so you can easily style your hair from all angles. A locking safety latch allows for safer cooling and easy storage.



Image: Visual representation of Moisture Pulse Technology at work, showing negative ions sealing moisture into hair strands.

Red Light Therapy

Red Light + Infrared Technology assists strands in retaining interior moisture by gently heating the hair from the inside out. This makes the titanium flat iron ideal for thick hair.



Image: The red light element visible on the flat iron plate, indicating the Red Light Therapy feature.

Dual Voltage & Travel Friendly

Equipped with worldwide voltage compatibility (AC 100-240V), a locking safety latch for secure storage, and an auto shut-off function for enhanced safety, making it suitable for travel.

PRODUCT BENEFITS:



YOUR PERSONAL
STYLIST



FAST & EASY
STYLING



STRAIGHTENS
& WAVES



SMOOTHES
& SHINES



RED LIGHT
THERAPY



5 HEAT
SETTINGS

Image: Demonstrates the 360° swivel cord for anti-tangle use and the locking safety latch for storage.

Triple Heater with Tourmaline Plates

Ensures fast and even styling, providing consistent heat distribution across the plates for optimal results.

5 Heat Settings

Allows for precise temperature control to suit various hair types and styling needs.

SETUP

1. **Unpack:** Carefully remove the Spa Styler from its packaging. Retain packaging for future storage or transport.
2. **Inspect:** Check the appliance and its cord for any signs of damage. Do not use if damaged.
3. **Power Connection:** Plug the appliance into a suitable electrical outlet. The device is dual voltage (AC 100-240V) and will automatically adjust.
4. **Unlock:** If the safety latch is engaged, release it to allow the plates to open.



Image: The YA-MAN Spa Styler Straight + Wave, ready for use.

OPERATING INSTRUCTIONS

General Use

1. **Power On:** Press and hold the power button until the display illuminates.
2. **Select Temperature:** Use the temperature control buttons to select your desired heat setting. The device offers 5 heat settings. Refer to the table below for guidance.
3. **Heat Up:** Allow the styler to heat up. The triple heater ensures fast heating.
4. **Section Hair:** Divide your hair into manageable sections, typically 1-2 inches wide.
5. **Style:** Proceed with either straightening or waving techniques.
6. **Power Off:** After use, press and hold the power button to turn off the device. Unplug from the power outlet.
7. **Cool Down:** Allow the styler to cool completely before storing. Engage the safety latch for secure storage.

Temperature Guide

Hair Type	Recommended Setting
Fine, Damaged, or Chemically Treated Hair	Lower settings (e.g., 1-2)
Normal Hair	Medium settings (e.g., 3)
Thick, Coarse, or Curly Hair	Higher settings (e.g., 4-5)

Note: Always start with a lower temperature and increase if necessary to avoid heat damage.

Straightening Hair

1. Ensure hair is clean, dry, and detangled.

2. Take a small section of hair and place it between the plates, close to the roots.
3. Gently close the plates and glide the styler slowly down the hair section from root to tip.
4. Repeat on all sections until desired straightness is achieved.



Image: Demonstrating the straightening process with the YA-MAN Spa Styler.

Waving Hair

1. Ensure hair is clean, dry, and detangled.
2. Take a small section of hair. Place the styler near the roots, then rotate it 180 degrees away from your face.
3. Slowly pull the styler down the hair shaft, maintaining the rotation. The rounded plates facilitate this motion.
4. Release the hair and allow the wave to cool. Repeat on all sections.



Image: Demonstrating the waving process with the YA-MAN Spa Styler, showing how to rotate the iron for curls.

MAINTENANCE AND CARE

- **Cleaning:** Ensure the appliance is unplugged and completely cool before cleaning. Wipe the plates and exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
- **Storage:** Store the styler in a cool, dry place. Use the locking safety latch to keep the plates closed and protect them. Do not wrap the cord around the appliance, as this can damage the cord.
- **Cord Care:** Regularly inspect the power cord for any damage. If damaged, discontinue use immediately. The 360° swivel cord is designed to prevent tangling during use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet issue; Appliance malfunction.	Ensure the plug is fully inserted into a working outlet. Try a different outlet. If problem persists, contact customer support.
Appliance not heating up.	Temperature setting too low; Internal fault.	Increase the temperature setting. Allow sufficient time for heating. If still no heat, contact customer support.
Hair not styling effectively.	Incorrect temperature setting for hair type; Sections too large; Hair not clean/dry.	Adjust temperature according to hair type. Use smaller sections of hair. Ensure hair is completely dry and free of product buildup.
Red light not visible.	This feature is integrated and should activate with heat.	Ensure the device is powered on and heating. If the device heats but the light is not visible, contact customer support.

SPECIFICATIONS

- Model Number:** YJHB0USW
- Product Dimensions:** 11.4 x 1.6 x 1.6 inches
- Weight:** 2 Pounds
- Material:** Titanium
- Voltage:** AC 100-240V (Dual Voltage)
- Wattage:** 42 watts
- Manufacturer:** YA-MAN
- Country of Origin:** China
- Product Benefits:** Straightening, Curling

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official YA-MAN website. Keep your proof of purchase for any warranty claims.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is a hair styling appliance and not a dietary supplement.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00AZY1474>

More documents and user manuals: **<https://manuals.plus/>**