

[Manuals.plus](#) /

> [YA-MAN](#) /

> YA-MAN Blow Dryer with Scalp Massager Instruction Manual

YA-MAN B00AZY22CU

YA-MAN Blow Dryer with Scalp Massager Instruction Manual

Model: B00AZY22CU

[Overview](#) [Setup](#) [Introduction](#) [Safety Information](#) [Package Contents](#) [Product](#)
[Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the YA-MAN Blow Dryer with Scalp Massager. This device combines efficient hair drying with advanced scalp care features, including ionic reset technology and red light therapy. Please read this manual thoroughly before use to ensure safe and optimal performance.



Image 1.1: The YA-MAN Blow Dryer with Scalp Massager in Gold.

2. IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances. This appliance is intended for household use only.

- Do not use this appliance near water, such as in a bathtub, shower, or sink.
- Always unplug the appliance immediately after use.
- Do not use with a voltage converter.
- Keep the power cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Do not operate if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- YA-MAN Blow Dryer Main Unit
- Scalp Lift Attachment
- Air Concentrator (Diffuser)



Image 3.1: The YA-MAN Blow Dryer with its two included attachments: Air Concentrator and Scalp Lift Attachment.

4. PRODUCT OVERVIEW

The YA-MAN Blow Dryer is designed for efficient and gentle hair drying, incorporating several advanced features:

- **High-Speed Motor:** Features a 103,000 rpm motor for fast drying.
- **Quiet Operation:** Engineered for a low noise level of approximately 78 dB.
- **Ionic Reset Technology:** Helps reduce static and frizz, promoting smoother hair.
- **Red Light Therapy:** Integrated red light and infrared technology to stimulate the scalp and aid moisture retention.

- **Scalp Lift Attachment:** Delivers warm airflow and 100 vibrations per second for a relaxing scalp massage.
- **Customizable Settings:** Three speed selections and a cool shot button for varied styling needs.
- **Lightweight Design:** Weighs less than a pound for comfortable handling.



Image 4.1: Diagram illustrating key features of the YA-MAN Blow Dryer, including faster dry time, static eliminator, red light therapy, scalp massage, lightweight design, and 3 speed settings.

5. SETUP

Before first use, ensure the appliance is clean and free from any packaging materials.

1. **Attaching Accessories:** To attach the Scalp Lift Attachment or Air Concentrator, align the attachment with the nozzle of the blow dryer and gently push until it clicks into place. Ensure it is securely fastened before use.
2. **Power Connection:** Plug the power cord into a standard electrical outlet. Ensure your hands are dry when plugging in or unplugging the device.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off and Speed Control

- **Power On:** Slide the power switch to the 'On' position. The dryer will typically start on a low speed setting.
- **Adjust Speed:** Press and hold the speed selector button to cycle through the three available speed settings (Low, Medium, High). Release the button when the desired speed is reached.
- **Power Off:** Slide the power switch to the 'Off' position.

6.2 Heat Settings and Cool Shot

- **Heat On/Off:** The dryer operates with heat by default when powered on.
- **Cool Shot:** Press and hold the cool shot button to temporarily switch to cool air. Release the button to resume heated airflow. This feature helps to set your hairstyle.

6.3 Using the Scalp Lift Attachment

The Scalp Lift Attachment provides a relaxing scalp massage and promotes healthy hair.

1. Attach the Scalp Lift Attachment to the dryer nozzle.
2. Power on the dryer. The attachment will deliver warm airflow and vibrations.
3. Gently place the attachment on your scalp and move it slowly across different areas. The vibrations help to stimulate the scalp.

SCALP MASSAGER

100 Vibrations Per Second + Warm Airflow For Healthier Hair



Image 6.1: A woman demonstrating the use of the Scalp Lift Attachment for a scalp massage.

6.4 Red Light Therapy

The red light and infrared technology activate when the dryer is operating with heat. This feature works to stimulate the scalp and aid in moisture retention.

6.5 Using the Air Concentrator (Diffuser)

The Air Concentrator focuses airflow for precise styling and faster drying.

1. Attach the Air Concentrator to the dryer nozzle.
2. Direct the concentrated airflow to specific sections of your hair for targeted drying or styling.

7. MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your appliance.

- **Cleaning the Air Filter:** Periodically check the rear air inlet filter for dust and debris. Unplug the dryer and gently wipe the filter with a soft, dry cloth or use a small brush to remove accumulated particles. Do not rinse the filter with water.
- **Cleaning Attachments:** The Scalp Lift Attachment and Air Concentrator can be wiped clean with a

damp cloth. Ensure they are completely dry before reattaching or storing.

- **Storage:** Store the dryer and its attachments in a cool, dry place, away from direct sunlight and moisture. Do not wrap the power cord tightly around the appliance, as this can damage the cord.

8. TROUBLESHOOTING

If you encounter any issues with your YA-MAN Blow Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dryer does not turn on.	No power, faulty outlet, or damaged cord.	Check power connection. Try a different outlet. Inspect the power cord for damage. If damaged, discontinue use and contact support.
Low airflow or overheating.	Blocked air inlet filter.	Unplug the dryer and clean the air inlet filter as described in the Maintenance section.
Attachments do not stay on.	Improper attachment or wear.	Ensure attachments are aligned and pushed firmly until they click. If they still do not stay, contact customer support.

If the problem persists after attempting these solutions, please contact YA-MAN customer support for further assistance.

9. SPECIFICATIONS

- **Model:** B00AZY22CU
- **Brand:** YA-MAN
- **Package Dimensions:** 13.46 x 13.3 x 3.82 inches
- **Item Weight:** 3.26 Pounds
- **Manufacturer:** Ya-man
- **Hair Type Compatibility:** All, Frizzy
- **Number of Speeds:** 3
- **UPC:** 860006499877
- **Special Features:** Fast Drying, Hair Smoothing, Scalp Soothing, Ionic Reset Technology, Red Light Therapy
- **Material Type:** Metal

10. WARRANTY AND CUSTOMER SUPPORT

The YA-MAN Blow Dryer with Scalp Massager comes with a **1-year limited warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.



Image 10.1: The product packaging indicating a 1-year warranty.

For warranty service, technical support, or any questions regarding your product, please contact YA-MAN customer support through the official YA-MAN website or your retailer's support channels. Please have your model number (B00AZY22CU) and purchase date available when contacting support.