

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LEGO](#) /

› [LEGO Chima 70010 The Lion CHI Temple Instruction Manual](#)

## LEGO 70010

# LEGO Chima 70010 The Lion CHI Temple

Model: 70010 | Brand: LEGO

## INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your LEGO Chima 70010 The Lion CHI Temple building set. Please read all instructions carefully before beginning assembly to ensure correct construction and safe use. This set is designed for builders aged 8-14 years.



*Image: The complete LEGO Chima 70010 The Lion CHI Temple set, including the main temple, various vehicles, and minifigures.*

## SAFETY INFORMATION

- **Choking Hazard:** This set contains small parts and is not suitable for children under 3 years.
- **Age Recommendation:** Recommended for ages 8-14 years. Adult supervision is advised for younger builders.
- **Proper Handling:** Handle LEGO bricks and assembled models with care to prevent damage or accidental disassembly.

## PARTS LIST OVERVIEW

The LEGO Chima 70010 The Lion CHI Temple set includes numerous LEGO bricks and specialized elements. Key components include:

- Large CHI orb element
- Golden CHI elements

- Lion gate components
- Drawbridge trap mechanism
- Hidden lion claw bikes
- Eagle drone fighter
- Rotating tower cannon
- Prison cell elements
- Various minifigures: Lagravis, Laval, Longtooth, Ewald, Cragger, Crawley, and Razar
- Weapons: 4 CHI weapons and 2 standard weapons
- Crawley's reptile raider with rubber track and biting mouth

Refer to the numbered bags and the detailed instruction booklets included in your package for a complete list and visual guide to all parts.

## SETUP AND ASSEMBLY

---

Follow the step-by-step instructions provided in the physical instruction booklets. Organize your bricks by color and type before starting. The assembly process is divided into several stages, typically corresponding to numbered bags of bricks.

### Key Assembly Features:

1. **Main Temple Structure:** Begin by constructing the base of the Lion CHI Temple, ensuring all foundational elements are securely connected.
2. **Lion Gate and Drawbridge:** Assemble the functional lion gate and the integrated drawbridge trap mechanism. Test its movement to ensure smooth operation.
3. **Towers and Upper Levels:** Build the various towers, including the one housing the rotating cannon, and connect the upper platforms.
4. **Hidden Features:** Integrate the hidden lion claw bikes and the eagle drone fighter launch points as instructed.
5. **Vehicles and Minifigures:** Assemble Crawley's reptile raider and the individual minifigures with their respective weapons.



*Image: Front view of the Lion CHI Temple, highlighting the main entrance and architectural details.*

## OPERATING FEATURES

Once assembled, the Lion CHI Temple offers several interactive play features:

- **Lion Gate Mechanism:** Slam the lion gate shut to activate the drawbridge trap, designed to send minifigures plummeting into the pit below.
- **Hidden Lion Bikes:** Release the hidden lion claw bikes from their concealed compartments for quick deployment.
- **Eagle Drone Fighter:** Deploy the agile eagle drone fighter to simulate airborne assaults.
- **Rotating Tower Cannon:** Aim and fire the rotating tower cannon by pressing the designated firing mechanism.
- **Crawley's Reptile Raider:** Operate the reptile raider with its functional rubber track and biting mouth feature.

## MAINTENANCE

To ensure the longevity and playability of your LEGO set, follow these maintenance guidelines:

- **Cleaning:** Clean LEGO bricks with a mild soap solution and lukewarm water (not exceeding 40°C or 104°F). Rinse thoroughly and air dry. Do not use hot water, harsh chemicals, or abrasive materials.
- **Storage:** Store the assembled model or individual bricks in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping.
- **Disassembly:** If disassembling, carefully separate bricks to avoid damage. Keep small parts organized to prevent loss.

## TROUBLESHOOTING

If you encounter issues during assembly or play, consider the following:

- **Missing Pieces:** Double-check all packaging and surrounding areas. If a piece is genuinely missing, contact LEGO Customer Service for replacement parts.
- **Loose Connections:** Ensure all bricks are firmly pressed together. Sometimes, a loose connection can cause instability in the model.
- **Functional Mechanisms Not Working:** Review the specific assembly steps for the lion gate, drawbridge, or cannon. Ensure all gears, levers, and connecting pins are correctly installed and move freely.
- **Model Instability:** Verify that the base is correctly assembled and placed on a flat, stable surface. Reinforce any sections that frequently detach during play.

## SPECIFICATIONS

Product Dimensions	22.91 x 14.88 x 3.43 inches
Item Weight	4.88 pounds
Item Model Number	70010
Manufacturer Recommended Age	8 - 14 years
Release Date	August 1, 2013
Manufacturer	LEGO

## WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding warranty, missing parts, or further support, please visit the official LEGO website or contact LEGO Customer Service directly. Keep your purchase receipt as proof of purchase.

Online Support: [www.lego.com/service](http://www.lego.com/service)