

Lorell LLR48085

Lorell LLR48085 Essentials Computer Workstation Instruction Manual

Model: LLR48085

1. INTRODUCTION

Thank you for choosing the Lorell LLR48085 Essentials Computer Workstation. This mobile computer workstation is designed for efficiency and convenience, featuring high-quality laminate construction and a contemporary design. It includes an internal shelf for your CPU, binders, or paper, and a pullout shelf specifically designed for a keyboard. Integrated wire grommets ensure organized cable management. The workstation is equipped with four casters for easy mobility, two of which are locking for stability.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use.

- Ensure the desk is properly anchored to prevent tipping, especially when moving or adjusting.
- Use the locking casters as directed to secure the workstation in place and prevent unintended movement.
- Do not exceed the maximum weight limit of 88 pounds (40 kg) for the workstation. Distribute weight evenly.
- Keep small parts away from children during assembly to prevent choking hazards.
- Assemble on a soft, clean surface to prevent scratching the product.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.




Figure 1: Exploded view of workstation components. Refer to the included assembly instructions for a detailed parts list.

- Top Panel
- Side Panels (2)
- Back Panel
- Internal Shelf
- Keyboard Pullout Shelf
- Casters (4, two with locks)
- Hardware Pack (screws, dowels, cam locks, cam bolts, keyboard tray slides)
- Wire Grommets (3)

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires two people. A Phillips head screwdriver and a hammer (or mallet) may be needed.

1. **Prepare Components:** Unpack all parts and lay them out on a clean, soft surface to prevent damage. Identify each component using the provided parts list in your package.
2. **Attach Casters:** Secure the four casters to the bottom of the side panels. Ensure the two locking casters are placed on the front-facing side of the workstation for easy access. Use the provided screws.
3. **Assemble Side Panels and Internal Shelf:** Attach the internal shelf between the two side panels using dowels, cam bolts, and cam locks. Ensure the cam locks are fully tightened for a secure fit. The internal shelf is designed to hold a CPU or other items.
4. **Install Keyboard Tray Slides:** This step requires careful attention. The keyboard tray slides (e.g., Hettich Ball Bearing Slide KA5632 or similar) typically come as a single unit. To install, you must **separate the inner rail from the outer rail**
 - Locate the small plastic lever or tab on the side of the slide mechanism.

- Press or pull this lever while simultaneously pulling the inner rail forward until it detaches from the outer rail.
- Attach the **outer rails** to the designated slots on the workstation's side panels using the provided screws.
- Attach the **inner rails** to the sides of the keyboard pullout shelf.

Ensure both sets of rails are installed correctly and aligned.

5. **Attach Top Panel:** Place the top panel onto the assembled side panels and internal shelf. Secure it using dowels, cam bolts, and cam locks. Ensure the wire grommet holes align correctly.
6. **Install Back Panel:** Slide the back panel into the grooves on the side panels and secure it. Ensure the wire grommet hole on the back panel is correctly positioned.
7. **Insert Wire Grommets:** Place the plastic wire grommets into the pre-drilled holes on the top panel (2) and the back panel (1).
8. **Insert Keyboard Pullout Shelf:** Carefully align the inner rails on the keyboard shelf with the outer rails on the workstation. Gently push the keyboard shelf into place until it clicks, indicating the rails are engaged. Test the smooth operation of the pullout shelf.
9. **Final Check:** Verify all connections are tight and the workstation is stable. Lock the front casters to prevent movement.




Figure 2: Workstation dimensions and key features, including grommets and keyboard panel.

5. OPERATING INSTRUCTIONS

- **Mobility:** To move the workstation, unlock the two front casters by flipping their levers. Once in the desired position, lock the casters to ensure stability.
- **Keyboard Pullout Shelf:** Gently pull the shelf forward to extend it for keyboard and mouse use. Push it back until it is flush with the desk when not in use.
- **Internal Storage:** Utilize the internal shelf for storing your computer tower, binders, or other office supplies. Ensure items do not obstruct airflow if storing a CPU.
- **Cable Management:** Route power cords and data cables through the two grommets on the top surface and the one grommet on the back panel to maintain an organized workspace.




Figure 3: Front view highlighting the pullout keyboard shelf and top wire grommets.



Figure 4: Back view showing the rear wire grommet for cable management.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the laminate finish.
- **Caster Care:** Periodically check casters for debris (hair, dust) and clean as needed to ensure smooth rolling. Lubricate axles with a silicone-based spray if movement becomes stiff.
- **Hardware Check:** Every few months, inspect all screws, cam locks, and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Keyboard Tray Slides:** If the keyboard tray becomes difficult to slide, clean the rails and apply a small amount of silicone lubricant.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Workstation is wobbly or unstable.	Loose hardware; uneven floor.	Check and tighten all cam locks and screws. Ensure the workstation is on a level surface.
Keyboard tray does not slide smoothly.	Debris in slides; dry rails; incorrect installation.	Clean the slide rails. Apply a silicone lubricant. Verify the inner and outer rails are correctly engaged and installed.
Casters do not roll freely.	Debris in wheels; casters locked.	Remove any debris (e.g., hair, dust) from the wheels. Ensure the locking levers are in the unlocked position.
Parts do not fit during assembly.	Incorrect orientation; wrong parts used.	Double-check the assembly diagrams and part numbers. Ensure components are oriented correctly before forcing them.

8. SPECIFICATIONS

Feature	Detail
Brand	Lorell
Model Number	LLR48085
Product Dimensions (D x W x H)	23.63"D x 41.38"W x 29.5"H
Item Weight	88 Pounds (40 kg)
Maximum Weight Recommendation	88 Pounds (40 kg)
Material Type	Engineered Wood with Laminated Finish
Color	Mahogany
Desk Design	Computer Desk
Special Feature	Portable (with casters)
Included Components	Keyboard Tray, Internal Shelf
Required Assembly	Yes
Number of Drawers	1 (Keyboard Tray)
Number of Open Shelves	1 (Internal Shelf)

9. WARRANTY INFORMATION

The Lorell LLR48085 Essentials Computer Workstation comes with a **5-year limited warranty** from the manufacturer. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific details regarding warranty coverage and claims, refer to the official Lorell website or contact customer support.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Lorell customer support.

- **Website:** Visit the official Lorell website for FAQs and support resources.
- **Contact:** Refer to the contact section on the Lorell website for phone numbers or email support.

© 2024 Lorell. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question