

[Manuals.plus](#) /

› [Little Tikes](#) /

› Little Tikes Hide and Seek Climber Instruction Manual

## Little Tikes 630286M

# Little Tikes Hide and Seek Climber Instruction Manual

Model: 630286M | Brand: Little Tikes

## 1. PRODUCT OVERVIEW

The Little Tikes Hide and Seek Climber is a versatile play set designed for young children aged 1 to 4 years. It offers a combination of climbing, sliding, and crawling activities, suitable for both indoor and outdoor use. This lightweight yet sturdy play set is designed for easy assembly and provides a safe environment for active play.



*Image: The Little Tikes Hide and Seek Climber, showing a toddler interacting with the climbing wall and slide structure.*



*Image: A banner indicating that Little Tikes products are Made in the USA.*

## 2. SAFETY INFORMATION

- Always supervise children during play.
- Ensure the climber is placed on a soft, level surface, away from hard surfaces like concrete, to prevent injuries from falls.
- Regularly inspect all components for wear, damage, or loose parts. Tighten any loose fasteners.

- Maximum weight recommendation for the climber is 60 pounds.
- Recommended age range: 1 to 4 years.

### 3. PARTS LIST

Before assembly, ensure all parts are present. The Little Tikes Hide and Seek Climber typically includes:

- Climber base structure (main house-like sections)
- Slide component
- Climbing wall component
- Fasteners (plastic screws/knobs)

### 4. SETUP AND ASSEMBLY

The Little Tikes Hide and Seek Climber is designed for straightforward assembly. Follow these general steps:

1. Unpack all components and verify against the parts list.
2. Connect the main base sections of the climber. These typically snap together or are secured with large plastic knobs.
3. Attach the climbing wall to its designated slot on one side of the base.
4. Attach the slide component to the platform on the other side of the base. Ensure it is securely fastened.
5. Confirm all connections are tight and stable before allowing children to use the product.

The design allows for easy setup and relocation, making it convenient for moving between indoor and outdoor play areas.

Your browser does not support the video tag.

*Video: A demonstration of the Little Tikes Hide and Seek Climber, highlighting its sturdy construction and ease of movement. It shows the climbing wall and slide components.*

### 5. OPERATING INSTRUCTIONS

The Hide and Seek Climber offers multiple play features:

- **Climbing Wall:** The easy climbing rock wall is designed for beginners to develop motor skills and coordination.
- **Slide:** A gentle slope slide provides a fun and safe descent. The slide length is approximately 28.25 inches.
- **Crawl Tunnel/Hideout:** The base of the climber features an adventurous crawl tunnel and hideout area, encouraging imaginative play.
- **Clubhouse Windows:** Windows on the upper structure allow for peek-through play and interaction.



*Image: Multiple children engaging with the Little Tikes Hide and Seek Climber, showing the slide, climbing area, and upper platform.*

Your browser does not support the video tag.

*Video: A detailed look at the Little Tikes Hide and Seek Climber, showcasing its various features including the climbing wall, slide, and crawl-through tunnel, suitable for young children.*

## 6. MAINTENANCE

To ensure the longevity and safety of your Little Tikes Hide and Seek Climber:

- **Cleaning:** Wipe down the plastic surfaces with a damp cloth and mild soap as needed. Avoid harsh chemicals.
- **Inspection:** Periodically check all connections, especially the plastic knobs, to ensure they remain tight. Inspect for cracks or damage to the plastic.
- **Storage:** While durable for outdoor use, storing the climber indoors during extreme weather conditions can extend its lifespan. Its lightweight design facilitates easy movement.

## 7. TROUBLESHOOTING

If you encounter any issues with your climber:

- **Wobbling:** If the climber feels wobbly, re-check all assembly points and tighten any plastic knobs or fasteners. Ensure it is on a flat, stable surface.
- **Damaged Parts:** Do not use the product if any part is broken or damaged. Contact Little Tikes customer support for replacement parts.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Little Tikes
Model Number	630286M
Material	Plastic
Product Dimensions (L x W x H)	40.75" x 15.5" x 25"
Color	Red/Cream/Green
Maximum Weight Recommendation	60 Pounds
Item Weight	24.5 Pounds
Assembly Required	Yes
Age Range	1 - 4 years
Slide Height (ground to top)	19.75 inches
Platform Height (ground to top)	18.00 inches
Climbing Wall Height	12.50 inches
Slide Length	28.25 inches
UPC	050743630286
Manufacturer	MGA Entertainment
First Available	January 11, 2013

## 9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please visit the official Little Tikes website or contact their customer service department. Keep your purchase receipt for warranty claims. You can visit the Little Tikes Store for more products and information:[Little Tikes Store](#)

