

Technoline WT7050

Technoline WT7050 Wall Clock Instruction Manual

Model: WT7050

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Technoline WT7050 Wall Clock. The WT7050 is a quartz movement analog wall clock featuring a durable metallic frame. Please read this manual thoroughly before installation and use to ensure proper function and longevity of your device.



Image 1.1: The Technoline WT7050 Wall Clock, showcasing its round design, black metallic frame, and classic Roman numeral display on a light background.

2. SAFETY INFORMATION

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove exhausted batteries promptly to prevent leakage.
- Dispose of batteries according to local regulations.
- Ensure the clock is securely mounted to prevent falling and potential injury or damage.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.

3. PACKAGE CONTENTS

Please verify that all items are present in the package:

- 1 x Technoline WT7050 Wall Clock
- 1 x Instruction Manual (this document)

4. SETUP

4.1 Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert one (1) AA battery (not included) according to the polarity markings (+ and -) inside the compartment.
4. Close the battery compartment cover securely.

4.2 Time Setting

1. After installing the battery, locate the time setting knob on the back of the clock, usually a small wheel or dial.
2. Gently turn the knob in either direction to move the clock hands to the correct time.
3. Avoid forcing the hands directly, as this may damage the movement.

4.3 Mounting the Clock

1. Choose a suitable location on a wall that can support the clock's weight (approximately 2.86 kg).
2. Use an appropriate wall anchor and screw for your wall type (e.g., drywall, plaster, concrete).
3. Ensure the screw or hook is securely fastened into the wall.
4. Hang the clock using the hanging slot or hook located on the back of the clock, ensuring it is stable and level.

5. OPERATING THE CLOCK

Once the battery is installed and the time is set, the Technoline WT7050 Wall Clock will begin to operate automatically, displaying the current time with its analog hands. No further user interaction is required for basic timekeeping.

6. MAINTENANCE

6.1 Cleaning

- Wipe the clock's surface and frame with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the finish.

6.2 Battery Replacement

Replace the battery when the clock hands stop moving or begin to slow down significantly. Follow the battery installation steps outlined in Section 4.1.

7. TROUBLESHOOTING

- **Clock not running:** Check if the battery is inserted correctly with the correct polarity. Replace the battery with a fresh one.
- **Incorrect time:** Ensure the time was set accurately using the setting knob. If the time drifts, replace the battery.
- **Hands are stuck:** Gently check if any debris is obstructing the hands. If the issue persists after battery

replacement, the clock mechanism may require professional inspection.

8. SPECIFICATIONS

Model Number	WT7050
Brand	Technoline
Dimensions (L x W x H)	50 x 6 x 50 cm
Weight	2.86 Kilograms
Material	Metal
Display Type	Analog
Power Source	Battery-powered (1 x AA, not included)




9. WARRANTY INFORMATION

The Technoline WT7050 Wall Clock comes with a 2-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or improper installation. Please retain your proof of purchase for warranty claims.

10. SUPPORT

For further assistance, technical support, or warranty inquiries, please contact the retailer where you purchased the Technoline WT7050 Wall Clock. You may also visit the official Technoline website for additional product information or contact details.

Related Documents - WT7050

	<p>TechnoLine WT 755 Radio-controlled Analog Alarm Clock: Instruction Manual</p> <p>User guide for the TechnoLine WT 755 radio-controlled analog alarm clock. Learn how to set up, use automatic time synchronization, alarm functions, snooze, illumination, and proper battery disposal.</p>
	<p>WT 498 Radio Controlled Clock Instruction Manual</p> <p>This instruction manual provides detailed guidance on setting up, operating, and troubleshooting the WT 498 radio-controlled clock, featuring automatic time synchronization, alarm functions, and temperature display.</p>
	<p>Moon Phase Clock Instruction Manual - Radio Controlled Time, Date, Temperature</p> <p>Comprehensive instruction manual for the Moon Phase Clock, detailing setup, features, manual settings, and maintenance for the DCF-77 radio-controlled timepiece by Technoline.</p>

