

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [Onida](#) /
- > [Onida Neo LEO24NMSF100L 24-inch Full HD LED Television User Manual](#)

Onida LEO24NMSF100L

Onida Neo LEO24NMSF100L 24-inch Full HD LED Television User Manual

Model: LEO24NMSF100L

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Onida Neo LEO24NMSF100L 24-inch Full HD LED Television. Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

- Do not expose the television to rain or moisture.
- Ensure proper ventilation around the unit.
- Do not block ventilation openings with items such as newspapers, table-cloths, or curtains.
- Protect the power cord from being walked on or pinched.
- Unplug the television during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Before proceeding with the setup, please verify that all items are present in the package:

- Onida Neo LEO24NMSF100L LED Television
- Remote control
- Power cord
- User Manual (this document)
- Table stand components (if applicable)
- Screws for stand assembly (if applicable)

SETUP

1. Mounting the Television

Your Onida Neo LEO24NMSF100L television supports both table-top and wall-mount installations.

Table-Top Installation

1. Carefully place the television screen-down on a soft, flat surface to prevent damage.
2. Attach the stand base to the television using the provided screws. Ensure it is securely fastened.
3. Place the television on a stable, level surface, ensuring adequate ventilation.

Wall-Mount Installation

For wall-mounting, a compatible VESA wall-mount bracket (not included) is required. Follow the instructions provided with your wall-mount bracket. It is recommended to have this installation performed by qualified personnel.

2. Connecting External Devices

The television features multiple ports for connecting various devices.

- **HDMI Ports (2x):** Connect Blu-ray players, gaming consoles, set-top boxes, or other HDMI-enabled devices.
- **USB Ports (2x):** Connect USB storage devices for media playback.
- **Antenna/Cable Input:** Connect an antenna or cable TV signal for broadcast channels.

Ensure all connections are secure before powering on the television.

3. Power Connection

1. Connect the power cord to the AC input on the back of the television.
2. Plug the other end of the power cord into a suitable electrical outlet.

The television is designed to operate on AC power.

4. Initial Setup

Upon first power-on, the television will guide you through the initial setup process, which typically includes:

- Language selection.
- Time zone and date settings.
- Channel scanning (for antenna/cable connections).

OPERATING INSTRUCTIONS

Remote Control Overview

The included remote control allows you to operate all functions of your television. Ensure batteries are correctly inserted.



Image: Front view of the Onida Neo LEO24NMSF100L 24-inch Full HD LED Television. The screen displays a vibrant, multi-colored eye against a black and white background. The television has a black bezel with "neo" printed on the top right and "ONIDA" on the bottom center. It is mounted on a black oval stand.

Basic Operations

- **Power On/Off:** Press the **POWER** button on the remote control.
- **Channel Selection:** Use the **CH +/-** buttons to change channels sequentially, or enter channel numbers directly using the numeric keypad. The **Surf** feature allows for easy channel access.
- **Volume Control:** Adjust the volume using the **VOL +/-** buttons.
- **Input Source:** Press the **SOURCE** or **INPUT** button to select between HDMI 1, HDMI 2, USB, TV, etc.

Advanced Features

- **Media Playback (iPlayon, Dual USB):** Connect a USB drive to one of the two USB ports. Use the **iPlayon** function to browse and play media files (photos, music, videos) directly on your TV.
- **Picture Settings (SRVe, DNR):** Access the picture menu to adjust settings like brightness, contrast, color, and sharpness. The **SRVe (Super Real Visual enhancer)** image engine optimizes picture quality. **DNR (Digital Noise Reduction)** helps reduce visual noise for a clearer image.
- **Sound Settings (Surround Sound):** Adjust audio settings, including activating the **Surround Sound** mode for an immersive audio experience. The TV supports a 2.1 speaker surround sound channel configuration.
- **Picture Freeze:** Pause the live picture on screen using the **Picture Freeze** function.
- **Wakeup Timer:** Set a timer for the TV to automatically turn on at a specified time.
- **Favorite Channel Sort:** Organize your preferred channels for quick access using the **Fav channel sort** feature.
- **Operating System:** This television runs on the **Android** operating system, providing a user-friendly interface.

MAINTENANCE

Cleaning the Screen

- Turn off the television and unplug the power cord.
- Gently wipe the screen with a soft, lint-free cloth.

- For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (do not spray directly onto the screen).
- Avoid using harsh chemicals, abrasives, or alcohol-based cleaners.

Cleaning the TV Body

- Use a soft, dry cloth to wipe dust from the television's casing.
- Do not allow water or cleaning solutions to enter the ventilation openings.

TROUBLESHOOTING

If you encounter issues with your television, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cord disconnected; power outlet issue.	Ensure power cord is securely connected. Check if the power outlet is working.
No picture, but sound is present	Incorrect input source selected; faulty cable connection.	Press the SOURCE button to select the correct input. Check HDMI/AV cable connections.
No sound, but picture is present	Volume muted or too low; audio cable issue.	Press VOL + or the MUTE button. Check audio cable connections.
Remote control not working	Batteries depleted; obstruction between remote and TV.	Replace batteries. Remove any obstructions. Point remote directly at the TV's IR sensor.
Poor picture quality	Weak signal; picture settings incorrect.	Check antenna/cable connection. Adjust picture settings (brightness, contrast, sharpness, DNR).

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Onida
Model Name	Neo
Model Number	LEO24NMSF100L
Display Technology	LED
Screen Size	24 Inches
Resolution	1080p Full HD (1920 x 1080 pixels)
Aspect Ratio	16:9
Viewing Angle	178 Degrees
Image Contrast Ratio	1,000,000:1

Feature	Detail
Operating System	Android
Connectivity	2 x HDMI, 2 x USB
Audio Output Mode	Surround Sound (2.1 Channel Configuration)
Special Features	SRVe Image Engine, DNR, iPlayon, Surf, Picture Freeze, Wakeup Timer, Fav Channel Sort
Mounting Type	Wall Mount & Table Mount
Item Weight	4.2 kg
Package Dimensions	558 x 346 x 69 cm
Included Components	Remote control

WARRANTY AND SUPPORT

Warranty Information

This Onida television comes with a **1-Year Warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty.

Important Note: This product is eligible for **Refund only**. There will be no replacement or change of mind returns allowed for this product.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Onida customer support. Refer to the official Onida website or your purchase documentation for current contact details.



© 2025 Onida. All rights reserved. Information in this manual is subject to change without notice.

Related Documents - LEO24NMSF100L

	<p>Onida HD, FHD, UHD TV Instruction Manual</p> <p>Instruction manual for Onida HD, FHD, and UHD televisions, covering installation, operation, troubleshooting, and external information. Includes safety guidelines and warranty details.</p>
	<p>ONIDA F080 User Guide - Comprehensive Manual</p> <p>Detailed user guide for the ONIDA F080 mobile phone, covering setup, features, operations, safety, and maintenance. Learn how to use your ONIDA F080 effectively.</p>

	<p>Onida Semi-Automatic Washing Machine User Manual - Operation, Installation, and Maintenance</p> <p>Comprehensive user manual for Onida semi-automatic washing machines, covering installation, safety precautions, operating instructions, technical specifications, troubleshooting, maintenance, and warranty details.</p>
	<p>ONIDA Android TV Instruction Manual: Setup, Operation, and Troubleshooting</p> <p>Comprehensive instruction manual for ONIDA Android TVs, covering initial setup, remote control functions, connectivity options, smart features, troubleshooting, and warranty information.</p>
	<p>MIRC Electronics Limited: Disclosure of Non-Convertible Debenture Allotment - Tranche II</p> <p>Official disclosure from MIRC Electronics Limited (ONIDA) to stock exchanges (BSE, NSE) detailing the allotment of 3,000 Senior Secured Redeemable Non-Convertible Debentures (Tranche II) to Neo Income Plus Fund.</p>
	<p>MIRC Electronics Limited: Statutory Auditor Resignation Notification</p> <p>Official notification from MIRC Electronics Limited to BSE and NSE regarding the resignation of statutory auditors ASA & Associates LLP. Details provided as per SEBI Listing Regulations.</p>