

[Manuals.plus](#) /

- › [International Caravan](#) /
- › International Caravan Square Vented Canopy Gazebo Instruction Manual

International Caravan YF-3136B-TC-IC

International Caravan Square Vented Canopy Gazebo Instruction Manual

Model: YF-3136B-TC-IC | **Brand:** International Caravan

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the gazebo on a flat, level surface.
- Secure the gazebo to the ground using appropriate anchors (not included) through the holes in the base of the legs. This is crucial for stability, especially in windy conditions.
- Do not use the gazebo in extreme weather conditions, such as heavy winds, rain, or snow. Remove the canopy during such conditions to prevent damage.
- Keep all flame and heat sources away from the gazebo fabric.
- Adult assembly is required. Keep children away during assembly.

PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Steel Frame Components (legs, beams, connectors)
- Two-Tier Vented Canopy (Polyester fabric, Terra Cotta color)
- Hardware Pack (screws, nuts, washers, tools if provided)
- Instruction Manual

Note: Ground anchors are not included and must be purchased separately for secure installation.

SETUP INSTRUCTIONS

Assembly typically requires two adults. Allow ample time for setup. Refer to the diagram for component identification and dimensions.



Image: The International Caravan Square Vented Canopy Gazebo, showing its overall dimensions: 118 inches in length, 105 inches in width, and 118 inches in height. The gazebo features a terra cotta colored two-tier canopy and a dark-colored steel frame.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list to ensure everything is present.
2. **Assemble the Base Frame:** Connect the horizontal beams to the vertical legs to form the base structure. Ensure all connections are secure but do not fully tighten bolts until the entire frame is assembled.
3. **Install Upper Frame Components:** Attach the upper frame sections that support the canopy. This typically involves connecting corner pieces and roof support bars.
4. **Attach the Canopy:** Carefully drape the two-tier vented canopy over the assembled frame. Secure the canopy to the frame using the provided fasteners or ties. Ensure the canopy is taut and evenly distributed.
5. **Final Tightening and Securing:** Once the entire structure is assembled and the canopy is in place, fully tighten all bolts and screws. Secure the gazebo to the ground using appropriate anchors through the pre-

drilled holes in the leg bases.

OPERATING INSTRUCTIONS

The International Caravan Square Vented Canopy Gazebo is designed for outdoor use, providing shade and shelter.

- **Intended Use:** This gazebo is intended for temporary or semi-permanent outdoor shade. It is not designed as a permanent structure.
- **Canopy Ventilation:** The two-tier vented canopy design helps to reduce wind pressure and improve air circulation.
- **Weather Conditions:** Always monitor weather conditions. In anticipation of strong winds, heavy rain, or snow, remove the canopy to prevent damage to the gazebo and potential hazards.

MAINTENANCE

Regular maintenance will extend the life and appearance of your gazebo.

- **Cleaning the Canopy:** Clean the polyester canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the steel frame periodically for any signs of rust or damage. Clean the frame with a damp cloth. Touch up any scratches on the powder-coated finish to prevent rust.
- **Hardware Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten as necessary.
- **Winter Storage:** For prolonged periods of non-use or during winter months, it is recommended to disassemble the gazebo and store it in a dry, protected area to prevent weather damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Gazebo is unstable or wobbly.	Not properly anchored; bolts are loose; uneven ground.	Ensure all legs are securely anchored to the ground. Check and tighten all frame bolts. Move to a level surface if possible.
Canopy does not fit correctly.	Canopy installed incorrectly; frame not fully extended or assembled properly.	Review assembly instructions for canopy placement. Ensure the frame is fully assembled and all connections are secure.
Water pooling on canopy.	Canopy not taut enough; heavy rainfall.	Adjust canopy to ensure it is stretched tightly over the frame. Remove canopy during heavy rain.

SPECIFICATIONS

Model Number: YF-3136B-TC-IC

Brand: International Caravan

Dimensions (L x W x H): 118" x 105" x 118" (approximately 9.8 ft x 8.75 ft x 9.8 ft)

Frame Material: Powder Coated Alloy Steel

Canopy Material: UV Protected Polyester

Canopy Color: Terra Cotta

Shape: Square

Item Weight: 51 Pounds

Assembly Required: Yes

UPC: 700493383511

WARRANTY AND SUPPORT

For warranty information or assistance with your International Caravan Square Vented Canopy Gazebo, please contact the manufacturer directly. Keep your purchase receipt and model number (YF-3136B-TC-IC) handy for all inquiries.

Manufacturer: International Caravan

For further support, please refer to the contact information provided with your original purchase documentation or visit the official International Caravan website.