

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OttLite](#) /

› [OttLite W9437T-SHPR 18-watt Easy View Floor Lamp, 62" x 0" x 10.5" , Dove Grey Modern](#)

## OttLite W9437T-SHPR

# OttLite W9437T-SHPR 18-watt Easy View Floor Lamp Instruction Manual

Model: W9437T-SHPR | Brand: OttLite

## INTRODUCTION

This manual provides essential information for the safe and efficient operation, setup, and maintenance of your OttLite W9437T-SHPR 18-watt Easy View Floor Lamp. This lamp is designed to provide natural daylight illumination, reducing eyestrain and enhancing clarity for detailed tasks. Please read all instructions carefully before use.

## APPLICATIONS

The OttLite W9437T-SHPR Easy View Floor Lamp is versatile and ideal for a variety of activities requiring clear, accurate lighting and magnification:

- **Studying:** Provides bright, even light for reading and note-taking.
- **Crafting:** Enhances visibility for intricate details in hobbies like jewelry making, model building, or scrapbooking.
- **Sewing:** Illuminates stitches and fabric textures, and the magnifier assists with threading needles and fine work.
- **Reading:** Reduces eye strain and makes small print easier to read, especially for extended periods.

## This Durable Lamp is Perfect For



Studying



Crafting



Sewing



Reading

Figure 1: The OttLite lamp is perfect for various tasks including studying, crafting, sewing, and reading, providing optimal illumination.

## SETUP AND ASSEMBLY

Your OttLite Easy View Floor Lamp requires minimal assembly. Follow these steps to set up your lamp:

- 1. Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present: lamp head, flexible neck with magnifier, main pole sections, base, and 18-watt CFL bulb.
- 2. Assemble the Pole:** Connect the main pole sections by twisting them clockwise until secure.
- 3. Attach to Base:** Insert the assembled pole into the lamp base. Secure it by tightening the screw or knob located on the underside of the base, if applicable.
- 4. Attach Lamp Head and Magnifier Arm:** Connect the lamp head and the flexible magnifier arm to the main pole. Ensure they are securely fastened.
- 5. Install Bulb:** Gently insert the 18-watt CFL bulb into the lamp socket. Do not overtighten.
- 6. Position the Lamp:** Place the lamp on a flat, stable surface. Plug the power cord into a standard electrical outlet.



Figure 2: Fully assembled OttLite Easy View Floor Lamp, showing the main lamp head and the flexible magnifier arm.



**Illuminate and Magnify**  
**3x optical-grade magnifier** attachment  
brings details into full view.

Figure 3: Detailed view of the lamp head and the 3x optical-grade magnifier attachment, highlighting its clarity.



Figure 4: Illustration of the lamp's adjustable height (50.75 to 62 inches) and base dimensions (7.75 x 10.5 inches).

## OPERATING INSTRUCTIONS

Operating your OttLite Easy View Floor Lamp is straightforward:

- **Power On/Off:** Locate the push-button switch on the lamp pole. Press it once to turn the lamp on, and press it again to turn it off.
- **Adjusting Height:** The lamp's height can be adjusted from 50.75 inches to 62 inches. Loosen the height adjustment knob on the main pole, slide the upper section to the desired height, and then tighten the knob securely.
- **Positioning the Light and Magnifier:** The lamp head and the magnifier arm feature flexible necks. Gently bend and position them to direct the light and magnifier exactly where needed for your task. The magnifier extends from 16 to 22 inches.
- **Using the Magnifier:** The integrated 3x optical-grade magnifier is ideal for intricate tasks. Position it over your work area to enlarge details and reduce eyestrain.



Height adjusts from

**50.75" to 62"**

Base measures

**7.75" x 10.5"**



**Flexible neck and  
multi-position shade** direct  
light exactly where you need it.



Figure 5: The lamp's flexible neck and adjustable height feature, allowing precise positioning of light and magnification.



## Designed to Deliver Natural Daylight Indoors

- Helps reduce eyestrain
- Helps you see fine print clearly and comfortably
- Low glare

Figure 6: The lamp provides natural daylight indoors, designed to reduce eyestrain and improve clarity for reading and fine print.



Figure 7: The lamp's ability to show colors with incredible accuracy, beneficial for crafts and tasks requiring true color perception.

## MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your OttLite lamp.

- **Cleaning:** Disconnect the lamp from the power outlet before cleaning. Use a soft, dry cloth to wipe down the lamp's surfaces. Do not use abrasive cleaners or solvents, as they may damage the finish. For the magnifier lens, use a lens cleaning cloth.
- **Bulb Replacement:** The lamp uses an 18-watt CFL bulb, rated to last up to 10,000 hours. When the bulb needs replacement, ensure the lamp is unplugged and cool. Gently twist the old bulb counter-clockwise to remove it. Insert a new OttLite 18-watt Type B CFL bulb by aligning the pins and twisting clockwise until secure.



Figure 8: The included 18W Type B OttLite Bulb, designed for long-lasting performance up to 10,000 hours.

## TROUBLESHOOTING

If you encounter any issues with your OttLite lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	<ul style="list-style-type: none"> <li>Power cord not fully plugged in.</li> <li>Bulb not installed correctly or is faulty.</li> <li>Power outlet is not functioning.</li> </ul>	<ul style="list-style-type: none"> <li>Ensure the power cord is securely plugged into a working outlet.</li> <li>Check if the bulb is fully seated and tightened. Replace the bulb if necessary.</li> <li>Test the outlet with another device.</li> </ul>
Light is dim or flickers.	<ul style="list-style-type: none"> <li>Bulb is nearing end of life.</li> <li>Incorrect bulb type.</li> </ul>	<ul style="list-style-type: none"> <li>Replace the bulb with a new OttLite 18-watt Type B CFL bulb.</li> <li>Ensure you are using the correct bulb type as specified.</li> </ul>
Magnifier is blurry.	<ul style="list-style-type: none"> <li>Lens is dirty.</li> <li>Incorrect focal distance.</li> </ul>	<ul style="list-style-type: none"> <li>Clean the magnifier lens with a soft, lint-free cloth.</li> <li>Adjust the distance between the magnifier and the object until clear focus is achieved.</li> </ul>

## SPECIFICATIONS

Feature	Detail
Model Number	W9437T-SHPR
Brand	OttLite
Lamp Type	Floor Lamp
Wattage	18 watts
Light Source Type	CFL

Feature	Detail
Brightness	930 Lumen
Color Temperature	5000 Kelvin
Bulb Base	E27
Switch Type	Push Button
Material	Metal
Color	Dove Grey
Assembled Height	Adjustable from 50.75 to 62 inches
Base Dimensions	7.75 x 10.5 inches
Magnifier	3x optical-grade, 6-inch diameter, extends 16 to 22 inches
Power Source	Corded Electric
Voltage	120 Volts
Item Weight	12.45 Pounds




Figure 9: Lighting Facts for the 18-watt bulb, showing 900 lumens brightness, 5000K color temperature, and estimated yearly energy cost.

## WARRANTY INFORMATION





Specific warranty details for the OttLite W9437T-SHPR Easy View Floor Lamp are typically provided with the product packaging or on the manufacturer's official website. Please refer to the documentation included with your purchase or visit the OttLite website for the most current warranty terms and conditions.

## CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your OttLite W9437T-SHPR Easy View Floor Lamp, please contact OttLite customer service. Contact information can typically be found on the product packaging, the OttLite official website, or through your retailer.

When contacting support, please have your model number (W9437T-SHPR) and purchase date available.

## Related Documents - W9437T-SHPR

	<p><a href="#">OttLite 13W Magnifier Task Lamp: Assembly, Use, and Safety Instructions</a></p> <p>Learn how to assemble, use, and maintain your OttLite 13W Magnifier Task Lamp. This guide includes important safety instructions, tube replacement steps, and FCC compliance information for models like OTL13MAGWT and OTL13MAGTU.</p>
	<p><a href="#">OttLite Natural Daylight LED Flex Floor Lamp Assembly and Operation Manual</a></p> <p>Comprehensive instructions for assembling, operating, and safely using the OttLite Natural Daylight LED Flex Floor Lamp (models CSP9300C, CSP93G5C, CSP9300C-SHPR, CSP93G5C-SHPR). Includes safety warnings, assembly steps, operation details, and FCC compliance information.</p>
	<p><a href="#">OttLite Covington Floor Lamp Assembly and Safety Guide</a></p> <p>Detailed assembly instructions, safety warnings, and FCC compliance information for the OttLite Covington Floor Lamp (Model L1604NK9-SHPR). Learn how to assemble, install the bulb, and use the lamp safely.</p>
	<p><a href="#">OttLite 20w Marietta Floor Lamp Assembly and Safety Instructions</a></p> <p>A comprehensive guide for assembling, using, and safely operating the OttLite 20w Marietta Floor Lamp, including bulb replacement and important safety warnings. Features product registration and compatibility information.</p>
	<p><a href="#">OttLite Ultimate LED 3-in-1 Creative Station with Magnifier: Assembly &amp; Operation Guide</a></p> <p>Comprehensive guide for the OttLite Ultimate LED 3-in-1 Creative Station with Magnifier (CSY53CPC). Learn how to assemble, operate, and safely use this versatile craft lamp with magnifier.</p>
	<p><a href="#">OttLite Better Vision Pro Floor Lamp with Tablet Stand - Assembly and Usage Guide</a></p> <p>Comprehensive instructions for assembling and using the OttLite Better Vision Pro Floor Lamp with Tablet Stand (Model 8TSG54-SHPR). Includes safety warnings, lamp assembly, adjustable stand attachment, and tube replacement.</p>