

Manuals.plus /

> [ChomChom Roller](#) /

> ChomChom Roller Pet Hair Remover and Reusable Lint Roller - Cat and Dog Hair Remover for Furniture, Couch, Carpet, Clothing and Bedding - Portable, Multi-Surface Fur Removal Tool (White) User Manual

ChomChom Roller 2323445

ChomChom Roller Pet Hair Remover User Manual

Model: 2323445 | Brand: ChomChom Roller

1. INTRODUCTION

The ChomChom Roller is a highly effective and reusable tool designed for removing pet hair and lint from various surfaces. Unlike traditional sticky lint rollers, it utilizes a unique brush system to capture and collect fur into an internal chamber, making cleanup simple and eco-friendly. This manual provides detailed instructions on how to use, maintain, and troubleshoot your ChomChom Roller to ensure optimal performance.



Image: The ChomChom Roller, a white handheld device with red lint-collecting surfaces, shown effectively removing pet hair from fabric.

2. PRODUCT OVERVIEW

The ChomChom Roller consists of a durable plastic body, a comfortable handle, and an internal fur-grabbing brush system. It features a convenient hair collection chamber that can be easily opened and emptied.

Key Components:

- **Roller Head:** Contains the specialized fur-grabbing brushes.
- **Handle:** Ergonomically designed for comfortable grip and control.
- **Hair Collection Chamber:** Internal compartment where collected pet hair is stored.
- **Release Button:** Located on the handle, used to open the hair collection chamber.

WORKS ANYWHERE YOU NEED IT

Couches



Cat & Dog Beds



Cat Towers



Car Mats & Seats



Image: A detailed view of the ChomChom Roller, highlighting its fur-grabbing brush and large waste compartment, along with its dimensions (7.5 inches in length and height).

3. SETUP

The ChomChom Roller requires no assembly or batteries. It is ready for immediate use right out of the packaging.

4. OPERATING INSTRUCTIONS

Follow these steps for effective pet hair removal:

1. **Prepare the Surface:** Ensure the surface you are cleaning (furniture, clothing, carpet, bedding, car seats, etc.) is relatively flat and taut.
2. **Roll Back and Forth:** Place the roller head firmly on the surface. Roll the ChomChom Roller back and forth in short, deliberate strokes. The unique brush system will automatically pick up pet hair and lint, depositing it into the internal collection chamber.

3. **Continue Rolling:** Repeat the back-and-forth motion until the desired area is free of pet hair.

EASY-TO-USE PET HAIR REMOVER



Image: A visual guide demonstrating the three simple steps of using the ChomChom Roller: 1. Roll over hair, 2. Press button to open chamber, 3. Remove & dispose of hair.

Applications:

- Couches and Upholstery
- Cat & Dog Beds
- Clothing and Fabrics
- Car Mats & Seats
- Cat Towers

WHERE CHOMCHOM WINS



	 ChomChom ROLLER	 Others
Can use on any furniture upholstery	✓	✗
Can use on delicate clothing	✓	✗
Conveniently traps & collects hair for easy disposal	✓	✗
Large waste compartment	✓	✗

Image: The ChomChom Roller effectively removing pet hair from a blue couch, a pink pet bed, a cat tower, and a car seat, demonstrating its versatility.

5. MAINTENANCE

To maintain the effectiveness and longevity of your ChomChom Roller, follow these simple maintenance steps:

1. **Empty the Hair Chamber:** After each use, or when the chamber is full, press the release button on the handle to open the hair collection chamber. Dispose of the collected pet hair into a waste bin.
2. **Clean the Rollers:** If necessary, gently wipe the red lint-collecting surfaces with a damp cloth to remove any stubborn residue. Allow to air dry completely before closing the chamber.
3. **Storage:** Store the ChomChom Roller in a clean, dry place away from direct sunlight.

The ChomChom Roller is designed for repeated use and does not require sticky tape refills, making it a sustainable choice for pet hair removal.

6. TROUBLESHOOTING

If you encounter any issues with your ChomChom Roller, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Roller not picking up hair effectively.	Chamber is full; roller surfaces are dirty; incorrect rolling motion.	Empty the hair chamber. Clean the roller surfaces with a damp cloth. Ensure you are using a firm back-and-forth motion.
Hair getting stuck in hinges or corners.	Excessive hair accumulation; fine, fluffy fur.	Regularly empty the chamber. Carefully remove any trapped hair manually from the hinges or corners.
Chamber accidentally opens during use.	Thumb or finger pressing the release button during operation.	Adjust your grip to avoid pressing the release button while rolling.

7. SPECIFICATIONS

- Brand:** ChomChom Roller
- Model Number:** 2323445
- Material:** Plastic
- Color:** White
- Product Dimensions:** 2.5"D x 7.5"W x 7.5"H
- Handle Material:** Plastic
- Operation Mode:** Manual
- Item Weight:** 6.7 ounces
- Assembly Required:** No
- Batteries Required:** No
- Included Components:** ChomChom Roller

8. WARRANTY AND SUPPORT

Specific warranty information for the ChomChom Roller is not provided in this manual. For any warranty claims, product support, or inquiries, please contact the manufacturer directly through their official website or the retailer where the product was purchased. You can visit the [ChomChom Roller Store on Amazon](#) for more information and contact options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00BAGTNAQ>

More documents and user manuals: <https://manuals.plus/>