Beurer MG16

Beurer MG16 Handheld Mini Body Massager User Manual

Model: MG16

1. Introduction

The Beurer MG16 Handheld Mini Body Massager is designed to provide a gentle vibration massage for various body parts. Its compact and portable design allows for use at home, in the office, or while traveling. This manual provides essential information for the safe and effective operation, setup, and maintenance of your MG16 massager.



Front view of the Beurer MG16 Handheld Mini Body Massager, showcasing its compact, ergonomic design with three massage nodes and a central power button.

2. Safety Instructions

Please read these safety instructions carefully before using the device. Keep this manual for future reference.

- **Water Exposure:** Do not use the massager near water or submerge it in water. Avoid using it in damp environments such as bathrooms or showers.
- **Children:** This device is not intended for use by children. Keep out of reach of children.
- **Medical Conditions:** Consult your physician before use if you have any medical conditions, including but not limited to pregnancy, diabetes, heart conditions, or if you have a pacemaker.
- **Damaged Device:** Do not operate the device if it is damaged or malfunctioning. Contact customer

support for assistance.

- **Batteries:** Use only the specified battery type. Ensure correct polarity when inserting batteries. Do not mix old and new batteries or different types of batteries. Remove batteries if the device will not be used for an extended period.
- **Overheating:** If the device feels excessively warm, discontinue use immediately.
- **Intended Use:** Use the massager only for its intended purpose as described in this manual.

3. Product Features

The Beurer MG16 Mini Body Massager offers several features designed for user comfort and convenience:

- **Gentle Vibration Massage:** Provides a soothing massage experience.
- **LED Lighting:** Features aesthetic LED lights during operation.
- **Easy On/Off Button:** Simple single-button operation.
- **Portable and Compact Design:** Small size for easy transport and storage.
- **Ergonomic Hand Grip:** Designed for comfortable handling.
- **Targeted Pressure Point Massage:** Allows for precise application to specific areas.



The Beurer MG16 Mini Massager displayed with text overlays emphasizing its features: pressure point massage capability, comfortable hand grip, and a simple on/off button for ease of use.

4. Package Contents

Upon unpacking your Beurer MG16 Mini Body Massager, please ensure all items are present:

- 1 x Beurer MG16 Handheld Mini Body Massager
- 3 x AAA Batteries
- 1 x User Manual (this document)



An illustration showing the Beurer MG16 Mini Massager, three AAA batteries, and the user manual, representing the complete package contents.

5. Getting Started (Battery Installation)

The Beurer MG16 requires 3 AAA batteries for operation. Batteries are included with your purchase.

1. Locate the battery compartment cover, which is typically the top section of the massager.
2. Gently twist or pull the cover to open the battery compartment.
3. Insert 3 AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it is securely closed.

6. Operation

Using your Beurer MG16 Mini Body Massager is straightforward:

1. **Select Area:** Choose a muscle group or pressure point on your body that you wish to massage (e.g., back, neck, arms, legs).
2. **Apply Massager:** Gently place the massager onto the chosen area.
3. **Turn On:** Press the easy on/off button located on the top of the device to activate the vibration massage and LED lights.
4. **Massage:** Move the massager slowly and gently over the desired area. Apply light pressure as needed for comfort and relief.
5. **Turn Off:** Press the on/off button again to stop the vibration and turn off the device.



A woman gently applying the Beurer MG16 Mini Massager to her neck, demonstrating its use for targeted relief.



Images showing a woman using the Beurer MG16 Mini Massager on her arm and leg, illustrating its versatility for different body areas.

7. Care and Maintenance

- **Cleaning:** Wipe the massager with a soft, slightly damp cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace all three AAA batteries when the vibration strength weakens or the device stops functioning. Ensure proper disposal of used batteries according to local regulations.

8. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on or vibrates weakly.	Batteries are depleted or incorrectly inserted.	Check battery polarity. Replace all 3 AAA batteries with new ones.

Problem	Possible Cause	Solution
Battery compartment cover twists off during use.	Cover not securely fastened.	Ensure the cover is twisted on tightly and securely before use.
Device feels too warm.	Prolonged use.	Discontinue use immediately and allow the device to cool down.

9. Technical Specifications

- **Model:** MG16
- **Power Source:** 3 x AAA Batteries (included)
- **Material:** Plastic
- **Product Dimensions:** Approximately 4 x 4 x 4 inches (10.16 x 10.16 x 10.16 cm)
- **Item Weight:** Approximately 0.4 pounds (6.4 ounces / 181 grams)
- **Manufacturer:** Beurer
- **Date First Available:** February 5, 2013



Diagram illustrating the compact dimensions of the Beurer MG16 Mini Massager, measuring approximately 3.86 inches in both height and width.

10. Warranty Information

The Beurer MG16 Mini Body Massager comes with a limited lifetime warranty. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or contact Beurer customer support.

11. Customer Support

If you have any questions, require assistance, or need to report an issue with your Beurer MG16 Mini Body Massager, please contact Beurer customer service. Contact information can typically be found on the official Beurer website or on the product packaging.

© 2024 Beurer. All rights reserved.