

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Starfrit](#) /

› [Starfrit Digital Kitchen Scale - 5kg/11lb - Precision Baking Imperial to Metric - Measures Liquid Volume User Manual](#)

Starfrit 093756-004-COUN

Starfrit Digital Kitchen Scale User Manual

Model: 093756-004-COUN

INTRODUCTION

The Starfrit Digital Kitchen Scale is designed for precise measurement of ingredients in your kitchen. Featuring a sleek glass top weighing platform, it offers versatile functionality for both weight and liquid volume measurements. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your scale.



Image: Starfrit Digital Kitchen Scale, black circular design with a digital display, showing three tomatoes on its surface.

SETUP

Battery Installation

Your Starfrit Digital Kitchen Scale requires one CR2032 lithium battery (included). To install or replace the battery:

1. Turn the scale upside down.
2. Locate the battery compartment cover.
3. Open the cover and insert the CR2032 battery, ensuring the positive (+) side is facing upwards.
4. Close the battery compartment cover securely.



Image: Graphic displaying key features, including a battery icon indicating 1x CR2032 lithium battery is included.

OPERATING INSTRUCTIONS

Turning On/Off

- To turn on the scale, press the **ZERO** button. The display will show "0" or "0 g" when ready.
- The scale features an auto-off function that activates after approximately two minutes of inactivity to conserve battery life.
- To manually turn off the scale, press and hold the **ZERO** button for a few seconds until the display turns off.

Changing Measurement Units

The scale can measure in various units, including grams (g), pounds:ounces (lb:oz), milliliters (ml) for milk, and milliliters (ml) for water. To cycle through the units:

- Press the **MODE** button repeatedly to switch between weight (g, lb:oz) and liquid volume (ml for milk, ml for water) measurements.



Image: A visual guide illustrating the six available measurement units: grams, pounds:ounces, milliliters for milk, fluid ounces for milk, milliliters for water, and fluid ounces for water.

Tare Function (Zeroing)

The tare function allows you to weigh multiple ingredients in the same container by resetting the scale to zero after each ingredient is added. It also allows you to subtract the weight of a container.

1. Place an empty container on the scale. The display will show its weight.
2. Press the **ZERO** button. The display will reset to "0".
3. Add your first ingredient to the container. The scale will display the weight of only the ingredient.
4. To add another ingredient, press the **ZERO** button again to reset the display to "0", then add the next ingredient.

TARE FUNCTION / FONCTION TARE



①

Place a bowl on the scale
Déposer un bol sur la balance



②

**Press "ZERO" button
to remove the weight of the bowl**
Appuyer sur le bouton "ZERO"
pour retirer le poids du bol



③

Add your food
Ajouter votre nourriture

Image: A three-step visual guide demonstrating the tare function: 1) Place a bowl on the scale, 2) Press "ZERO" button to remove the weight of the bowl, 3) Add your food.

MAINTENANCE AND CARE

Cleaning

The scale features a durable black tempered glass platform, making it easy to clean. Wipe the surface with a damp cloth and mild detergent if necessary. Do not immerse the scale in water or use abrasive cleaners.



Image: A hand wiping the black glass platform of the Starfrit scale with a white cloth, demonstrating its ease of cleaning.

Storage

Its ultra-slim design allows the scale to fit perfectly in kitchen cabinets or drawers, saving counter space.

Ultra Slim!
Fits perfectly in your kitchen cabinet and drawer

Ultra mince !
Se range parfaitement dans vos armoires et vos tiroirs de cuisine



Image: The ultra-slim Starfrit scale neatly placed inside a kitchen drawer, alongside other kitchen utensils, highlighting its compact storage capability.

TROUBLESHOOTING

- **"Lo" or Low Battery Indicator:** If the display shows "Lo", it indicates that the battery is low and needs to be replaced. Refer to the "Battery Installation" section for instructions.
- **"Err" or Overload Indicator:** If the display shows "Err", the scale is overloaded. Remove items immediately to prevent damage. The maximum capacity is 11 lb / 5 kg.
- **Inaccurate Readings:** Ensure the scale is placed on a flat, stable surface. Avoid placing it near strong electromagnetic fields or extreme temperature changes. Recalibrate by turning it off and on, or by using the tare function.

SPECIFICATIONS

Brand	Starfrit
Model Number	093756-004-COUN
Capacity	11 lb / 5 kg

Accuracy	0.1 oz / 1 g
Material	Tempered Glass
Power Source	1 x CR2032 Lithium Metal Battery (included)
Dimensions	7.28" diameter x 0.6" (18.5 cm diameter x 1.5 cm)
Special Features	Low battery and overload indicators, Auto Shut Off, Automatic imperial & metric conversion, Tare Function, Measures milk and water volume.



Image: The Starfrit scale shown with its compact dimensions (7" diameter, 0.6" height) and maximum capacity (11 lb / 5 kg) clearly labeled.

IMPORTANT SAFETY INFORMATION

This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Please handle with care and follow all safety guidelines.