CalExotics SE-0004-41-2

CalExotics First Time Travel Teaser Kit: Waterproof Bullet Vibrator Instruction Manual

Model: SE-0004-41-2

Overview Setup Operation Maintenance Troubleshooting Specifications Warranty Support

1. Product Overview

The CalExotics First Time Travel Teaser Kit is a compact, waterproof bullet vibrator designed for personal use. It features powerful multi-speed vibrations and comes with four interchangeable pleasure tips to customize your experience. This manual provides instructions for safe and effective use, maintenance, and troubleshooting.

2. Setup and Battery Installation

2.1 Battery Requirements

The device requires one (1) AA battery (not included) for operation.

2.2 Installing the Battery

1. Grip the main body of the vibrator firmly.
2. Twist the bottom section of the vibrator counter-clockwise to open the battery compartment. The word "OPEN" is indicated on the casing.
3. Insert one (1) AA battery into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the device.
4. Twist the bottom section clockwise to securely close the battery compartment. Ensure it is tightly sealed to maintain waterproofing.




ON
OFF
OPEN



Figure 1: Device body showing battery compartment opening instructions.

2.3 Attaching Pleasure Tips

The kit includes four interchangeable pleasure tips. To attach a tip:

1. Select your desired pleasure tip.
2. Gently push the tip onto the top of the vibrator until it is securely seated.
3. To remove, gently pull the tip off the vibrator.






ON
OFF
OPEN


ON
OFF
OPEN





Figure 2: Examples of the vibrator with different pleasure tips attached.

3. Operating Instructions

3.1 Powering On/Off and Vibration Control

The device features a simple twist control for power and vibration intensity.

1. To turn the device ON, twist the bottom section of the vibrator clockwise past the "OFF" position towards "ON". Continue twisting to increase vibration intensity.
2. To turn the device OFF, twist the bottom section counter-clockwise until it reaches the "OFF" position.
3. The device offers powerful multi-speed vibrations, allowing you to adjust the intensity to your preference.

3.2 Waterproof Use

The CalExotics First Time Travel Teaser Kit is waterproof and can be used in and out of water. Ensure the battery compartment is securely closed before exposing the device to water.

4. Care and Maintenance

4.1 Cleaning

Proper cleaning ensures hygiene and extends the life of your device.

- Always clean the device before and after each use.
- Wash with warm water and a toy cleaner, or mild soap.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the material.

4.2 Storage

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Remove the battery if the device will not be used for an extended period to prevent battery leakage.

5. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on or vibrations are weak.	Battery is dead or incorrectly installed.	Check battery orientation. Replace with a fresh AA battery.
Pleasure tips fall off during use.	Tips may be wet or not securely attached.	Ensure tips and device are dry before attaching. Push tips firmly onto the device.
Water leakage into battery compartment.	Battery compartment not securely closed.	Ensure the bottom section is twisted tightly clockwise to seal the compartment before water exposure.

6. Product Specifications

Model Number: SE-0004-41-2

Brand: CalExotics

Style: Bullet Vibrator

Color: Pink

Power Source: 1 x AA Battery (not included)

Water Resistance: Waterproof

Product Dimensions: Approximately 2 x 5.25 x 8.5 inches (L x W x H)

Weight: Approximately 11.7 ounces

Manufacturer: California Exotic Novelties

Date First Available: February 8, 2013



Figure 3: Product packaging displaying key features and specifications.

7. Warranty Information

This CalExotics product is backed by a **one-year limited manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, alteration, or unauthorized repair. Please retain your proof of purchase for warranty claims.

8. Customer Support

For further assistance, questions, or warranty claims, please contact CalExotics customer service. Refer to the product packaging or the official CalExotics website for the most current contact information.
Note: This product is intended for adult use only.