Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-0004-65-2

CalExotics First Time Satin Teaser Multi-Speed Bullet Vibrator

Model: SE-0004-65-2

Introduction

This manual provides instructions for the safe and effective use of your CalExotics First Time Satin Teaser Multi-Speed Bullet Vibrator. Please read all instructions carefully before first use and retain this manual for future reference.

Product Overview

The CalExotics First Time Satin Teaser is a multi-speed bullet vibrator designed for external stimulation. It features a compact design with an ultra-thin controller for ease of use.

- Power-packed and multi-speed functionality.
- Ultra-thin controller for precise speed adjustments.
- Silky-smooth Satin Finish for comfortable use.
- Requires 2 AAA batteries (not included).



Figure 1: CalExotics First Time Satin Teaser Multi-Speed Bullet Vibrator.





Figure 2: Product in original packaging.

Setup

Battery Installation

1. Locate the battery compartment on the controller unit.
2. Gently open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

Note: Batteries are not included with the product. Use new, high-quality AAA batteries for optimal performance.



Figure 3: Close-up of the bullet stimulator.

Operation

To operate the vibrator, locate the dial on either side of the controller. Slide the dial from 'LOW' to 'HIGH' to turn the device on and adjust the vibration intensity. Slide the dial back to 'LOW' to turn the device off.
For enhanced comfort and experience, it is recommended to use a water-based lubricant with the product.

Video 1: Official product video demonstrating the features and operation of the CalExotics First Time Satin Teaser.

Cleaning and Maintenance

Proper cleaning and maintenance are essential for hygiene and product longevity.

1. Always clean the product before and after each use.
2. Use a toy cleaner specifically designed for intimate products, such as CalExotics Universal Toy Cleaner.
3. Spray the cleaner onto the bullet stimulator and wipe clean with a soft, lint-free cloth.
4. Do not immerse the controller unit in water.
5. Store the product in a clean, dry place away from direct sunlight and extreme temperatures.





Figure 4: Product packaging with cleaning and usage information.

Safety Information

- This product is intended for adult use only. Purchasers must be over 18 years of age.
- This product is for novelty use only. It is not intended for any medical purpose.
- Discontinue use immediately if you experience any discomfort, irritation, or adverse reaction.
- Consult a healthcare professional if you have any concerns about using this product.
- Do not use on broken or irritated skin.
- Keep out of reach of children.

Specifications

Model Number	SE-0004-65-2
Brand	CalExotics
Material	ABS Plastic, Polyurethane Coating
Color	Pink
Power Source	2 x AAA Batteries (not included)
Product Dimensions	1.25 x 5 x 8.5 inches (packaging); 2.47 ounces
Manufacturer	California Exotic Novelties

Warranty and Support

This CalExotics product is backed by a **1-year manufacturer warranty**. For warranty claims or product support, please contact California Exotic Novelties directly. Retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BD0W2O8

More documents and user manuals: **https://manuals.plus/**