

Logitech MK270

Logitech Wireless Combo MK270 Instruction Manual

Model: MK270

INTRODUCTION

This manual provides instructions for setting up, operating, and maintaining your Logitech Wireless Combo MK270 keyboard and mouse set. Please read this manual carefully before using the product.

SETUP

1. Battery Installation

The Logitech Wireless Combo MK270 requires batteries for both the keyboard and mouse. Two AAA batteries are included with the product. Install batteries into the designated compartments on the underside of both the keyboard and mouse, ensuring correct polarity (+/-).

- Locate the battery compartments on the underside of the keyboard and mouse.
- Open the compartments and insert the batteries, ensuring correct polarity (+/-).
- Close the battery compartments securely.

2. Connecting the Receiver

The MK270 combo uses a tiny Logitech nano-receiver for wireless connectivity.

1. Plug the Logitech nano-receiver into an available USB port on your computer.
2. Ensure the keyboard and mouse are powered on using their respective power switches.
3. The devices should connect automatically. No additional software is typically required for basic functionality.

Note: This combo uses 2.4 GHz wireless technology and is not Bluetooth compatible.



Image Description: A top-down view of the Logitech MK270 keyboard and mouse, with numbered labels pointing to key features. The keyboard features 8 multimedia controls, a power button, and a standard size with a numeric keypad. The mouse features an ambidextrous design, smooth cursor control, and a compact size.

OPERATING INSTRUCTIONS

Keyboard Usage

The MK270 keyboard features a full-size layout with quiet, low-profile keys, designed for comfortable typing. This specific model features an AZERTY keyboard layout, common in French-speaking regions.

- **Multimedia Hot Keys:** Eight dedicated hot keys provide instant access to functions such as movies, music, internet browser, email, volume control, and play/pause. These are typically located above the function keys (F1-F12).
- **Power Switch:** A power button is located on the keyboard, allowing you to conserve battery life when not in use.

Mouse Usage

The included mouse is portable and contoured for comfortable control, suitable for both left and right-handed users due to its ambidextrous design. It uses optical movement detection for precise tracking.

- **Power Switch:** A power switch is located on the underside of the mouse to turn it on or off.
- **Smooth Cursor Control:** The optical sensor provides fluid and responsive cursor movement.



Image Description: A top-down view of the Logitech MK270 keyboard and mouse on a light wooden desk. A hand is shown typing on the keyboard. The image highlights the wireless freedom and comfortable typing experience.



CONFORT AMBIDEXTRE COMPACT

Image Description: A close-up shot of a hand comfortably gripping the Logitech MK270 mouse. The image emphasizes the compact and ambidextrous design of the mouse.

MAINTENANCE

Battery Replacement

The keyboard offers up to 36 months of battery life, and the mouse up to 12 months. Battery life may vary based on usage and computing conditions. Replace batteries when performance degrades.

- Follow the battery installation steps outlined in the "Setup" section to replace old batteries with new ones.
- Dispose of used batteries responsibly according to local regulations.

Cleaning

The keyboard is designed to be splash-resistant, meaning it can withstand minor spills. However, it is not waterproof and should not be submerged in liquid.

- To clean the keyboard and mouse, use a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners.
- For spills, immediately power off the device, disconnect it, and gently wipe away the liquid. Allow to air dry completely before re-use.



(2) Testé dans des conditions limitées (épanchement maximum de 60 ml de liquide). Ne pas plonger dans un liquide.



**CLAVIER RÉSISTANT
AUX ÉCLABOUSSURES (2)
TOUCHES PROFILÉES PROFONDES**

Image Description: A close-up view of the Logitech MK270 keyboard with several water droplets on its surface, illustrating its splash-resistant design. A note indicates it was tested under limited conditions (maximum spill of 60 ml of liquid) and should not be immersed.



Image Description: The Logitech MK270 keyboard and mouse are shown side-by-side. Icons above the mouse indicate 12 months of battery life, and above the keyboard, 36 months of battery life, highlighting the durable design and long-lasting power.

TROUBLESHOOTING

Connection Issues

- **No Response:** Ensure both the keyboard and mouse are powered on and that the nano-receiver is securely plugged into a working USB port on your computer.
- **Intermittent Connection:** Try plugging the nano-receiver into a different USB port, preferably one closer to the keyboard and mouse. Avoid placing the receiver near other wireless devices or large metal objects that might cause interference.
- **Battery Check:** If devices are unresponsive, replace the batteries in both the keyboard and mouse.
- **Compatibility:** The Logitech Wireless Combo MK270 is compatible with Windows 10 or later, Windows 8, 7, Windows Vista, Windows XP, and Chrome OS. It is **not** Bluetooth compatible. Ensure your operating system is supported.

Cursor Movement Issues (Mouse)

- **Erratic Movement:** Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface; highly reflective or transparent surfaces may affect tracking.
- **No Movement:** Check the mouse's power switch and battery level.

SPECIFICATIONS

Brand	Logitech
Model	MK270
Color	Black
Connectivity Technology	Radio Frequency (2.4 GHz)
Special Feature	Wireless
Compatible Devices	Personal Computer
Movement Detection	Optical
Operating System	Windows, macOS (Windows 10 or later, Windows 8, 7, Windows Vista, Windows XP, Chrome OS)
Hand Orientation (Mouse)	Ambidextrous
Batteries Required	Yes (2 AAA batteries included)
Number of Keys (Keyboard)	111
Power Source	Battery Powered
Keyboard Layout	AZERTY
Item Weight	481 Grams

WARRANTY AND SUPPORT

For detailed warranty information and technical support, please visit the official Logitech website or contact Logitech customer service. Keep your purchase receipt as proof of purchase.

Logitech Support Website: www.logitech.com/support

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question