Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bene Casa BC-58021

Bene Casa BC-58021 Manual Water Pump

Instruction Manual

Introduction

The Bene Casa BC-58021 Manual Water Pump is designed for convenient dispensing of potable water from standard 5-6 gallon water jugs. This portable pump operates using an innovative vacuum action, requiring no batteries or electricity, making it suitable for both indoor and outdoor use. Its simple design ensures quick water delivery in seconds.

Safety Information

- Read all instructions thoroughly before operating the pump.
- This pump is intended for use with potable (drinking) water only. Do not use with other liquids.
- Keep the pump and its components out of reach of children when not in use.
- Ensure all connections are secure to prevent leaks and maintain proper vacuum.
- Do not attempt to disassemble the pump beyond what is necessary for cleaning or maintenance.

Package Contents

Please verify that all components are present in the package:

- 1 x Manual Pump Unit
- 1 x Suction Tube (multi-piece for adjustable length)
- 1 x Spout

Setup Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Suction Tube:** Connect the sections of the suction tube together to achieve the desired length for your 5 or 6-gallon water jug. Ensure connections are firm.
3. **Attach Suction Tube to Pump:** Insert the assembled suction tube firmly into the bottom opening of the main pump unit.
4. **Attach Spout:** Securely attach the spout to the designated opening on the pump unit.
5. **Install on Water Jug:** Place the assembled pump unit onto the neck of a standard 5 or 6-gallon water jug. Press down firmly to create a tight seal between the pump and the jug opening. A good seal is crucial for proper operation.



Image: The Bene Casa BC-58021 Manual Water Pump fully assembled and placed on a water jug, ready for use.

Operating Instructions

1. **Position Container:** Place a cup, glass, or other container directly under the pump's spout.
2. **Pump Water:** Press the pump head down repeatedly and steadily. The innovative vacuum action will draw water up through the suction tube and out of the spout.
3. **Stop Flow:** Release the pump head to stop the flow of water.

Maintenance

- **Regular Cleaning:** To ensure hygiene and optimal performance, clean the pump regularly. Disassemble the spout and suction tube from the main pump unit.
- **Washing:** Wash all components with mild soap and warm water. Use a brush if necessary to clean inside the tubes and spout.
- **Rinsing:** Rinse all parts thoroughly with clean water to remove any soap residue.
- **Drying:** Allow all components to air dry completely before reassembling or storing the pump.
- **Storage:** Store the pump in a clean, dry place away from direct sunlight when not in use.

Troubleshooting

Problem	Possible Cause	Solution
No water flow or very slow flow	• Loose connection or poor seal on the jug. • Suction tube not fully submerged in water. • Blockage in the suction tube or spout. • Water jug is empty.	• Ensure the pump is pressed firmly onto the jug to create a tight vacuum seal. • Check that the suction tube reaches the bottom of the water jug. • Disassemble and clean the suction tube and spout to remove any obstructions. • Replace the empty water jug with a full one.
Suction tube detaches frequently	• Tube sections not securely connected. • Vibration during pumping.	• Ensure all sections of the suction tube are firmly twisted or pushed together until they click or feel secure. • Periodically check connections during use.
Water leaks from pump base	• Poor seal between pump and jug. • Crack in pump housing.	• Re-seat the pump firmly onto the jug. • Inspect the pump for any visible damage. If damaged, discontinue use.

Specifications

- **Model:** BC-58021
- **Material:** Plastic
- **Capacity:** Designed for standard 5-6 Gallon Water Jugs
- **Color:** White and Blue

- **Operation:** Manual, Vacuum Action
- **Power:** No batteries or electricity required
- **Manufacturer:** MBR INDUSTRIES
- **GTIN:** 50037005580218

Warranty and Support

For specific warranty information, product support, or to inquire about replacement parts, please contact the manufacturer, MBR INDUSTRIES, or your original retailer. Please have your model number (BC-58021) and proof of purchase available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00BF84EF8

More documents and user manuals: **https://manuals.plus/**