

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Samsung](#) /
- › [Samsung BD-F7500 4K Upscaling 3D Wi-Fi Blu-ray Disc Player User Manual](#)

## Samsung BD-F7500

# Samsung BD-F7500 4K Upscaling 3D Wi-Fi Blu-ray Disc Player

Model: BD-F7500

## INTRODUCTION

---

The Samsung BD-F7500 is a versatile Blu-ray Disc Player designed to enhance your home entertainment experience. It supports Full HD 1080p Blu-ray Disc playback with advanced 4K upscaling capabilities, allowing for a sharper and more detailed picture on compatible 4K displays. This player also features 3D Blu-ray Disc playback for immersive viewing. With built-in Wi-Fi and Smart Hub, you can access a wide range of streaming content and web services directly from your device. Its compact design ensures it fits seamlessly into any setup.




Image: Front view of the Samsung BD-F7500 Blu-ray Disc Player, showcasing its sleek, dark design.

## SETUP

---

### 1. Unpacking and Placement

- Carefully remove the Blu-ray Disc Player and all accessories from the packaging.
- Place the player on a stable, level surface with adequate ventilation. Avoid placing it near heat sources or in direct sunlight.

### 2. Connecting to Your TV

- Connect one end of an HDMI cable (not included) to the **HDMI OUT** port on the back of the Blu-ray Disc Player.
- Connect the other end of the HDMI cable to an available **HDMI IN** port on your television. Note the HDMI input number on your TV for later selection.

### 3. Connecting to the Network

The BD-F7500 supports both wired and wireless network connections.

- **Wireless (Wi-Fi):** The player has built-in Wi-Fi (802.11 a/b/g/n). During initial setup, you will be prompted to select your Wi-Fi network and enter the password.
- **Wired (LAN):** Connect an Ethernet cable (not included) from your router or modem to the **LAN (100)** port on the back of the player.

## 4. Power Connection

- Connect the power cord to the player's power input and then plug it into a wall outlet.

## 5. Initial Setup

- Turn on your TV and select the correct HDMI input.
- Press the **Power** button on the player or remote control.
- Follow the on-screen instructions to complete the initial setup, including language selection, network configuration, and time zone settings.

# OPERATING THE PLAYER

---

## 1. Disc Playback

- Press the **Eject** button (triangle with line underneath) on the player or remote control to open the disc tray.
- Place a Blu-ray Disc, DVD, or CD onto the disc tray with the label side facing up.
- Press the **Eject** button again to close the tray. The player will automatically begin playback or display a menu.
- Supported disc types include: Blu-ray (BD-ROM, BD-3D, BD-R, BD-RE), DVD (DVD-R, DVD-RW, DVD+R, DVD+RW), and CD (CD-Audio, CD-R, CD-RW).

## 2. Smart Hub and Streaming Services

The Smart Hub provides access to various streaming applications and web content.

- Press the **Smart Hub** button on your remote control to access the Smart Hub interface.
- Navigate through the available applications such as Netflix, Vudu, HuluPlus, Amazon Instant Video, YouTube, and more.
- Use the remote's directional buttons to select and launch applications.

## 3. Media Playback via USB or DLNA

- **USB:** Insert a USB storage device into the USB 2.0 port on the front of the player. The player supports various video, audio, and picture file formats.
- **DLNA:** The player is DLNA Certified, allowing you to stream audio, video, and photo content from compatible networked devices (e.g., computers, NAS drives) on your home network.

## 4. Screen Mirroring

Mirror the screen of your compatible mobile device directly to your TV via the Blu-ray player.

- Access the Screen Mirroring function from the player's menu.
- Follow the on-screen instructions and your mobile device's mirroring settings to establish a connection.

# MAINTENANCE

---

## 1. Cleaning the Player

- Wipe the exterior of the player with a soft, dry cloth. Do not use liquid or aerosol cleaners.
- For disc cleaning, use a soft, lint-free cloth and wipe from the center outwards.

## 2. Firmware Updates

- Periodically check for software updates to ensure optimal performance and access to the latest features. Updates can typically be performed via the Network Settings menu.

## TROUBLESHOOTING

---

### No Power

- Ensure the power cord is securely connected to both the player and a working electrical outlet.
- Try plugging another device into the same outlet to confirm it has power.

### No Picture/Sound

- Verify that the HDMI cable is correctly connected to both the player and the TV.
- Ensure your TV is set to the correct HDMI input source.
- Check the audio settings on both the player and your TV/audio receiver.

### Network Connection Issues

- For Wi-Fi, ensure the correct network and password are entered in the player's network settings.
- For wired connections, verify the Ethernet cable is properly connected.
- Restart your router/modem and the Blu-ray player.
- Check for any available firmware updates for the player, as these can sometimes resolve connectivity issues.

### Disc Not Playing

- Ensure the disc is clean and free of scratches or smudges.
- Verify the disc type is supported by the player (Blu-ray, DVD, CD).
- Check if the disc is inserted correctly with the label side facing up.

### Remote Control Not Working

- Replace the batteries (requires 2 AA batteries).
- Ensure there are no obstructions between the remote and the player's sensor.

## SPECIFICATIONS

---

Feature	Description
Model Number	BD-F7500
Dimensions (WxDxH)	16.9 x 7.9 x 1.8 inches
Weight	2 pounds (3.74 lbs listed in detailed specs)
Processing	900Mhz Dual-Core Processor
Disc Types Supported	Blu-ray (BD-ROM, BD-3D, BD-R, BD-RE), DVD (DVD-R, DVD-RW, DVD+R, DVD+RW), CD (CD-Audio, CD-R, CD-RW)
Video Resolution	Full HD 1080p, 4K Upscaling (2D 2160p, 1080p, 1080i, 720p, 480p; 3D 1080p, 720p)

Connectivity	HDMI (2 ports), USB 2.0 (1 port), LAN (Ethernet 100BT), Wi-Fi (802.11 a/b/g/n), Digital Optical Out
Audio Output Mode	Surround (PCM, Bitstream)
Surround Sound Decoding	Dolby Digital, Dolby Digital Plus, Dolby TrueHD, DTS, DTS-HD HRA, DTS-HD Master Audio (up to 7.1ch)
Networked Services	Netflix 5.1, Vudu, HuluPlus, Amazon Instant Video, YouTube, and more via Smart Hub
Special Features	3D Playback, 4K Upscaling, Smart Hub, Built-in Wi-Fi, DLNA Certified, Screen Mirroring, CD Ripping, BD Wise, Bonus View, BD-Live, Anynet+, Wireless Keyboard/Mouse Compatible, Parental Lock, Wi-Fi Direct
Power Consumption	AC110-120V 50/60Hz, 22W
Operating Temperature	41°F to 95°F (5°C to 35°C)
Operating Humidity	10% to 75%

## WARRANTY AND SUPPORT

---

For warranty information, please refer to the warranty card included with your product or visit the official Samsung website. Specific warranty terms may vary by region and purchase date.

For technical support, product registration, or service inquiries, please contact Samsung Customer Service or visit their support website. Have your model number (BD-F7500) and serial number ready when contacting support.