Master Airbrush MAS S622-SET-HB

Master Airbrush S622-SET Instruction Manual

Model: MAS S622-SET-HB

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Master Airbrush S622-SET Master S62 All-Purpose Precision Dual-Action Siphon Feed Airbrush Pro Set. This airbrush is designed for a wide range of applications, from fine detail work to broader spray patterns, accommodating low to high fluid viscosities.



Figure 1: Complete Master Airbrush S622-SET kit including airbrush, hose, and accessories.

2. Safety Information

Adhering to safety guidelines is crucial for safe and effective operation. Please read and understand all safety information before using the airbrush.

- **WARNING:** Always use this airbrush within the recommended working pressure range (15-50 PSI). Never exceed the maximum pressure to prevent injury or damage.
- Always follow material safety guidelines when using paints and other substances.
- Keep the airbrush and its contents away from heat sources and open flames.
- Dispose of materials and the airbrush in accordance with local, state, and federal regulations.
- Always wear appropriate personal protective equipment (PPE) when using this airbrush, including eye protection and a respirator if working with hazardous materials.

3. What's in the Box

Your Master Airbrush S622-SET package should contain the following items:

- Master S62 Dual-Action Siphon Feed Airbrush
- 0.3mm Nozzle Set (Needle, Nozzle, Air Cap)
- 0.5mm Nozzle Set (Needle, Nozzle, Air Cap)
- 0.8mm Nozzle Set (Needle, Nozzle, Air Cap)
- 3/4 Ounce Siphon Feed Fluid Bottle
- 6' Braided Air Hose with 1/8" connections
- Instruction Guide (this manual)
- Gun Lubricant
- Measuring Cap
- Nozzle Adapter
- Shoulder Strap
- Strainer
- Replacement Seal
- Cleaning Kit
- Storage Case for Airbrush and Accessories

4. Product Components and Features

Familiarize yourself with the various parts of your Master S62 Airbrush for optimal use and maintenance.



Figure 2: Key components of the Master S62 Airbrush, including the ergonomic trigger, preset fluid control knob, quick flush cutaway handle, and 3/4 ounce siphon feed fluid bottle.



Figure 3: Exploded view showing all individual parts of the Master S62 Airbrush and the three included nozzle sets (0.3mm, 0.5mm, 0.8mm) with corresponding needles.

Nozzle Sets

The S622-SET includes three self-centering drop-in nozzle sets for high fluid flow, allowing for versatility in your projects:

- **0.3mm:** Ideal for fine detail lines and intricate work.
- **0.5mm:** A versatile size for general purpose spraying and medium detail.
- **0.8mm:** Best for broader coverage, background work, and higher viscosity materials.

5. Setup

Follow these steps to prepare your airbrush for use:

1. **Attach Air Hose:** Connect the 6-foot braided air hose to the airbrush's air inlet and to your air compressor. Ensure connections are secure to prevent air leaks.
2. **Select Nozzle Set:** Choose the appropriate nozzle, needle, and air cap set (0.3mm, 0.5mm, or 0.8mm) for your

desired spray pattern and material viscosity. Install it carefully according to the exploded view diagram (Figure 3).

3. **Prepare Fluid Bottle:** Fill the 3/4 ounce siphon feed fluid bottle with your prepared paint or medium. Ensure the paint is thinned to the appropriate consistency for airbrushing.
4. **Attach Fluid Bottle:** Securely attach the filled fluid bottle to the airbrush's siphon connection.
5. **Connect to Power:** Turn on your air compressor and set the pressure within the recommended range of 15-50 PSI.

6. Operating Instructions

The Master S62 is a dual-action airbrush, meaning the trigger controls both air and fluid flow independently.

Basic Operation

1. **Air First:** Press the trigger down to release air.
2. **Fluid Second:** Pull the trigger back to control the amount of fluid released. The further back you pull, the more fluid will spray.
3. **Release Fluid First:** When finishing a stroke, release the trigger forward to stop fluid flow.
4. **Release Air Second:** Then release the trigger up to stop air flow.

Spray Patterns and Applications

This airbrush is capable of producing fine detail lines up to 2 inches wide, making it suitable for various artistic and practical applications.



Figure 4: Examples of spray patterns achievable with the Master S62 airbrush, demonstrating its versatility from fine lines to broader coverage.



Figure 5: Visual examples of common applications for this airbrush, including automotive graphics, cake decorating, illustration, and makeup/cosmetics.



Figure 6: Proper grip and usage of the Master S62 Airbrush during a painting session.

7. Maintenance

Proper cleaning and maintenance are essential for the longevity and performance of your airbrush.

After Each Use (Quick Clean)

1. Empty any remaining paint from the fluid bottle.
2. Rinse the fluid bottle with appropriate cleaner (water for water-based paints, solvent for solvent-based paints).
3. Fill the bottle with cleaner and spray through the airbrush until the spray runs clear.
4. Use a soft brush from the cleaning kit to clean the inside of the fluid bottle and the siphon tube.

Periodic Deep Cleaning

For thorough cleaning or if paint has dried in the airbrush:

1. Disassemble the airbrush carefully, referring to Figure 3.
2. Clean all components (needle, nozzle, air cap, fluid tip, body) with the appropriate cleaning solution and brushes.
3. Pay special attention to the nozzle and needle, ensuring no paint residue remains.
4. Inspect O-rings and seals for wear or damage. Replace if necessary using the provided replacement seal.
5. Apply a small amount of gun lubricant to moving parts, such as the trigger mechanism and needle packing, before reassembly.
6. Reassemble the airbrush, ensuring all parts are correctly seated and tightened.

8. Troubleshooting

If you encounter issues with your airbrush, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
No Air Flow	Air hose disconnected, compressor off, trigger not fully depressed, air valve issue.	Check hose connections, turn on compressor, ensure full trigger depression, inspect air valve for obstructions.
No Fluid Flow / Sputtering	Clogged nozzle/needle, paint too thick, insufficient air pressure, siphon tube blockage, loose fluid bottle.	Clean nozzle/needle, thin paint, increase air pressure (within limits), clear siphon tube, tighten fluid bottle.
Inconsistent Spray Pattern	Partially clogged nozzle, bent needle tip, damaged air cap, uneven paint consistency.	Perform deep clean, inspect needle/air cap for damage, ensure paint is well-mixed and thinned.
Air Bubbles in Fluid Bottle	Loose nozzle, damaged nozzle, clogged air cap.	Tighten nozzle, inspect/replace nozzle, clean air cap.
Trigger Sticking	Dried paint in trigger mechanism, lack of lubrication.	Disassemble and clean trigger area, apply gun lubricant.

9. Specifications

Feature	Detail
Brand	Master Airbrush
Model Number	MAS S622-SET-HB
Type	Dual-Action Siphon Feed Airbrush
Nozzle Sizes Included	0.3mm, 0.5mm, 0.8mm (Self-Centering Drop-in Nozzles)
Fluid Bottle Capacity	0.75 Fluid Ounces (approx. 22 ml)

Feature	Detail
Material	Metal
Power Source	Air Powered
Maximum Recommended Pressure	50 PSI (Pound per Square Inch)
Product Dimensions	9.2 x 6.7 x 3.1 inches
Item Weight	14.6 ounces

10. Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please contact Master Airbrush directly or visit their official website. Keep your purchase receipt as proof of purchase for any warranty claims.
You can find more information and resources at the Master Airbrush Store on Amazon.

© 2024 Master Airbrush. All rights reserved.