

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Keter](#) /

› [Keter Easy Grow 31.7 Gallon Rectangular Plastic Indoor Planter User Manual](#)

Keter 212157

Keter Easy Grow 31.7 Gallon Rectangular Plastic Indoor Planter User Manual

Model: 212157

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Keter Easy Grow 31.7 Gallon Rectangular Plastic Indoor Planter. Designed for convenience and efficiency, this planter features a self-watering system to support healthy plant growth. Please read these instructions carefully before use to ensure proper setup and longevity of your product.

2. PRODUCT FEATURES

- **Material:** Durable Plastic
- **Color:** Brown
- **Capacity:** 31.7 Gallons
- **Dimensions (D x W x H):** 19.4 inches x 44.9 inches x 29.8 inches
- **Weight:** 18.5 Pounds
- **Special Features:** Integrated drainage hole, self-watering system with water tank and drainage system.
- **Usage:** Suitable for indoor and outdoor use.
- **Design:** Rectangular box form with a stylish Easy Grow design.



Image: Keter Easy Grow Planter with labeled dimensions for height, width, and length.

3. SETUP AND ASSEMBLY

The Keter Easy Grow Planter is designed for straightforward assembly. Follow the steps below to set up your planter.

3.1 Package Contents

Before assembly, ensure all components are present:

- Planter body panels
- Legs
- Water tank/drainage system components
- Water level indicator

3.2 Assembly Steps

1. Connect the side panels of the planter body.
2. Attach the legs to the base of the planter. Ensure they are securely fastened.
3. Insert the water tank/drainage system into the bottom of the planter.
4. Install the water level indicator into its designated slot.

For a visual guide, please refer to the product video below, which demonstrates the assembly process and key

features.

Video: This video demonstrates the assembly of the Keter Raised Garden Planter, including connecting panels, attaching legs, and installing the self-watering system components.

4. OPERATING INSTRUCTIONS

4.1 Planting

Fill the planter with appropriate potting soil, leaving some space from the top rim. Plant your desired flowers, herbs, or vegetables. The self-watering system is designed to provide consistent moisture to the roots.



Image: A person planting in the Keter Easy Grow Planter.

4.2 Watering

Water your plants by pouring water directly into the soil or through the designated spout. The integrated water level indicator will rise as the water reservoir fills, helping you monitor the water level. The system ensures that roots receive water from below, promoting deeper root growth and reducing the frequency of watering.

4.3 Drainage

The planter includes a drainage hole to prevent overwatering. If the water level becomes too high, excess water will drain out. For outdoor use, you may choose to remove the plug to allow continuous drainage. For indoor

use, ensure a drip tray is placed underneath if the drainage plug is removed, or keep the plug in place and monitor the water level indicator to avoid overfilling.

5. MAINTENANCE

- **Cleaning:** Clean the planter periodically with mild soap and water. Avoid abrasive cleaners that may damage the plastic.
- **Winter Storage:** If using outdoors in freezing climates, it is recommended to empty the planter of soil and water and store it in a sheltered area to prevent potential damage from ice expansion.
- **Soil Replacement:** Replace or refresh the potting soil annually to ensure optimal nutrient levels for your plants.

6. TROUBLESHOOTING

6.1 Water Leaking

If you observe water leaking from areas other than the designated drainage hole, inspect the assembly points. Ensure all panels are securely connected and the water tank is properly seated. Check for any cracks or damage to the plastic components. If damage is found, contact customer support for assistance.

6.2 Plants Not Thriving

Ensure your plants are receiving adequate sunlight for their specific needs. Check the water level indicator to confirm the self-watering system is functioning and the reservoir is not empty. Verify that the soil is appropriate for the plants and consider adding fertilizer if necessary.

7. SPECIFICATIONS

Feature	Detail
Brand	Keter
Model Number	212157
Material	Plastic
Color	Brown
Shape	Rectangular
Capacity	31.7 Gallons
Item Dimensions (D x W x H)	19.4" x 44.9" x 29.8"
Item Weight	18.5 Pounds
Special Feature	Drainage Hole, Self-watering system

Included Components	Water Tank, Drainage System
Indoor/Outdoor Usage	Indoor
UPC	731161034206

8. WARRANTY AND SUPPORT

The Keter Easy Grow Planter comes with a **2-year manufacturer's warranty** covering defects. For warranty claims, product support, or any questions regarding your planter, please contact Keter customer service. Keep your proof of purchase for warranty validation.