

**Miele 09338540/4**

# Miele Style U Vacuum Bags & Filters Instruction Manual

For use with compatible Miele Vacuum Cleaners

[Instructions](#)   [Introduction](#)   [Maintenance](#)   [Setup & Installation](#)   [Operating](#)  
[Troubleshooting](#)   [Specifications](#)   [Support](#)

## 1. INTRODUCTION

This manual provides essential information for the proper use and replacement of Miele Style U Vacuum Bags and accompanying filters. These high-quality bags and filters are designed to maintain the optimal performance and filtration efficiency of your compatible Miele vacuum cleaner. Regular replacement ensures effective dust retention and prolongs the life of your appliance.



Figure 1: Miele Style U AirClean Vacuum Bags. This image displays four individual boxes of Miele Style U AirClean vacuum bags. Each box features the 'U AirClean' branding and indicates 'NEU - NEW - NOUVEAU' and 'ORIGINAL Miele'. A folded white vacuum

bag with a distinctive green plastic collar and fitting is visible through a clear window on each box. The green fitting has arrows indicating insertion direction. The Miele logo is prominently displayed at the bottom of each box.

## 2. SETUP & INSTALLATION

---

Proper installation of the vacuum bag and filters is crucial for effective operation and to prevent damage to your vacuum cleaner. Always ensure the vacuum cleaner is unplugged from the power outlet before performing any installation or maintenance.

### 2.1 Replacing the Vacuum Bag

1. **Preparation:** Unplug the vacuum cleaner from the wall socket. Open the dust compartment lid of your Miele vacuum cleaner.
2. **Remove Old Bag:** Carefully pull the full vacuum bag upwards by its collar. The bag's self-closing flap will automatically seal the opening, preventing dust from escaping. Dispose of the full bag responsibly.
3. **Insert New Bag:** Unfold a new Miele Style U vacuum bag. Slide the green collar of the new bag into the bag holder until it clicks securely into place. Ensure the bag is fully seated and flat within the dust compartment.
4. **Close Compartment:** Close the dust compartment lid firmly until it latches.

### 2.2 Replacing the Filters

Your Miele vacuum cleaner typically uses two types of filters that should be replaced periodically: the Motor Protection Filter and the Exhaust Filter.

#### 2.2.1 Motor Protection Filter

- This filter is usually located behind the vacuum bag.
- Lift the vacuum bag out of its holder.
- Remove the old motor protection filter and insert a new one, ensuring it lies flat and covers the entire filter frame.

#### 2.2.2 Exhaust Filter (AirClean Filter or HEPA Filter)

- The exhaust filter is typically located in a separate compartment, often at the rear or side of the vacuum cleaner. Consult your specific Miele vacuum cleaner's manual for its exact location.
- Open the exhaust filter compartment.
- Remove the old filter and insert the new one, ensuring it is correctly oriented and sealed.
- Close the filter compartment securely.

*Note:* The frequency of filter replacement depends on usage and the type of filter. Refer to your Miele vacuum cleaner's operating manual for specific recommendations.

## 3. OPERATING INSTRUCTIONS

---

Once the Miele Style U vacuum bag and filters are correctly installed, your vacuum cleaner is ready for operation. These bags are designed for optimal performance in Miele upright vacuum cleaners that specify Style U bags.

### 3.1 Bag Full Indicator

Most Miele vacuum cleaners are equipped with a bag full indicator. This indicator will change color or illuminate when the vacuum bag needs to be replaced. Do not wait until the bag is completely overflowing, as this can reduce suction power and strain the motor.

### 3.2 Optimal Performance

For consistent and powerful suction, it is recommended to replace the vacuum bag when the indicator signals it, or when you notice a decrease in suction power, even if the bag does not appear completely full. This ensures maximum airflow and filtration efficiency.

## 4. MAINTENANCE

The Miele Style U vacuum bags are designed for single use and require no maintenance other than proper disposal and timely replacement.

### 4.1 Disposal of Used Bags

- Once removed from the vacuum cleaner, the self-closing collar of the Miele bag seals in dust and allergens.
- Dispose of the sealed bag in your regular household waste according to local regulations.

### 4.2 Storage of New Bags and Filters

- Store unused vacuum bags and filters in their original packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep them out of reach of children and pets.

## 5. TROUBLESHOOTING

If you encounter issues after replacing your Miele Style U vacuum bag or filters, consider the following common solutions:

Problem	Possible Cause	Solution
Reduced suction after bag replacement.	Bag not installed correctly or filters are clogged.	Ensure the bag's collar is fully seated and clicked into place. Check and replace the motor protection filter and exhaust filter if necessary.
Bag does not fit into the compartment.	Incorrect bag style or improper unfolding.	Verify that you are using Miele Style U bags. Ensure the bag is fully unfolded and positioned correctly within the compartment before attempting to close the lid.
Dust escaping from the vacuum cleaner.	Bag not sealed, compartment lid not closed, or filter issues.	Check that the bag's collar is properly sealed and the dust compartment lid is securely latched. Inspect all filters for proper installation and replace if damaged or missing.

If these steps do not resolve the issue, please refer to your Miele vacuum cleaner's main operating manual or contact Miele customer support.

## 6. SPECIFICATIONS

Key specifications for the Miele Style U Vacuum Bags and Filters:

- **Product Type:** Vacuum Cleaner Bags and Filters
- **Bag Style:** Style U (AirClean)
- **Compatible Devices:** Miele Upright Vacuum Cleaners requiring Style U bags
- **Material:** Paper (Bags)

- **Number of Items:** 16 Vacuum Bags + 8 Filters (as per product description)
- **Item Model Number:** 09338540/4
- **Manufacturer:** Miele
- **Product Dimensions (Packaging):** 14.5 x 9 x 6.5 inches
- **Item Weight (Packaging):** 3.15 pounds
- **ASIN:** B00BLOY7DA

## 7. SUPPORT & WARRANTY

### 7.1 Product Support



For further assistance, technical support, or inquiries regarding your Miele vacuum cleaner and its accessories, please visit the official Miele website or contact Miele customer service directly. You can find more information and contact details on the [Miele Store on Amazon](#) or the main Miele corporate website.



### 7.2 Warranty Information

Miele Style U Vacuum Bags and Filters are consumable items. Specific warranty coverage for these accessories typically pertains to manufacturing defects upon purchase. For detailed warranty information concerning your Miele vacuum cleaner and its components, please refer to the warranty documentation provided with your original vacuum cleaner purchase or consult the official Miele website.

© 2023 Miele. All rights reserved. This manual is for informational purposes only.

## Related Documents

	<p><a href="#">Miele Vacuum Cleaners: Simply Breath Easy Floorcare Solutions</a></p> <p>Explore Miele's range of high-quality vacuum cleaners, including cylinder, stick, and robotic models. Discover innovative features, superior cleaning performance, and advanced hygiene for a healthier home. Learn about Miele's 'Immer Besser' philosophy.</p>
	<p><a href="#">Miele Guarantee Information and Conditions</a></p> <p>This document outlines the guarantee conditions and terms for Miele appliances across various European countries, detailing coverage, limitations, and user responsibilities.</p>

<div><div><div>Miele</div><div>Vacuum cleaner</div><div></div><div>Operating instructions</div></div><div><div>en-AU/NZ</div><div><div>HS22</div><div>M-Nr. 121932 270</div></div></div></div>	<div><div><a href="#">Miele Vacuum Cleaner HS22 Operating Instructions</a></div><div>Comprehensive operating instructions for the Miele HS22 vacuum cleaner, covering safety, usage, maintenance, troubleshooting, and optional accessories.</div></div>
<div><div><div>Miele</div><div></div><div><div>de</div><div>de</div><div>en</div><div>fr</div><div>it</div></div><div><div>Gebrauchsanweisung (Bodenstaubsauger)</div><div>Vacuum cleaner operating instructions</div><div>Mode d'emploi (aspirateur balai)</div><div>Istruzioni d'uso (aspirapolvere a traino)</div><div>Gebrauchsanweisung (Staubsauger)</div></div><div><div>HS22</div><div>M-Nr. 121932 270</div></div></div></div>	<div><div><a href="#">Miele HS22 Vacuum Cleaner Operating Instructions</a></div><div>Comprehensive operating instructions for the Miele HS22 vacuum cleaner, covering safety, device description, operation, maintenance, and troubleshooting.</div></div>