

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PROFLO](#) /

› [PROFLO PFWPLUSA7040 Plus A 70" x 40" Drop In 6 Jet Whirlpool Bath Tub Instruction Manual](#)

PROFLO PFWPLUSA7040

PROFLO PFWPLUSA7040 Plus A Whirlpool Bath Tub Instruction Manual

Model: PFWPLUSA7040

1. INTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your PROFLO PFWPLUSA7040 Plus A 70" x 40" Drop In 6 Jet Whirlpool Bath Tub. Please read all instructions thoroughly before beginning installation or use. Retain this manual for future reference.



Image 1.1: Top-down view of the PROFLO PFWPLUSA7040 Plus A Whirlpool Bath Tub, highlighting its oval design and jet placement.

2. SAFETY INFORMATION

WARNING: Risk of Electric Shock. Connect only to a circuit protected by a ground-fault circuit interrupter

(GFCI).

WARNING: Risk of Injury. Do not permit children to use this product unless they are closely supervised at all times.

- Always ensure proper electrical grounding according to local codes.
- Do not operate the whirlpool system without sufficient water in the tub.
- Avoid using abrasive cleaners or sharp objects that could damage the acrylic surface.
- Consult a qualified electrician and plumber for all installation procedures.
- Keep all electrical components dry and away from water spray.

3. INSTALLATION

The PROFLO PFWPLUSA7040 is designed for drop-in installation. Professional installation by a licensed plumber and electrician is highly recommended to ensure compliance with all local building and electrical codes.

3.1 Pre-Installation Checks

- Verify that the installation area can support the weight of the tub filled with water and a bather.
- Ensure adequate access for plumbing and electrical connections.
- Confirm that the rough-in dimensions match the tub specifications.

3.2 Plumbing and Electrical Connections

This model features a reversible drain placement, offering flexibility during installation. Connect the drain assembly according to the manufacturer's instructions and local plumbing codes. The whirlpool system requires a dedicated 120 Volt electrical circuit protected by a GFCI.



Image 3.1: Side view of the PROFLO PFWPLUSA7040 Plus A Whirlpool Bath Tub, illustrating its drop-in installation.

4. OPERATING INSTRUCTIONS

To operate your PROFLO whirlpool bath tub, follow these steps:

1. **Fill the Tub:** Ensure the drain is closed. Fill the tub with water to a level at least 2 inches above the highest jet. Do not operate the jets if the water level is below the jets.
2. **Activate Jets:** Locate the control button for the whirlpool system, typically on the rim of the tub. Press the button to turn the jets on. Press it again to turn them off.

3. **Adjust Jet Direction (if applicable):** Some jets allow for directional adjustment. Gently rotate the jet nozzle to direct the water flow as desired.
4. **Drain the Tub:** After use, open the drain to empty the tub.



Image 4.1: Top view of the tub, showing the six strategically placed jets and the control button for the whirlpool function.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your whirlpool bath tub.

5.1 Tub Surface Cleaning

The acrylic construction of the tub is designed for easy cleaning. Use a soft cloth or sponge with a non-abrasive, mild bathroom cleaner. Rinse thoroughly with clean water after cleaning. Avoid harsh chemicals, abrasive pads, or solvents as these can damage the acrylic finish.

5.2 Whirlpool System Cleaning

To clean the internal plumbing of the whirlpool system:

1. Fill the tub with hot water to 2 inches above the jets.
2. Add 2 tablespoons of low-foaming dishwasher detergent and 1/2 cup of household bleach.
3. Run the whirlpool system for 10-15 minutes.
4. Drain the tub and refill with cold water.
5. Run the whirlpool system for another 5 minutes to rinse.
6. Drain the tub completely.

6. TROUBLESHOOTING

If you encounter issues with your PROFLO whirlpool bath tub, refer to the following common problems and solutions:

- **Jets not operating:** Check if the GFCI has tripped. Reset if necessary. Ensure the tub is filled with water above the jets. Verify electrical connections.
- **Weak jet pressure:** Check for blockages in the jets. Ensure the pump intake is not obstructed.
- **Leaks:** Immediately turn off the whirlpool system and drain the tub. Inspect plumbing connections for tightness. Contact a professional plumber if the leak persists.

- **Unusual noise from pump:** Ensure the pump is properly mounted and free from obstructions. Check for air in the system; run the jets with the tub full to purge air.

For issues not resolved by these steps, contact PROFLO customer support or a qualified service technician.

7. SPECIFICATIONS

Feature	Specification
Model Number	PFWPLUSUSA7040
Brand	PROFLO
Dimensions (L x W x H)	70" x 40" x 20.5"
Material	Acrylic
Installation Type	Drop-In
Number of Jets	6
Capacity	75 Gallons
Electrical Requirements	120 Volts
Item Weight	100 Pounds
Color	Biscuit
UPC	781889197578

8. WARRANTY AND SUPPORT

The PROFLO PFWPLUSUSA7040 Whirlpool Bath Tub is covered under a **5-year residential warranty** and a **1-year commercial warranty**. This warranty covers defects in materials and workmanship under normal use and service. For warranty claims, technical assistance, or to purchase replacement parts, please contact PROFLO customer support. Keep your proof of purchase for warranty validation.

For further information, you may visit the official PROFLO website or contact their customer service department directly.