

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VTech](#) /

› [VTech VTCS6629-3 DECT 6.0 3-Handset Expandable Cordless Phone System with Caller ID and Answering System User Manual](#)

VTech CS66293

VTech VTCS6629-3 DECT 6.0 3-Handset Expandable Cordless Phone System User Manual

Model: CS66293

INTRODUCTION

This manual provides comprehensive instructions for the VTech VTCS6629-3 DECT 6.0 3-Handset Expandable Cordless Phone System. This system is designed to offer clear communication and convenient features for your home or office. Please read this manual thoroughly to ensure proper setup and operation of your new phone system.

Key Features:

- DECT 6.0 Digital Technology for enhanced security and clarity
- Three-Handset System for extended coverage
- Digital Answering System with message counter
- Caller ID/Call Waiting capability
- Backlit Keypad and Display for easy viewing
- Full-Duplex Handset Speakerphone
- Expandable up to 5 handsets (additional handsets sold separately)
- Intercom between handsets

WHAT'S IN THE BOX

Verify that your package contains the following items:

- Main Base Unit with Digital Answering System
- Cordless Handsets (3)
- Charging Cradles (2) for additional handsets
- AC Adapters (3) for base unit and charging cradles
- Telephone Line Cord
- Rechargeable Ni-MH Batteries (3)
- User's Manual (this document)

SETUP

1. Connecting the Base Unit

1. Plug one end of the telephone line cord into the TEL LINE jack on the back of the base unit.
2. Plug the other end of the telephone line cord into a telephone wall jack.
3. Plug one of the AC adapters into the POWER jack on the back of the base unit.
4. Plug the other end of the AC adapter into a wall outlet not controlled by a wall switch.

2. Battery Installation

Each handset requires a rechargeable Ni-MH battery. Follow these steps for each handset:

1. Open the battery compartment cover on the back of the handset.
2. Connect the battery pack plug securely into the jack inside the battery compartment.
3. Place the battery pack with the label UP into the battery compartment.
4. Close the battery compartment cover.

3. Charging the Handsets

Once the batteries are installed, place each handset in the main base unit or one of the charging cradles to charge. The CHARGE light on the handset will illuminate, indicating it is charging. Allow at least 10 hours for the batteries to fully charge before initial use.



Image: The VTech VTCS6629-3 system, showing the main base unit with one handset and two additional charging cradles with handsets. This illustrates the complete setup for charging all three handsets.

OPERATING YOUR PHONE SYSTEM

Making and Receiving Calls

- To make a call: Press **TALK/FLASH** or **SPEAKER**, then dial the number.
- To receive a call: Press **TALK/FLASH** or **SPEAKER** when the phone rings.
- To end a call: Press **OFF/CANCEL**.

Using the Digital Answering System

The main base unit features a digital answering system to record incoming messages. The message counter on the base unit displays the number of new messages.

- To turn the answering system ON/OFF: Press the **ANS ON/OFF** button on the base unit.
- To play messages: Press **PLAY/STOP** on the base unit.
- To delete messages: Press **DELETE** during message playback.

Video: A product overview demonstrating the VTech cordless phone system, including the answering machine functions on the base unit. This video highlights how to play, skip, and delete messages, and turn the answering system on or off.

Caller ID and Call Waiting

The phone displays the caller's name and number (if available) before you answer. If you subscribe to Call Waiting service, the phone will alert you to a new incoming call while you are on another call.

- To review Caller ID history: Press **CID** on the handset.
- To answer a waiting call: Press **FLASH**.

Intercom Between Handsets

You can use the intercom feature to communicate between two handsets within the system.

- To initiate an intercom call: Press **INT** on a handset, then dial the number of the destination handset (e.g., 1, 2, or 3).
- To end an intercom call: Press **OFF/CANCEL**.

Speakerphone Function

Each handset is equipped with a full-duplex speakerphone, allowing for hands-free conversations.

- To activate speakerphone during a call: Press **SPEAKER**.
- To switch back to handset mode: Press **TALK/FLASH**.

Backlit Keypad and Display

The handsets feature a backlit keypad and display, making it easier to dial and view information in low-light conditions.



Image: A close-up view of a VTech VTCS6629-3 handset, highlighting its backlit keypad and display for improved visibility.

MAINTENANCE

- **Cleaning:** Clean the phone and handsets with a soft, damp cloth. Do not use cleaning agents or abrasive powders.
- **Battery Care:** To maintain optimal battery performance, fully charge the handsets for 10 hours before initial use. If the phone will not be used for an extended period, remove the batteries.
- **Avoid Water:** Do not expose the phone system to water or moisture.

TROUBLESHOOTING

If you experience issues with your phone system, try the following common solutions:

Problem	Solution
No dial tone	Ensure the telephone line cord is securely plugged into both the base unit and the wall jack. Check if the AC adapter is properly connected.

Problem	Solution
Handset not charging	Make sure the handset is correctly placed in the base unit or charging cradle. Verify the AC adapter for the charging unit is plugged into a working outlet. Clean the charging contacts on the handset and charger.
Poor sound quality	Move closer to the base unit. Ensure there are no large metal objects or other electronic devices interfering with the signal. Check your telephone line connection.
Answering system not recording	Ensure the answering system is turned ON. Check if the memory is full; delete old messages if necessary.
Handset displays "Out of range"	Move the handset closer to the base unit. Ensure the base unit is powered on.

SPECIFICATIONS

Feature	Detail
Product Dimensions	5.2 x 6.7 x 6.9 inches
Item Weight	1.5 pounds
Model Number	CS66293
Batteries	1 AAA batteries required (included) per handset
Telephone Type	Cordless
Answering System Type	Digital
Color	Silver
Manufacturer	VTech
Date First Available	March 7, 2013

WARRANTY AND SUPPORT







For warranty information and technical support, please refer to the documentation included with your product or visit the official VTech website. Keep your purchase receipt as proof of purchase.

SAFETY INFORMATION

Legal Disclaimer: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury to persons.

Related Documents - CS66293

<p>VG 208 208-2</p>  <p>vtech User's manual</p>	<p>VTEch VG208 / VG208-2 User Manual: Features, Safety, and Operation Guide</p> <p>Comprehensive user manual for the VTEch VG208 and VG208-2 DECT 6.0 cordless phones. Learn about installation, operation, features like answering machine, caller ID, call blocking, intercom, safety instructions, and technical specifications.</p>
	<p>VTEch Expandable Cordless Phone User Guide - Setup and Operation</p> <p>Get started with your VTEch Expandable Cordless Phone (DECT 6.0) using this user guide. Learn about easy installation, battery setup, handset and base features, answering system operation, caller ID, intercom, and directory management. Find support links and model information for VTEch phones.</p>
	<p>VTEch CS5229 Cordless Phone Quick Start Guide</p> <p>This guide provides instructions for setting up and using the VTEch CS5229 DECT 6.0 cordless telephone, including installation, basic operation, phonebook, caller ID, call blocking, and answering system features.</p>
	<p>VTEch VS122-16 Cordless Phone Quick Start Guide</p> <p>A quick start guide for the VTEch VS122-16 cordless phone, covering setup, features like Smart Call Blocker, Caller ID, Phonebook, Answering System, and Bluetooth connectivity.</p>
	<p>VTEch CS6529 Series Cordless Telephone User Manual</p> <p>Comprehensive user's manual for the VTEch CS6529 series cordless telephone, covering setup, operation, features like answering system and caller ID, troubleshooting, and safety instructions.</p>
	<p>VTEch CS5209 DECT 6.0 Accessory Handset User Manual</p> <p>User manual for the VTEch CS5209 DECT 6.0 accessory handset, providing instructions on setup, registration, operation, and safety precautions. Learn how to install the battery, connect the charger, register new handsets, and understand display icons and features.</p>