

Lorell LLR60622

Lorell LLR60622 Executive Mesh-Back Chair User Manual

Model: LLR60622

[Contents](#) [Setup](#) [Operation](#) [Introduction](#) [Safety Information](#) [Package](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. INTRODUCTION

Thank you for choosing the Lorell LLR60622 Executive Mesh-Back Chair. This chair is designed to provide ergonomic support and comfort for office environments. It features a breathable mesh back, a posture mechanism for independent back angle adjustment, pneumatic seat-height adjustment, 360-degree swivel, and tilt functions with tension control and lock.



Figure 1: Lorell LLR60622 Executive Mesh-Back Chair. This image shows the chair from a front-side angle, highlighting its mesh back, padded seat, and five-star base with casters.

2. SAFETY INFORMATION

- **Maximum Weight Capacity:** This chair is designed to support a maximum weight of 250 pounds (113 kg). Do not exceed this limit to prevent damage or injury.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions before use. Regularly check all bolts and screws for tightness.
- **Adjustments:** Follow instructions for safe operation of all adjustable mechanisms. Avoid sudden movements or excessive force when adjusting the chair.
- **Stability:** Do not stand on the chair. Avoid leaning excessively to one side or backward, especially when the tilt mechanism is unlocked, to prevent tipping.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play on or with the chair.
- **Maintenance:** Perform routine maintenance as described in this manual. Discontinue use if any part is damaged or

missing.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Seat Cushion (1)
- Mesh Backrest (1)
- Gas Lift Cylinder (1)
- Five-Star Base (1)
- Casters (5)
- Mechanism Plate (1)
- Hardware Pack (Screws, Washers, Allen Wrench) (1)

4. SETUP AND ASSEMBLY

Assembly is required for this chair. It is recommended to assemble the chair on a soft, clean surface to prevent damage. Two people may be helpful for certain steps.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the five-star base. Push firmly until they click into place.
2. **Insert Gas Lift Cylinder:** Place the gas lift cylinder into the center hole of the assembled five-star base. Ensure it is seated firmly.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism (usually indicated by an arrow or "FRONT" label) faces the front of the seat. Secure with the provided screws and Allen wrench.
4. **Attach Backrest to Seat:** Align the backrest support with the corresponding holes on the mechanism plate or seat. Secure with the provided screws.
5. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the cylinder's top fits securely into the mechanism plate's center hole. Apply downward pressure to seat the components.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the chair's adjustment features to optimize your comfort and support.

- **Pneumatic Seat-Height Adjustment:**
Locate the lever on the right side, beneath the seat. To raise the seat, lift the lever while taking your weight off the seat. To lower the seat, lift the lever while seated.
- **360-Degree Swivel:**
The chair is designed to rotate freely 360 degrees on its base, allowing for easy movement and access to your workspace.
- **Tilt Function and Tilt Lock:**
The lever on the left side, beneath the seat, controls the tilt function. Pull the lever out to allow the chair to recline. Push the lever in to lock the chair in an upright position.
- **Tilt Tension Adjustment:**

The round knob located at the front, under the seat, adjusts the resistance of the tilt mechanism. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).

• **Posture Mechanism / Back Angle Adjustment:**

This mechanism allows the backrest angle to be adjusted independently of the seat. Locate the lever (often a second lever on the right side or a separate knob). Engage this lever to unlock the backrest, adjust it to your desired angle, and then push the lever back in to lock the angle. This allows for multiple locked positions.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your Lorell Executive Mesh-Back Chair.

• **Cleaning:**

For general cleaning, use a soft, damp cloth. For spot cleaning the fabric seat, use a mild upholstery cleaner and follow the product's instructions. Avoid harsh chemicals or abrasive cleaners.

• **Inspection:**

Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary. Inspect casters for any debris that might hinder smooth movement.

• **Moving the Chair:**

When moving the chair, lift it rather than dragging it to prevent damage to the casters or base.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder is faulty or lever is not fully engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact support.
Chair squeaks when moving.	Loose connections or friction between parts.	Check and tighten all assembly screws. Apply a small amount of silicone lubricant to moving parts if necessary, avoiding contact with fabric.
Casters do not roll smoothly.	Debris caught in casters or damaged casters.	Remove any hair or debris from the caster wheels. If casters are damaged, they may need replacement.
Chair feels unstable.	Loose connections or improper assembly.	Re-check all assembly steps and ensure all screws are securely tightened. Verify the gas lift is properly seated in the base.

8. SPECIFICATIONS

Model Number	LLR60622
Brand	Lorell
Color	Fabric/Black
Material	Textile (Seat), Mesh (Back), Nylon (Frame)

Product Dimensions (D x W x H)	29"D x 16.9"W x 25.8"H
Item Weight	48.5 Pounds (22 kg)
Maximum Weight Recommendation	250 Pounds (113 kg)
Assembly Required	Yes
Features	Pneumatic Seat-Height Adjustment, 360-Degree Swivel, Tilt, Tilt Tension, Tilt Lock, Posture Mechanism/Back Angle Adjustment, Rolling Casters
Recommended Use	Office
UPC	035255606226

9. WARRANTY INFORMATION

The Lorell LLR60622 Executive Mesh-Back Chair comes with a manufacturer's warranty of **5 years** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, please refer to the warranty documentation included with your product or contact Lorell customer support.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Lorell customer support.

- **Website:** Visit the official Lorell website for FAQs and support resources.
- **Email:** Refer to your product packaging or the Lorell website for customer service email contact.
- **Phone:** Refer to your product packaging or the Lorell website for customer service phone numbers.

Please have your model number (LLR60622) and proof of purchase ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question